




Specific Parts:

- USB Type B: Same Sky UJ2-B-HR-G-TH

- RCA Jack: Kobiconn 156-0099-E

- 3.5mm Mono Jack: Same Sky SJ3-350820B

- DE9 Plug: Amphenol L717SDE09PA4CH4FC309 (or similar)

Brett Hallen

Sheet: /

File: ZX26\_Computer.kicad\_sch

Title: ZX26 Computer

Size: A4

Date: 22/JUL/2026

Rev: Issue 1

KiCad E.D.A. 10.0.3

Id: 1/4

H1

MountingHole

H2

MountingHole



H3

MountingHole


H4

MountingHole


# Dedicated cursor keys



# Keyboard



Atari-compatible Joystick  
Directions map to 5/6/7/8 cursor keys  
Fire maps to either 0 or SPACE



Brett Hallen


Sheet: /ZX26 Keyboard & Joystick/  
File: ZX26\_Computer\_Keyboard\_Joystick.kicad\_sch

Title: ZX26 Computer


Size: A4 Date: 22/JUL/2026  
KiCad E.D.A. 10.0.3

Rev: Issue 1  
Id: 2/4

RAM (32KB)



ROM (32KB)  
Four switchable 8KB banks



Brett Hallen

Sheet: /ZX26 Memory (ROM & RAM)/  
File: ZX26\_Computer\_Memory.kicad\_sch

**Title: ZX26 Computer**

Size: A4 Date: 22/JUL/2026  
KiCad E.D.A. 10.0.3

Rev: Issue 1  
Id: 3/4

