








Dedicated cursor keys



Keyboard



Atari-compatible Joystick
Directions map to 5/6/7/8 cursor keys
Fire maps to either 0 or SPACE



Brett Hallen

Sheet: /ZX26 Keyboard & Joystick/
File: ZX26_Computer_Keyboard_Joystick.kicad_sch


Title: ZX26 Computer

Size: A4 Date: 22/JUL/2026
KiCad E.D.A. 10.0.3


Rev: Issue 1
Id: 2/4

vLAB1 SW3/SW4 RAM Settings
MODE 0 (ON/OFF): 16KB (4000-7FFF) [STANDARD ZX81]
MODE 1 (OFF/ON): 32KB (4000-BFFF) [UPPER 32KB HIRES]
MODE 2 (OFF/ON): 32KB (2000-9FFF) [LOWER 32KB WRX HIRES]
MODE 3 (ON/ON): 32KB (0000-7FFF) [SOFT CONFIG]

RAM (32KB)



ROM (32KB)
Four switchable 8KB banks



Brett Hallen

Sheet: /ZX26 Memory (ROM & RAM)/
File: ZX26_Computer_Memory.kicad_sch

Title: ZX26 Computer

Size: A4 Date: 22/JUL/2026

KiCad E.D.A. 10.0.3

Rev: Issue 1

Id: 3/4

