# Open Time Series Database (OpenTSDB)

Document Revision 3
March, 2020

Copyright 2016, Cove Software, LLC, All Rights Reserved.

Cove Software, LLC (410) 715-1117 info@covesw.com



### **Table of Contents**

1	Ove	rview1	
	1.1	Revision History	
2 Installation and Configuration		allation and Configuration2	
	2.1	Fresh Schema Install	
	2.2	Configure OpenDCS	
	2.3	TSDB-Specific Properties	
3 Schema			
	3.1	OpenTSDB Time Series ID4	
	3.2	TSDB Global Properties4	
	3.3	Metadata About Each Time Series4	
	3.4	Interval and Duration Fields6	
	3.5	Time Series Values6	
	3.6	Time Series Properties	
	3.7	Time Series Value Data Sources	
	3.8	Time Series Value Annotions	
4	DEC	CODES OpenTSDB Consumer10	
	4.1	Building the TSID	
5 Time Series Utilities		e Series Utilities15	
	5.1	Updating Old Schema15	
	5.2	GUI Time Series List	
	5.3	Outputting Time Series Values	
	5.4 Importting Time Series Values		
	5.5	The 'Rebalance' Utility	
	5.6	List Time Series Data Sources	
	<b>5.</b> 7	The Generic "DbUtil" Utility	
		lroJSON Server21	
	6.1	Deploying the HydroJSON Server	
	6.2	Server Request Details	
	6.2.	1 Retrieve Catalog of Sites22	
	6.2.		
6.2.		3 Retrieve Data by TSIDs22	

### 1 Overview

OpenTSDB (TSDB = Time Series Database) is an extension of OpenDCS first included in the 6.5 release. This manual describes the schema and utilities making up OpenTSDB.

# 1.1 Revision History

Rev 1: OpenDCS 6.5 RCo1, June, 2018:

Initial release

Rev 2: OpenDCS 6.7 RCo1, February, 2020

- This release supports computations.
- The sections on Exporting and Importing time series data have been expanded and improved. The "outputts" and "importts" utilities now provide a good way of backing up time series data in an ASCII file, or for transferring data from one database to another. For example, you could use this to transfer data from a CWMS database into OpenTSDB.

Rev 3: OpenDCS 6.7 RCo2, March, 2020

• Define bits used for time series values.

# 2 Installation and Configuration

### 2.1 Fresh Schema Install

After installing OpenDCS 6.5 you will find a schema subdirectory containing two other subdirectories:

- opendcs-pg Schema installation scripts for PostgreSQL
- opendcs-oracle Schema installation scripts for Oracle

Follow the instructions in the README files contained in those directories for a fresh install.

# 2.2 Configure OpenDCS

Follow the instructions in the OPENDCS Installation Guide to configure your database. Make sure the Database Type is set to OPENTSDB.

### 2.3 TSDB-Specific Properties

The database schema contains a table "tsdb\_property" (see schema below). Currently the only way to add values to the table is with direct SQL statements. This will be improved in future releases. The following properties will affect OpenTSDB operation:

- allowDstOffsetVariation: (default = true) Allowing the variation means that daily averages may vary by an hour over a DST change. Setting to false will force OpenTSDB to operate like CWMS: The UTC Offsets must remain consistent for all values stored.
- offsetErrorAction: (default = ROUND) One of IGNORE, REJECT, or ROUND. This determines how sample times may be modified for time series values stored in the database for regular interval time series:
  - o INGORE means to do nothing. Store time values as-is
  - o ROUND means to round to the nearest regular interval
  - REJECT means to reject values that are not on a regular interval
- storagePresentationGroup: (default = CWMS-English) When creating a new time series, the presentation group named here will be used to determine the storage units based on the data type of the time series being created.
  - Note that for OpenDCS 6.5 a modification has been made for CWMS data types. The presentation group may contain Base Param values only. When attempting to find a match for a data type (e.g. "Stage-Tailwater"), if no exact match is found in the group, the code will look for a match for the base param value ("Stage"). Thus, you only need Base Params in the CWMS-English and CWMS-Metric presentation groups.

You can edit the TSDB\_PROPERTY values using a dialog in the Time Series GUI. From the launcher, select Time Series. Then press the TSDB Properties button in the upper right. Each property is shown with an explanation as to its use and proper setting.

# 3 Schema

### 3.1 OpenTSDB Time Series ID

An OpenTSDB Time Series Identifier (TSID) has 6 parts, separated by periods:

location . param . statcode . interval . duration . version

The location, param, and version parts are often subdivided with hyphens.

### **Example:**

```
Crystal-HeadWater.Inst.Elev.1Hour.O.GOES-raw
```

### The components are:

- *location* This refers to a Site in the DECODES database. This is the site name, preferably with CWMS name-type.
- param This is a DECODES Data Type, preferably with CWMS data type.
- *statcode* Statistics Code qualifies how the data was measured or calculated. See examples below. (Note In CWMS this is called param type).
- *interval* One of the valid intervals in this database. All CWMS intervals are accepted.
- *duration* o (zero) means an instantaneous value. Other intervals can specify the duration over which the value was measured or calculated.
- *version* A free-form string used to distinguish between different versions of a time series, e.g. raw vs. validated.

## 3.2 TSDB Global Properties

```
-- Global properties on the database components.

CREATE TABLE TSDB_PROPERTY
(

PROP_NAME VARCHAR(24) NOT NULL UNIQUE,
PROP_VALUE VARCHAR(240) NOT NULL,
PRIMARY KEY (PROP_NAME)
) WITHOUT OIDS;
```

### 3.3 Metadata About Each Time Series

```
CREATE TABLE TS_SPEC
(
TS_ID INT NOT NULL UNIQUE,
SITE_ID INT NOT NULL,
DATATYPE_ID INT NOT NULL,
STATISTICS CODE VARCHAR(24) NOT NULL,
```

```
INTERVAL ID INT NOT NULL,
    DURATION ID INT NOT NULL,
    TS VERSION VARCHAR (32) NOT NULL,
    ACTIVE FLAG VARCHAR (5) DEFAULT 'TRUE' NOT NULL,
    STORAGE UNITS VARCHAR (24) NOT NULL,
    -- Number of data storage table where values for this TS are stored.
    STORAGE TABLE INT NOT NULL,
    -- 'N' for numeric, 'S' for String.
    STORAGE TYPE CHAR DEFAULT 'N' NOT NULL,
    -- Last Modify Time for this record, stored as Java msec time value
UTC.
   MODIFY TIME BIGINT NOT NULL,
    DESCRIPTION VARCHAR (400),
    -- Initially set to NULL. After first ts value written, this is set to
number of seconds.
    UTC OFFSET INT,
    -- NULL = use default in TSDB PROPERTIES, TRUE=allow, FALSE=disallow
   ALLOW DST OFFSET VARIATION VARCHAR (5),
    -- NULL-use default in TSDB PROPERTIES, ROUND, REJECT, or IGNORE
    OFFSET ERROR ACTION VARCHAR (24),
    PRIMARY KEY (TS ID),
    CONSTRAINT time series identifier unique UNIQUE (SITE ID, DATATYPE ID,
STATISTICS CODE, INTERVAL ID, DURATION ID, TS VERSION)
) WITHOUT OIDS;
```

#### Notes:

- TS\_ID is a unique numeric key assigned from a sequence when the time series is created.
- SITE\_ID points to a DECODES Site record. This is analogous to a CWMS location.
- DATATYPE\_ID points to a DECODES DATATYPE record. This is analogous to a CWMS "Param".
- STATISTICS\_CODE is analogous to a CWMS "Param Type".
- INTERVAL\_ID and DURATION\_ID both point to records in the INTERVAL\_CODE table (see below).
- STORAGE\_UNITS must be a valid DECODES Engineering Unit abbreviation. It specifies the units in which the time series values are stored.
- STORAGE\_TABLE is an integer which specifies a 4-digit suffix to the table name where the actual data values are stored (see below).
- STORAGE\_TYPE currently the only acceptable value is 'N'. String values are not yet supported.
- MODIFY\_TIME specifies the last time the TS\_SPEC record was modified. It is a Java msec value specifies the number of ms since Midnight, Jan 1, 1970 UTC.
- UTC\_OFFSET can be used for regular interval data to ensure they all have the same UTC offset.
- ALLOW\_DST\_OFFSET\_VARIATION can be set to true to allow the offset to vary based on DST changes. Example: a daily value stored at local midnight would have a UTC\_OFFSET variance when DST changes.

### 3.4 Interval and Duration Fields

Valid Interval and Durations are stored in the INTERVAL\_CODE table:

```
CREATE TABLE INTERVAL_CODE

(
    INTERVAL_ID INT NOT NULL UNIQUE,
    -- Interval Name for Display in Pull-Down lists, files, etc.
    NAME VARCHAR(24) NOT NULL UNIQUE,
    -- Java Calendar Constant Name.
    -- One of MINUTE, HOUR_OF_DAY, DAY_OF_MONTH, WEEK_OF_YEAR, MONTH, YEAR CAL_CONSTANT VARCHAR(16) NOT NULL,
    -- Multiplier for calendar constant.
    -- Zero means instantaneous.
    CAL_MULTIPLIER INT NOT NULL,
    PRIMARY KEY (INTERVAL_ID)
) WITHOUT OIDS;
```

### 3.5 Time Series Values

The software tries to spread the time series values among the available tables that you created when you installed the database, or when you run the Rebalance utility (see below).

Table names are TS\_NUM\_NNNN, where NNNN is a 4 digit suffix. To determine the table, take the TS\_SPEC.STORAGE\_TABLE integer and format it as a 4-digit number. The tables have the following format:

```
CREATE TABLE TS_NUM_0001
(

TS_ID INT NOT NULL,
SAMPLE_TIME BIGINT NOT NULL,
TS_VALUE DOUBLE PRECISION NOT NULL,
-- Bitwise flags for each value
FLAGS BIGINT NOT NULL,
SOURCE_ID INT NOT NULL,
DATA_ENTRY_TIME BIGINT NOT NULL,
PRIMARY KEY (TS_ID, SAMPLE_TIME)
) WITHOUT OIDS;
```

Thus all values for a given time series are in the same table. This is different from CWMS, which divides the values by time: Each year has a separate data table in CWMS.

The FLAGS word is a collection of bit flags indicating various validation and other conditions. The following code defines the bits used by OpenTSDB. Bits not defined are reserved for future use:

```
// The value was successfully screened.
public static final int SCREENED
                                                           = 0 \times 00010000;
// Apply this mask and compare to SCR_VALUE_xxx definitions
// to obtain result
public static final int SCR VALUE RESULT MASK
                                                           = 0 \times 000 E00000;
public static final int SCR_VALUE_GOOD
                                                           = 0 \times 000000000:
public static final int SCR_VALUE_REJECT_HIGH
                                                           = 0 \times 00020000;
public static final int SCR_VALUE_CRITICAL_HIGH
                                                           = 0 \times 00040000;
public static final int SCR VALUE WARNING HIGH
                                                           = 0 \times 000600000;
public static final int SCR_VALUE_WARNING_LOW
                                                           = 0 \times 000800000;
public static final int SCR VALUE CRITICAL LOW
                                                          = 0 \times 0000 A00000;
public static final int SCR_VALUE_REJECT_LOW
                                                           = 0 \times 000 \times 0000;
// Apply this mask and compare to SCR ROC xxx definitions
// to obtain result
public static final int SCR_ROC_RESULT_MASK
                                                           = 0 \times 007000000;
public static final int SCR_ROC_GOOD
                                                           = 0 \times 0000000000:
public static final int SCR_ROC_REJECT_HIGH
                                                           = 0 \times 001000000;
public static final int SCR ROC CRITICAL HIGH
                                                           = 0 \times 002000000:
public static final int SCR_ROC_WARNING_HIGH
                                                           = 0 \times 003000000;
public static final int SCR ROC WARNING LOW
                                                          = 0 \times 00400000;
                                                        = 0 \times 005000000;
public static final int SCR_ROC_CRITICAL_LOW
public static final int SCR ROC REJECT LOW
                                                           = 0 \times 006000000;
public static final int SCR_STUCK_SENSOR_DETECTED = 0x00800000;
// The following is NOT stored in data values, but used by the
// alarm system only
public static final int SCR_MISSING_VALUES_EXCEEDED = 0x010000000;
```

### 3.6 Time Series Properties

TS\_PROPERTY records are not currently used. They are intended for future expansion where there may be a need for additional meta-data not currently stored in TS\_SPEC.

```
CREATE TABLE TS_PROPERTY
(

TS_ID INT NOT NULL,
PROP_NAME VARCHAR(24) NOT NULL,
PROP_VALUE VARCHAR(240) NOT NULL,
PRIMARY KEY (TS_ID, PROP_NAME)
) WITHOUT OIDS;
```

### 3.7 Time Series Value Data Sources

The TSDB tracks the source of every value in the database through the SOURCE\_ID field in the TS\_NUM\_nnnn tables. The SOURCE\_ID refers to a record in TSDB\_DATA\_SOURCE:

```
CREATE TABLE TSDB_DATA_SOURCE

(

SOURCE_ID INT NOT NULL UNIQUE,
LOADING_APPLICATION_ID INT NOT NULL,

-- Further describes source: If DECODES routing spec,
-- this should be the rs and ds names.

-- If manual entry, this is user name
-- If computation, this is comp name
-- If modeled, this is the model name, etc.

MODULE VARCHAR(120),
PRIMARY KEY (SOURCE_ID)
) WITHOUT OIDS;
```

The combination of LOADING\_APPLICATION\_ID and MODULE should be unique. Thus a TSDB\_DATA\_SOURCE tells us, for each value, what application and module within that application created that values. Examples are:

- Routing Scheduler / Routing Spec Name
- Computation Processor / Computation Name

## 3.8 Time Series Value Annotions

TS\_ANNOTATION records are not currently used. They are intended for a new feature whereby a user could add a free form text annotation describing time series values over a given time range.

```
CREATE TABLE TS_ANNOTATION (

ANNOTATION ID INT NOT NULL UNIQUE,
```

TS\_ID INT NOT NULL,

START\_TIME BIGINT NOT NULL,

END\_TIME BIGINT NOT NULL,


ANNOTATION\_TEXT VARCHAR(1000) NOT NULL,

PRIMARY KEY (ANNOTATION\_ID)

) WITHOUT OIDS;

# **4 DECODES OpenTSDB Consumer**

The OpenTSDB Consumer writes time series data to the OpenTSDB. If you have an older OpenDCS Installation, your database may not have the consumer in its list. Before attempting to use the consumer, run the Reference List Editor (rledit). On the Enumerations Tab, select the Data Consumer enumeration. Make sure there is an entry for opentsdb and the the java class is exactly as shown below.



### The Java class must be exact:

opendcs.opentsdb.OpenTsdbConsumer

When using the consumer, you may specify the following properties in the routing spec:

Property Name	Default	Description
databaseLocation	null	By default, it will assume that you want to ingest data into the same database that hosts your DECODES data. If you want to write to a <i>different</i> OpenTSDB, you can specify the location URL here.
dbAuthFile	null	Not needed if databaseLocation is the default (null). If you are connecting to a <i>different</i> OpenTSDB, you can run 'setDecodesUser' with a file name to create an encrypted file containing the username and password. Then specify that file name as a property here.
jdbcOracleDriver	null	Also not needed if you are writing to the same database as DECODES. If it is a <i>different</i> database, you can specify the JDBC driver class here.
		The value for postgres is 'org.postgresql.Driver'
		The value for Oracle is 'oracle.jdbc.driver.OracleDriver'
appName	decodes	The consumer will make a connection to the database as this application. OpenTSDB tracks connections by app name.
dataTypeStandard	CWMS	Specifies which sensor data type to use to build the TSID. (See below.)
shefParamMapping	null	If you want to map SHEF-PE codes to the param type of the TSID, specify a mapping file here. (See below.)
tsidDuration	0	The default duration part for a time series ID if none is specified in the individual sensors. (See below.)
tsidVersion	raw	The default version for a time series ID if none is specified in the individual sensors. (See below.)
canCreateTs	true	Set to false if you do NOT want this routing spec to be able to create time series if it builds a TSID that does not yet exist.

# 4.1 Building the TSID

This section exlains how the consumer takes information from the DECODES database to build the TSID.

### Location

The Location part is taken from the DECODES site where the platform is located, or, if a sensor-specific site has been specified, it is used.

The CWMS name type is selected if one is present. If not, the preferred name type that you specified in your DECODES settings is used.

#### **Param**

The Param part is taken from one of the DECODES Data Type codes assigned to the sensor. A routing spec property called 'dataTypeStandard' may be used to specify one of the valid Data Type Standards in your database.

Hint: You can use the Reference List Editor (rledit) to define which data type standards are valid in your database.

If no property is specified, CWMS is used as a default.

Then if the specified data type is present it is used. If not, the sensor is skipped.

Exception for SHEF Parameter Mapping: If you specify a property named 'shefParamMapping' containing the name of a mapping file, then the SHEF-PE data type code will be used to look up a parameter in the named file. The format of each line in the file is:

SHEFCODE=Param

#### **Statistics Code**

If a DECODES Sensor Property named either 'statcode' or 'CwmsParamType', then the value will be used as the statcode part of the TSID. Otherwise, 'Inst' will be used.

### **Interval**

If a Sensor Property named 'cwmsInterval' is present, it will be used as the interval part of the TSID. Otherwise:

- If the recording mode is Variable (meaning an irregular time series), interval will be set to 0.
- Otherwise the interval will be derived from the specified recording interval in seconds.

### **Duration**

If a Sensor Property named 'cwmsDuration' is present, it will be used as the duration part of the TSID. Otherwise:

- If the recording mode is Variable (meaning an irregular time series), interval will be set to o.
- Else, if the Statistics Code determined above is 'Inst', o will be used as the duration.
- Else, the interval determined above will be used.

### Version

The routing spec property 'cwmsVersion' may be used to specify the default version part for all sensors. If none is specified, the default is 'raw'.

Each sensor can also specify a property named 'cwmsVersion' that will override the default.

#### Presentation Routing Sources Platforms Sites Configs Equipment Network List List Properties Name: opentsdb-ingest Add Value Data Source: covesw3 debugLevel Edit Irgs.timeout Destination: opentsdb appName Delete canCreateTS DB URI (if external DB): compConfig databaseLocation Output Format: dataTypeStandard Time Zone: UTC dbAuthFile Presentation Group: SHEF-English jdbcOracleDriver noLimits Enable in-line computations Is Production nassword Platform/Message Types Since: Now -10 days GOES Self Timed GOES Random Real Time 30 sec delay to avoid duplicates Until: Quality Notifications Apply To: Local Receive Time Ascending time order (may slow retrievals) GOES Spacecraft: East Platform Selection Enter Platform ID Value Network/Modem DCP Netlist test-platforms Select Platform Good Parity: Select from PDT Clear All Select All Add Network List Add GOES Channel

### The following routing spec runs in real time and ingests data into the OpenTSDB:

### Note:

Edit

Commit

Remove

Close

Clear

• Since we are ingesting into the same database where DECODES is running, no DB URI or username or password are necessary.

Help

- Output Format=null, because we are not formatting data, but rather placing it into the TSDB tables.
- SHEF-English presentation group is used. This will determine storage units when creating new time series in the database.

# **5** Time Series Utilities

### 5.1 Updating Old Schema

If you installed the database from pre OpenDCS 6.5 schema files you will need to update. A Java utility is provided to do this.


### Command:

dbupdate

You will be prompted to enter the TSDB Schema owner's database username and password. Tables will be modified to conform to OpenDCS 6.5 schema. the internal TSDB\_DATABASE\_VERSION number will be set to 16.

### 5.2 GUI Time Series List

The Time Series List GUI can be activated from the Launcher Button panel or from the "tslist" script:



It shows a list of time series which may be sorted in different ways by clicking the column headers.

This GUI is not unique to OpenTSDB. It also works for CWMS and HDB.

**Buttons:** 

- Open Not yet implemented. In a future release this will provide a way to edit the meta data about a time series, change its storage units, etc.
- New Brings up a dialog in which you can specify the time series identifier components and create a new time series.
- Delete Deletes a time series including all of its values and meta data.
- Refresh refreshes the list from the database.

### **5.3 Outputting Time Series Values**

### Command:

```
outputts [options] TSID|group:groupName|all [TSID2 ...]
```

This command can output time series data in any of the DECODES data formats. Run with –x for a help message showing options:

```
$ bin/outputts -x
Error: Unknown option -x
Usage: program [-Y <String>] [-P <String>] [-d <Int>] [-l <String>] [-D
<String> ...] [-c <String>] [-t ] [-m <Int>] [-a <String>] [-S <String>] [-
U <String>] [-F <String>] [-Z <String>] [-L <String>] [-G <String>] [-I
<String>] <String> ...
   -d 'debug-level' Default: 0
   -l 'log-file' Default: util.log
   -S 'Since Time dd-MMM-yyyy/HH:mm'
   -U 'Until Time dd-MMM-yyyy/HH:mm'
   -F 'OutputFormat' Default: Human-Readable
   -Z 'Time Zone' Default: UTC
   -L 'Lookup Type' Default: id
   -G 'PresentationGroup'
   -I 'TransportID'
    'time-series-IDs | all | group:groupname'
```

### **Examples:**

Output a specific time series values since midnight May 15 in HydroJSON format:

```
outputts -S 15-May-2018/00:00 -F HydroJSON HNTT1.Stage.Inst.30Minutes.0.raw
```

Output all values for a specific time series:

```
outputts -S all -F tsimport HNTT1.Stage.Inst.30Minutes.0.raw > somefile
```

Output all values for time series in a group named "Stages":

```
outputts -S all -F tsimport group:Stages > somefile
```

Output all values for all time series. This is suitable for making a backup of for transferring time series values to some other database:

```
outputts -S all -F tsimport all > somefile
```

Output is written to stdout. You can redirect to file if desired.

Note: Using the tsimport format as shown in the example above is the easiest way to transfer data from one database to another.

Example: suppose you wanted to transfer data from a group of time series on your CWMS database into an OpenTSDB database. Suppose the group is called "Stages".

1. On the CWMS Database, run:

```
outputts -S all -F tsimport group:Stage > somefile
```

- 2. Transfer "somefile" from the CWMS machine to the OpenTSDB installation.
- 3. On the OpenTSDB installation run:

```
importts somefile
```

# **5.4 Importting Time Series Values**

### Command:

```
Importts filename
```

### Description:

Reads the file and imports the data into HDB.

The file has three types of lines:

- SET:TZ=TimeZone
- TSID:Full Time Series Path Name
- SET:UNITS=Units Abbreviation, e.g. "ft"
- Data line: YYYY/MM/DD-HH:MM:SS,Value,Flags

The SET and TSID apply to all subsequent data lines.

# 5.5 The 'Rebalance' Utility

The Rebalance utility can be used to add new data tables after the initial installation.

#### Command:

```
decj opendcs.opentsdb.Rebalance [-N numTables]
```

Where the optional *numTables* integer specifies the number of numeric tables to add to the database.

Scenario: You created the database with a very small number of numeric tables (say, 10), but now that you have hundreds of time series, data writes and retrievals are becoming

slow. You wish to create new numeric data tables and then move existing time series among the tables to balance the load.

### 5.6 List Time Series Data Sources

This utility lists all of the unique TSDB\_DATA\_SOURCE records in the database.

#### Command:

```
decj opendcs.opentsdb.ListDataSources
```

# 5.7 The Generic "DbUtil" Utility

A generic utility to perform various operations on the database has existed for some time. It works with CWMS, HDB, or OpenTSDB.

#### Command:

```
bin/decj decodes.tsdb.DbUtil
```

Type the 'help' command to get a list of available commands. New commands are added from time to time:

```
cmd: help
Valid commands are:
list-site [startsWith] List sites, optionally starting with a specified
string, sorted name.
delete-site [default-site-name] - delete site by its default site name
delete-platform [id|site] [platformId or SiteName] - delete platform by ID
list-ts [contains] List Time Series, optionally with id containing
specified string, sorted name.
loc-aliases List all location aliases
ts-aliases List all time-series aliases
delete-ts [contains] List Time Series, optionally with id containing
specified string, sorted name.
list-dev List Device Statuses
update-dev [devname] [procname] [mediumId] [status] List Device Statuses
events-containing [string] List events containing a specified string
event [priority (I,W,F)] [subsystem] [event text...]
sched-event [priority (I,W,F)] schedStatusId platformId(or -1) subsystem
[event text...]
version -- show DECODES and tsdb database versions
bparam -- show CWMS Base Param - Unit Associations
select -- An arbitrary database SELECT statement.
alter -- An arbitrary database ALTER statement.
update -- An arbitrary database UPDATE statement.
hdbRating -- Install a test rating in HDB.
tsdbSpecs - Display statistics on OpenTSDB Storage Tables.
quit - Quit the program
help - Print this message
```

The "list-ts" command will print a list of time series IDs along with the storage units, storage table number, and description.

The "tsdbSpecs" command will print statistics on the time series specifiers including number of tables, number of values in each table, etc.

Some commands are specific to a database type (CWMS, HDB or OPENTSDB) and will give an error message if executed on the wrong type of database.

Care should be taken when executing update or alter commands.

# 6 HydroJSON Server

The HydroJSON Server is a web app that runs under Apache Tomcat. It handles the basic functions of HydroJSON defined on Gunnar's github page.

# 6.1 Deploying the HydroJSON Server

The server is distributed as a ".war" (Web Archive) file suitable for deploying under the Tomcat Application server.

Before deploying you need to fix the "context.xml" file contained in the WAR so that the application can connect to your database. Here are the instructions to do this:

1. Create a temporary directory and unpack the war file there:

Now copy the distro file HydroJSON.war into the parent of this directory (i.e. \$HOME) and ...

```
jar xvf ../HydroJSON.war
```

Now the tmpwar directory contains the image that was in the war file.

2. Modify the META-INF/context.xml file with your favorite text editor. It looks like this:

```
<Context>
  <Resource name="jdbc/opentsdb"
    auth="Container"
    type="javax.sql.DataSource"
    maxActive="100"
    maxIdle="30"
    maxWait="10000"
    username="tsdbadmin"
    password="tsdbadmin"
    driverClassName="org.postgresql.Driver"
    url="jdbc:postgresql://localhost/open_tsdb"/>
</Context>
```

Modify the url to point to your actual database. This is the same URL in the editDatabaseLocation in your decodes.properties file.

Modify the username and password to an account for the Web app to connect.

3. Rebuild the war file:

```
jar cvf ../HydroJSON.war *
```

4. Deploy the modified war file by copying it into Tomcat's webapps directory.

### **6.2 Server Request Details**

### **6.2.1** Retrieve Catalog of Sites

```
/getjson?catalog=[]
```

Returns a list of all site/locations defined in the database.

# **6.2.2** Retrieve Catalog of Time Series IDs

```
getjson?tscatalog=[search terms]
```

search\_terms= a string containing spec-delimited words. Only TSIDs
containing these words will be returned. The check is non-case-sensitive.

### 6.2.3 Retrieve Data by TSIDs

```
\label{lem:constraint} $$ / getjson?timeseries = $TsidSpecs\&backward = Duration\&time_format = PythonTimeSpec@tz = TimeZoneID $$
```

```
TsidSpecs= [["tsid1", "units1"], ["tsid2", "units2"], ...]

Duration= Duration as defined in ISO-8601, but without the leading 'P'.

PythonTimeSpec= As defined for Python's strftime function.

TimeZoneID= a standard time zone identifier.
```

#### Where

- tsidN is a fully-qualified 6-part TSID
- unitsN is optional. If not supplied the TS will be in its database storage units.
- Duration is optional. If not supplied, only the most recent value for each time series will be returned.
- PythonTimeSpec is optional. If not supplied it is %Y-%m-%dT%H:%M:%S in UTC.
- The tz argument is optional. If not supplied, UTC will be used.