


Microcontroller (ESP32 module)



Reset and boot buttons







Mounting holes



PWM servo driver and servo pins headers



USB TO UART



external 3.3V

