

Chart Channel Definitions

Chart 탭에서 사용되는 채널 번호(Channel ID) 정의표.

- **기본 자료형:** float
- **1-bit 자료형:** 채널 번호 **100 ~ 195** 범위 (디지털 입출력 / ControlWord / StatusWord)

Float 채널 (C0 ~ C55)

채널 번호	상수명	Hex	설명	단위
C0	C0_VELOCITY_FEEDBACK	0x00	Velocity Feedback	rpm, mm/s
C1	C1_VELOCITY_COMMAND	0x01	Velocity Command	rpm, mm/s
C2	C2_VELOCITY_ERROR	0x02	Velocity Error	rpm, mm/s
C3	C3_TORQUE_FEEDBACK	0x03	Torque Feedback	%
C4	C4_TORQUE_COMMAND	0x04	Torque Command	%
C5	C5_FOLLOWING_ERROR	0x05	Following Error	pulse
C6	C6_ACCUMULATED_OPERATION_OVERLOAD	0x06	Accumulated Operation Overload	%
C7	C7_DC_LINK_VOLTAGE	0x07	DC Link Voltage	V

채널 번호	상수명	Hex	설명	단위
C8	C8_ACCUMULATED_REGENERATIVE_OVERLOAD	0x08	Accumulated Regenerative Overload	%
C9	C9_ENCODER_SINGLETURN	0x09	Encoder SingleTurn Data	Pulse
C10	C10_INERTIA_RATIO	0x0A	Inertia Ratio	%
C11	C11_FOLLOWING_ERROR_ACTUAL_VALUE	0x0B	Following Error Actual Value	UU
C12	C12_DRIVE_TEMPERATURE1	0x0C	Drive Temperature 1	°C
C13	C13_DRIVE_TEMPERATURE2	0x0D	Drive Temperature 2	°C
C14	C14_ENCODER_TEMPERATURE	0x0E	Encoder Temperature	°C
C15	C15_HALL_SIGNAL_VALUE	0x0F	Hall Signal Value	—
C16	C16_U_PHASE_CURRENT	0x10	U Phase Current	A
C17	C17_V_PHASE_CURRENT	0x11	V Phase Current	A
C18	C18_W_PHASE_CURRENT	0x12	W Phase Current	A
C19	C19_POSITION_ACTUAL	0x13	Position Actual Value	UU
C20	C20_POSITION_DEMAND	0x14	Position Demand Value	UU

채널 번호	상수명	Hex	설명	단위
C21	C21_POSITION_COMMAND_VELOCITY	0x15	Position Command Velocity	rpm, mm/s
C22	C22_HALL_U	0x16	Hall U Value	—
C23	C23_HALL_V	0x17	Hall V Value	—
C24	C24_HALL_W	0x18	Hall W Value	—
C25	C25_COMMANDED_MOTOR_PHASE_ANGLE	0x19	Commanded Motor Phase Angle	—
C26	C26_HALL_PHASE_ANGLE	0x1A	Hall Phase Angle	—
C27	C27_ELECTRIC_ANGLE	0x1B	Electric Angle	—
C32	C32_LEFT_SENSOR_POSITION	0x20	Left Sensor Position	—
C33	C33_RIGHT_SENSOR_POSITION	0x21	Right Sensor Position	—
C34	C34_LR_POSITION_DIFFERENCE	0x22	L/R Position Difference	—
C35	C35_SENSOR_POSITION_INTERNAL_VALUE	0x23	Sensor Position Internal Value	—
C36	C36_LEFT_SENSOR_VALID	0x24	Left Sensor Valid	—
C37	C37_LEFT_SENSOR_VALID	0x25	Left Sensor Valid	—
C38	C38_LEFT_SENSOR_SINGLETURN_DATA	0x26	Left Sensor Singleturn Data	—

채널 번호	상수명	Hex	설명	단위
C39	C39_RIGHT_SENSOR_SINGLETURN_DATA	0x27	Right Sensor Singleturn Data	—
C40	C40_LMS_READY	0x28	LMS READY	—
C41	C41_RESERVED_1_LMS_STATEMACHINE	0x29	Reserved 1 (LMS StateMachine)	—
C42	C42_ROS	0x2A	ROS	—
C43	C43_RESERVED_3_LEFT_SENSOR_VALID_RAW	0x2B	Reserved 3 (Left Sensor Valid Raw)	—
C44	C44_RESERVED_4_RIGHT_SENSOR_VALID_RAW	0x2C	Reserved 4 (Right Sensor Valid Raw)	—
C54	C54_FFTINPUT	0x36	FFT Input	—
C55	C55_FFTOUTPUT	0x37	FFT Output	—

1-bit 채널 — 디지털 입력 (C100 ~ C131)

채널 번호 100 ~ 195 전체가 1-bit 자료형

채널 번호	상수명	Hex	신호명
C100	C100_POT	0x64	POT
C101	C101_NOT	0x65	NOT
C102	C102_HOME	0x66	HOME
C103	C103_STOP	0x67	STOP
C104	C104_PCON	0x68	PCON

채널 번호	상수명	Hex	신호명
C105	C105_GAIN	0x69	GAIN
C106	C106_P_CL	0x6A	P_CL
C107	C107_N_CL	0x6B	N_CL
C108	C108_PROBE1	0x6C	PROBE1
C109	C109_PROBE2	0x6D	PROBE2
C110	C110_EMG	0x6E	EMG
C111	C111_A_RST	0x6F	A_RST
C112	C112_SV_ON	0x70	SV_ON
C116	C116_START	0x74	START
C117	C117_PAUSE	0x75	PAUSE
C118	C118_REGT	0x76	REGT
C119	C119_HSTART	0x77	HSTART
C120	C120_ISEL0	0x78	ISEL0
C121	C121_ISEL1	0x79	ISEL1
C122	C122_ISEL2	0x7A	ISEL2
C123	C123_ISEL3	0x7B	ISEL3
C124	C124_ISEL4	0x7C	ISEL4
C125	C125_ISEL5	0x7D	ISEL5
C126	C126_ABS_RQ	0x7E	ABS_RQ
C127	C127_JSTART	0x7F	JSTART
C128	C128_JDIR	0x80	JDIR
C129	C129_PCLR	0x81	PCLR
C130	C130_AVOR	0x82	AVOR
C131	C131_INHIB	0x83	INHIB

1-bit 채널 — 디지털 출력 (C132 ~ C155)

채널 번호	상수명	Hex	신호명
C132	C132_BRAKE	0x84	BRAKE
C133	C133_ALARM	0x85	ALARM
C134	C134_READY	0x86	READY
C135	C135_ZSPD	0x87	ZSPD
C136	C136_INPOS1	0x88	INPOS1
C137	C137_TLMT	0x89	TLMT
C138	C138_VLMT	0x8A	VLMT
C139	C139_INSPD	0x8B	INSPD
C140	C140_WARN	0x8C	WARN
C141	C141_TGON	0x8D	TGON
C142	C142_INPOS2	0x8E	INPOS2
C148	C148_ORG	0x94	ORG
C149	C149_EOS	0x95	EOS
C150	C150_IOUT0	0x96	IOUT0
C151	C151_IOUT1	0x97	IOUT1
C152	C152_IOUT2	0x98	IOUT2
C153	C153_IOUT3	0x99	IOUT3
C154	C154_IOUT4	0x9A	IOUT4
C155	C155_IOUT5	0x9B	IOUT5

1-bit 채널 — ControlWord 비트 (C164 ~ C179)

채널 번호	상수명	Hex	비트
C164	C164_CONTROLWORD_0	0xA4	ControlWord.0
C165	C165_CONTROLWORD_1	0xA5	ControlWord.1
C166	C166_CONTROLWORD_2	0xA6	ControlWord.2
C167	C167_CONTROLWORD_3	0xA7	ControlWord.3
C168	C168_CONTROLWORD_4	0xA8	ControlWord.4
C169	C169_CONTROLWORD_5	0xA9	ControlWord.5
C170	C170_CONTROLWORD_6	0xAA	ControlWord.6
C171	C171_CONTROLWORD_7	0xAB	ControlWord.7
C172	C172_CONTROLWORD_8	0xAC	ControlWord.8
C173	C173_CONTROLWORD_9	0xAD	ControlWord.9
C174	C174_CONTROLWORD_10	0xAE	ControlWord.10
C175	C175_CONTROLWORD_11	0xAF	ControlWord.11
C176	C176_CONTROLWORD_12	0xB0	ControlWord.12
C177	C177_CONTROLWORD_13	0xB1	ControlWord.13
C178	C178_CONTROLWORD_14	0xB2	ControlWord.14
C179	C179_CONTROLWORD_15	0xB3	ControlWord.15

1-bit 채널 — StatusWord 비트 (C180 ~ C195)

채널 번호	상수명	Hex	비트
C180	C180_STATUSWORD_0	0xB4	StatusWord.0
C181	C181_STATUSWORD_1	0xB5	StatusWord.1
C182	C182_STATUSWORD_2	0xB6	StatusWord.2

채널 번호	상수명	Hex	비트
C183	C183_STATUSWORD_3	0xB7	StatusWord.3
C184	C184_STATUSWORD_4	0xB8	StatusWord.4
C185	C185_STATUSWORD_5	0xB9	StatusWord.5
C186	C186_STATUSWORD_6	0xBA	StatusWord.6
C187	C187_STATUSWORD_7	0xBB	StatusWord.7
C188	C188_STATUSWORD_8	0xBC	StatusWord.8
C189	C189_STATUSWORD_9	0xBD	StatusWord.9
C190	C190_STATUSWORD_10	0xBE	StatusWord.10
C191	C191_STATUSWORD_11	0xBF	StatusWord.11
C192	C192_STATUSWORD_12	0xC0	StatusWord.12
C193	C193_STATUSWORD_13	0xC1	StatusWord.13
C194	C194_STATUSWORD_14	0xC2	StatusWord.14
C195	C195_STATUSWORD_15	0xC3	StatusWord.15

Float 채널 — 기타 (C208, C250 ~ C253)

채널 번호	상수명	Hex	설명
C208	C208_INDEX_Z_PHASE	0xD0	INDEX (Z-PHASE)
C250	C250_OBJECT_MONITOR_1	0xFA	Object Monitor 1
C251	C251_OBJECT_MONITOR_2	0xFB	Object Monitor 2
C252	C252_OBJECT_MONITOR_3	0xFC	Object Monitor 3
C253	C253_OBJECT_MONITOR_4	0xFD	Object Monitor 4

자료형 요약

범위	채널 번호	자료형
아날로그 / 연산값	C0 ~ C55	float
디지털 입력 (DI)	C100 ~ C131	1-bit
디지털 출력 (DO)	C132 ~ C155	1-bit
ControlWord 비트	C164 ~ C179	1-bit
StatusWord 비트	C180 ~ C195	1-bit
기타 모니터	C208, C250~C253	float