

## Inclusion of IPP over USB

Rev.1.0 2015/Jan CS team

1

There are some limitations in the Windows environment by including a new function.

- A new model includes the function of IPP over USB to run AirPrint 1.4.
  - IPP over USB is a function to be used for running AirPrint on a USB printer.
    - For example, when connecting, by a USB cable, Mac OS X PC without a printer driver preinstalled and a printer with IPP over USB, the printer is added to Mac OS X as AirPrint.
    - Then, it can be printed on Mac OS X without a printer driver.



■However, since a problem has occurred by USB printing in the Mac environment, the measures were implemented on the device side.

## Operations in the Windows environment -1/2

Rev.1.0 2015/Jan CS team

- An unspecified icon or a [!] mark was displayed in a [device and printer] folder by connecting a new model with a USB cable.
  - Even though an unspecified icon is left, nothing will be happened but a [!] mark does not disappear.

The problem does not occur by printing in the Mac environment.
Device Manager
Device Manager




- Windows 8.1 **Device & Printer** ファイル(E) 操作(A) 表示(Y) ヘルプ(H) ←⇒ | □ | □ | □ □ | 型 □ | 型 □ □ □ | a 🚵 d446154 ⇒ 品 DVD/CD-ROM Fライブ ⇒ G IDE ATA/ATAPI コントローラー ⇒ 利 オーディオの入力および出力 ニ キーボード ■ コンピューター ・ ↑ 歳 ・ コントロール パネル ・ ハードウェアとサウンド ・ デバイスとブリンター ∨ 6 デバイスとプリンターの検索 ● システム デバイス □ ディスク ドライブ ■ ディスプレイ アタブター デバイスの追加 プリンターの追加 チバイス(6) ♀ットワーク アダプター ※ パッテリ 場とユーマン インターフェイス デバイス | 日かの子にイス | USB Device | | マンスとそのほかのパーンティング デバイス | モニター | ユニバーサル シリアル パス コントローラー オルター(3) 未指定(2) 7 11 個の項目 10
- With a need of a special driver for resolving [!] mark, USB IPP driver is provided.
  - ▶ The driver is only for an INF file.


#### Operations in the Windows environment -2/2

Rev.1.0 2015/Jan CS team

- Target device
  - B412, B432, B512, ES4132, ES5112

A [!] mark is not displayed by installing <u>USB IPP</u> driver.





- Name (Device Manager)
  - OKI USBIPP Device (~Win7)
  - USB Device (Win8~)



# **USB IPP Driver**

Rev.1.0 2015/Jan CS team


- How to get USB IPP driver
  - Case of using attached DVD or downloading from the website
    - Install USB IPP driver automatically through the setup.
    - After installing a printer driver and USB IPP driver, connect a PC and the device (model) by a USB cable.
  - Case of using Universal driver or Inbox driver
    - ▶ USB IPP driver is available on the website.
    - Install USB IPP driver by hand.



## Limitations


Rev.1.0 2015/Jan CS team

- If Windows PC and a new model are connected by a USB cable without a printer driver and USB IPP driver preinstalled, the Windows recognizes it as [Unspecified].
- Even if a printer driver and USB IPP driver are installed after the above, an [Unspecified] icon may not be disappeared as shown below.



See the next page for the flow of problem occurrence.

© Copyright 2015 Oki Data Corporation S ODC CONFIDENTIAL 5



© Copyright 2015 Oki Data Corporation S ODC CONFIDENTIAL