

July 2023

** Pulse rise time (defined as the time to attain 90% of maximum value) has a linear relationship with input capacitance. Value cited in the table assumes zero added input capacitance. To calculate pulse rise time for practical situations, use the equation: $t_r = 0.22 C_d + 3 \text{ ns}$, where t_r is the pulse rise time in ns, and C_d is the added capacitance (e.g. detector capacitance) in pF. Others factors within the detection system may further limit this value.