METHOD OF APPLICATION



Ensure a 24-hour time interval for grouting after tile fixing

The joints must be dry, clean, free of dust, debris, paints & adhesive





Take water into a clean mixing pail

Add JSW Tylfix Grout and mix thoroughly by hand or with a slow-speed mixer (50-100 RPM)





Ensure achieving a uniform color $\ensuremath{\mathtt{\&}}$ lump-free consistency

Allow the mix to stabilize for 2-5 minutes and then remix





Use the paste within 45-60 minutes from mixing

Ensure that the joint is filled completely, and the grout is not just sitting on top





After grouting, clean and polish tiles with a damp sponge or cloth

To remove hard stains, use Tylfix Cleaner



Disclaimer: ISW Construction Chemical Dry Mix products are guaranteed against material and manufacturing defects. The product is sold as per standard terms and conditions of sales, copies which may be obtained on request. ISWs endeavor is to ensure correct and accurate information on product performance and recommended specifications as mentioned in literature, and still may have to abstain from circumstantial deviations which are beyond control due to human intervention, atmospheric conditions or natural calamities which may not be in accordance with any advice, specification, recommendation or information given by it.



MARKETED BY: JSW Green Cement Pvt. Ltd.
Babukhan Millenium Centre, 6-3-1099/1100, No. 702, Block-A,
Somajiguda, Hyderabad, Telangana, India, Pincode - 500 082.

Email: info@jswcement.in | Website: www.jswcement.in Toll free - 18002662661



TYLFIX GROUT- Cementitious Shade Card

Substrate Preparation

- Ensure a 24-hour time interval for grouting after tile fixing
- · The joints must be dry, clean, and free of dust and adhesive
- Emptied at least 2/3 of the tile thickness depth
- Before grouting, ensure that the installation adhesive has set and released most of its moisture.
- The joints should not be wet during work
- Put masking tape beside the grouting space or use a sealer if necessary

Mixina

- Take water into a clean mixing pail
- Add JSW Tylfix grout and mix thoroughly by hand or with a slow-speed mixer (50-100 RPM)
- Avoid entraining air by mixing at a very high speed or by over-mixing
- Ensure that a uniform color and lumps-free consistency is achieved
- · Allow the mix to slake for 2-5 minutes and then remix
- Use the paste within 45-60 minutes from mixing

Application

- Using a hard rubber squeeze/grout float, press the grout firmly into the joints
- Hold the float at a 90° angle and pull it at a 45° angle diagonally across the joints and tile to avoid pulling out the material
- Work in small areas to have better control in removing excess grout from joints and the surface by moving the squeeze diagonally to the grout lines
- Ensure that the joint is filled completely, and the grout is not just sitting on top

PRODUCT DESCRIPTION

TYLFIX GROUT- Cementitious complies with the CG2W requirements as specified in "BS EN 13888:2009 - Requirements, evaluation of conformity, classification, and designation of grouts for tiles", as well as "ISO 13007- Part 3: Terms, definitions, and specifications for grouts."

FEATURES & BENEFITS

- Easy to use & Clean: just mix with water, ready to use
- Polymer modified: crack-free, minimum shrinkage & water resistance
- Suitable for varied tile and stones: All ceramics, vitrified tiles, granites, etc.
- Low VOC: For healthy living.

PACK SIZE

1kg



SCAN HERE FOR TDS



COLOR SHADES

