

Id	Objective	Input	Steps	Expected	Actual	Verdict
1	Power On	Power button press (device plugged in, empty tank)	1. Place device on flat surface. 2. Plug power cord into 220V/50Hz outlet. 3. Press the Power button once.	Device powers on, fan starts at default (low) speed, display/indicator lights up.		Not Run
2	Power Off	Power button press (device running)	1. Power on the device (see TC-1). 2. Let the device run for 30 seconds. 3. Press the Power button once to turn off.	Device powers off completely, fan stops, all indicator lights turn off.		Not Run
3	Fan Speed - Low	Speed selector set to Low	1. Power on the device. 2. Press the Speed button until the Low speed indicator is lit. 3. Stand 1 metre in front of the outlet grille.	Fan runs at minimum speed; airflow is gentle and clearly weaker than Medium.		Not Run
4	Fan Speed - Medium	Speed selector set to Medium	1. Power on the device. 2. Press the Speed button until the Medium speed indicator is lit. 3. Stand 1 metre in front of the outlet grille.	Fan runs at medium speed; airflow is noticeably stronger than Low.		Not Run
5	Fan Speed - High	Speed selector set to High	1. Power on the device. 2. Press the Speed button until the High speed indicator is lit. 3. Stand 1 metre in front of the outlet grille.	Fan runs at maximum speed; airflow is strongest and clearly stronger than Medium.		Not Run
6	Water Tank Fill	40 L of water poured into tank	1. Power off the device. 2. Remove or open the water tank. 3. Pour water until the tank is full (up to the MAX fill line). 4. Reattach the tank securely.	Tank accepts water up to the MAX fill line (~40 L) without leaking. Tank sits securely on the unit.		Not Run
7	Cooling Mode Activation (Pump On)	Water tank filled to at least 50%; Cooling/Pump button press	1. Fill the water tank at least halfway. 2. Power on the device. 3. Press the Cooling/Pump button to activate evaporative cooling.	Water pump activates; the cooling pad becomes visibly wet within ~60 seconds; air coming out feels noticeably cooler and more humid than fan-only mode.		Not Run
8	Fan-Only Mode (Pump Off)	Cooling mode currently active; Pump button press	1. Activate Cooling mode (see TC-7). 2. Press the Cooling/Pump button again to deactivate the pump.	Water pump stops; the cooling pad gradually dries; airflow continues but without added humidity.		Not Run
9	Oscillation (Swing) On/Off	Oscillation/Swing button press	1. Power on the device. 2. Press the Swing/Oscillation button to enable swing. 3. Observe for 15 seconds. 4. Press the Swing/Oscillation button again to stop.	Step 3: Louvers swing left and right automatically. Step 4: Louvers stop and remain in the last position.		Not Run
10	Timer Set and Auto-Shutdown	Timer set to 1 hour (shortest available setting)	1. Power on the device. 2. Press the Timer button and select the 1-hour (or minimum) timer setting. 3. Confirm the timer indicator is active. 4. Let the timer count down and expire.	Timer indicator is shown on display. When the timer expires, the device automatically powers off.		Not Run
11	Low Water Warning	Water tank empty or below minimum level; Cooling mode active	1. Run the device in Cooling mode until the tank is empty (or start with empty tank and activate Cooling mode). 2. Observe device behavior.	Device emits a warning indicator (audible beep and/or warning light) when the water level is critically low.		Not Run

12	Water Drain / Empty Tank	Full water tank; drain plug or drain hole	1. Fill the water tank. 2. Power off the device. 3. Locate the drain plug/hole at the bottom of the tank. 4. Open/remove the drain plug.	Water drains out completely through the drain hole without leaking from unintended areas. Tank can be reseated after draining.		Not Run
----	--------------------------	---	--	--	--	---------