


Tracker mount for standard Voron printers - installation guide (AirTag mount G4, Galaxy SmartTag2 mount G2)

Perquisites - the unit needs to be attached to a 60mm fan mount that has 3mm of thickness in-between the shroud and the fan (or the unit and the mount).



Skirt


4* M3*5*4 heat set
inserts



Tracker mount back
tracker-mount-airtag-back-g4.stl
(AirTag)
tracker-mount-smarttag-back-g2.stl
(Galaxy SmartTag2)

60mm fan mount

4* M3*6 BHCS



Tracker mount back

The mounting bracket needs to be attached to one of the fan mounts prior installation of the tracker.


Check the arrow, it should point to top after installation, or the screws mounting to the frame.

The back of the unit should face to the internals.

Tracker attaching

AirTag-specific


Tracker mounting
bracket
tracker-mount-airtag-
bracket.stl



Turn the bracket clockwise to secure the AirTag.


Galaxy SmartTag2-specific

Tracker mounting nut
tracker-mount-smarttag-
nut.stl




Turn the nut clockwise to secure SmartTag2.


Item tracker
AirTag / Galaxy SmartTag2



Main unit
tracket-mount-airtag-main-g4.stl
(AirTag)
tracker-mount-smarttag-main-g2.stl
(Galaxy SmartTag2)



Unit mounting



You will hear double-clicking when the unit is being secured.


Instructional stickers

You can use the instructional stickers [provided here](#), you should choose according to your item tracker. This version is prepared for paper cutting machines.

PDF version is also available, inside the STL model folder. PDF file is intended for hand-based cutting, and you may need to manually set specific page when doing that.

Removal guide

Turn the unit counter-clockwise to remove it. You will hear clicks during removal.



For AirTag version, unless if the part is imperfect, you can remove the battery of the tracker without the unit disassembled.

You can turn the bracket or the nut counter-clockwise to allow removal of the tracker.

For other questions or problems, please visit oitswilliam.com/support.
To flag issues on this manual, you can report them on [GitHub.com/Bunny350/OitswilliamV2/issues](https://github.com/Bunny350/OitswilliamV2/issues).