

How GearUp infers the EHAM departure runway

UNOFFICIAL LVNL picks a **combination**, not a landing runway and a departure runway independently. GearUp only shows this when the DEPT tab is displaying an arrival ATIS because there is no recent departure copy.

1 START HERE

DEPT tab · EHAM · arrival ATIS is filling the window.

If a real departure ATIS is shown, skip all of this.

2 READ THE LANDING RUNWAY(S)

Parse the arrival copy: **06, 18R, 36R, 18C, 27...**

One landing runway, or two in an inbound peak.

3 IS IT NIGHT?

Winter **2130–0530 UTC**

DST **2030–0430 UTC**

Yes → one primary pair only.

06 → **36L** · **18R** → **24** · **36C** → **36L**

No → continue. 09 / 18L / 36C are not night takeoffs.

THEN →

4 WHICH FAMILY? (FROM THE LANDING SET)

Walk this list. First match wins.

27 in the mix → west / pref 4

06 + easterly wind → east / pref 3

06 or **06+36R** or **36R** → north / pref 1

18R or **18R+18C** → south / pref 2

09 in the mix → east

Easterly = ATIS wind at least 20° closer to 090° than to 360°.

5 HOW MANY DEPARTURE RUNWAYS?

Off-peak or inbound peak: 1 departure

Outbound peak: add the extra (Dep 2)

Two landings on the ATIS counts as inbound, unless the clock is also outbound → overlap, 2+2

THEN →

6 WRITE THE LINE

One: **Inferred Departure Runway 36L**

Two: **Inferred Departure Runways, 36L and/or 36C**

Dep 1 first, then the peak extra. Unofficial estimate.

WIND STRIP UNDERNEATH

Use those takeoff ids as **DEPARTURE** winds.

Do not highlight inferred runways in the ATIS body — that copy is still arrivals.

THE TWO WORKHORSES

North: land **06** (+**36R**) · dep **36L** (+**36C**)

South: land **18R** (+**18C**) · dep **24** (+**18L**)

Look-up: land this, then what departs?

CHEAT SHEET Peak extras are in brackets. Night always drops the extra.

IF THE ARRIVAL ATIS SHOWS	FAMILY	OFF-PEAK / INBOUND	OUTBOUND PEAK / OVERLAP	NIGHT
06 alone	North (pref 1)	36L	36L and/or 36C	36L
06 + 36R	North inbound	36L	36L and/or 36C if peaks overlap	36L
06 + easterly wind	East (pref 3)	09	09 and/or 36L	36L
18R alone	South (pref 2)	24	24 and/or 18L	24
18R + 18C	South inbound	24	24 and/or 18L	24
36R + 36C	Parallels (pref 5a)	36L	36L and/or 36C	36L
27 (or 27+18R)	West (pref 4)	24	24 and/or 18L	24
09 in the mix	East	09	09 and/or 36L	36L

WORKED EXAMPLES

- Land **06 + 36R** at 10:50 local → inbound → **36L**
- Same pair at 09:30 local (outbound) → overlap → **36L** and/or **36C**
- Land **18R** off-peak → **24**
- Land **06**, wind 080° → **09**
- Land **06** at 22:00Z winter → night → **36L**

HARD LIMITS (WHY THE PAIRS LOOK ODD)

- 18R / 36R** never for takeoff
- 36L / 18L** never for landing (except emergency)
- So "land 06 + 36R, depart 36L" is normal. "Land 36L" is not.
- Safety and wind always beat the noise table. This is a guess, not ATC.

OUTBOUND PEAKS (AMSTERDAM LOCAL)

07:00–07:20 · 09:20–10:40 · 11:40–12:40
14:00–15:00 · 16:20–18:00 · 20:00–21:40

INBOUND PEAKS (AMSTERDAM LOCAL)

08:00–09:20 · 11:00–11:40 · 13:00–14:00
15:20–16:20 · 18:20–20:00

HOW MANY RUNWAYS AT ONCE

Off-peak / night: 1 land + 1 dep
Inbound: 2 land + 1 dep · Outbound: 1 land + 2 dep · Overlap: 2+2