

if something gets hot. The module should be loud at 25% volume

Then: Resolder all yr joints. Check If: You hear (almost) nothing

wrong way around.

You probably installed the IC the

If: Magic blue smoke appears Then: TURN IT OFFIIII

It'S STRNORRD PROCEDURE

Before you plug it in.

This part is kinda

*IROUBLESHOOTING* 

Front: soldering the resistors Start with placing and

Before you begin...



- Have a little bit of SOLDERING 

- Get all the NEEDER PARTY

- Open the BILL OF MATERIALS

(Though this build should be suitable for beginners)

This zine printed and folded ofc.

- Download & print the PANEL

Snip the legs off on the back

(Don't make the wires too short)





