

"БАБАЙ"
NANO v.1.1

ESP SWITCH

Reset

Rx:

Tx:

BUZZER1

BLUETOOTH

Arduino Nano

ESP-CAM



LM358AP

0V/CC

GND

3.3V

DRV6833



ESP_RESET

ESP_BOOT



12+

LM358AP

0V/CC

GND

5V

DC-DC 5v

IN5822

F1

SW

PWR

