

"БАБАЙ"
NANO v.1.1

ESP JAMPERS

Nano_RST
ESP_RST
ESP_TX

DRV8833

sleep	IB2
0A1	IB1
0A2	GND
0B1	VCC
0B2	A2
FU	IA1

DRV8833

Arduino Nano

ESP_RESET ESP_BOOT

MH-MINI-360

PWR

