

Community Water Quality Monitoring Procedure

Bilingual review copy: English and Sesotho. Human language approval required.

English	Sesotho
Community Water Quality Monitoring Procedure	Mokhoa oa ho Lekola Boleng ba Metsi a Sechaba
Purpose: This procedure explains how field teams collect and record drinking water samples so that results are reliable and traceable to the correct site.	Morero: Mokhoa ona o hlalosa hore na lihlopha tsa masimong li bokella le ho ngola mehlala ea metsi a nooang joang e le hore liphetho li tšepahale le ho lateloa ho ea sebakeng se nepahetseng.
Scope: It applies to routine samples collected from reservoirs, treatment outlets, and public taps. The procedure does not cover emergency chemical spills or laboratory instrument calibration.	Sebaka sa tšebeliso: Se sebetsa ho mehlala e tloaelehileng e bokelloang matamong, libakeng tsa phekolo ea metsi, le lipompong tsa sechaba. Mokhoa ona ha o akaretse ho qhalana ha lik'hemik'hale tsa tšohanyetso kapa ho lekanya lisebelisoa tsa laboratori.
Responsibilities: The team leader checks that each technician has PBT, clean sample bottles, and a calibrated meter. Technicians are responsible for completing the Chain of Custody Form QMS-07 and reporting unsafe conditions.	Boikarabelo: Moetapele oa sehlopha o hlahloba hore setekheniki se seng le se seng se na le PBT, libotlolo tse hloekileng tsa mehlala, le metha e lekantsoeng. Lithekheniki li ikarabella ho tlatsa Foromo ea Chain of Custody QMS-07 le ho tlaleha maemo a sa bolokehang.
Procedure: Before collecting a sample, allow the tap to run for 2 minutes. Rinse the probe with clean water, but do not rinse a sterile microbiological bottle. Record pH and turbidity in NTU at the site. Samples must be placed in a cooler between 2 and 8 degrees Celsius.	Mokhoa: Pele o bokella sampole, lumella pompo hore e phalle metsi ka metsotso e 2. Hlatsoa probe ka metsi a hloekileng, empa u se ke ua hlatsoa botlolo e sa tšoaetsoang ea likokoana-hloko. Ngola pH le turbidity ka NTU sebakeng seo. Mehlala e tlameha ho behoa ka har'a sehatsetsi pakeng tsa 2 le 8 degrees Celsius.
Data recording: Write the site code, date, time, and sampler initials on both the bottle and QMS-07. Corrections must be made with a single line through the error; correction fluid is not allowed. The reason for any missing reading must be stated.	Ho ngola data: Ngola khoutu ea sebaka, letsatsi, nako, le litlhaku tsa motho ea nkang sampole botlolong le ho QMS-07. Litokiso li tlameha ho etsoa ka mola o le mong ho tšela phoso; ha ho lumelloe ho sebelisa mokelikeli oa ho lokisa. Lebaka la ho se baloe ho itseng le tlameha ho boleloa.
Escalation: If pH is below 6.5 or above 9.5, or turbidity is higher than 1 NTU, phone the team leader immediately. Do not tell the community that the water is safe or unsafe until the	Ho nyolla taba: Haeba pH e ka tlase ho 6.5 kapa e kaholimo ho 9.5, kapa turbidity e phahame ho feta 1 NTU, letsetsa moetapele oa sehlopha hang-hang. U se ke ua bolella sechaba hore

authorised official has reviewed the result.

metsi a bolokehile kapa ha a bolokeha ho fihlela
ofisiri e lumelletsoeng e hlalobile sephetho.