DUCKY CLONE – SCRIPTING COMMANDS

COMMAND	EXAMPLE
STRING	Types out the text after 'STRING' Example: **STRING netstat -a**
DELAY	Causes the ducky to wait for X millisecs Example: **DELAY 1000**
ENTER	Presses the 'Enter' or 'Return' key
MENU	Presses the Windows Menu key
REM	Designates a remark to the script and is not typed out. Example: **REM Waits here from command prompt to open**
GUI	Presses the LEFT Windows Key
COMD	Types out the text after the 'COMD' and then presses Enter at the end of the line Example: **COMD cmd.exe**
KEY	Allows the ducky to simulate Windows ALT keys. Example: **KEY 0124** (ie. The pipe character)
ESC	The Escape key
TAB	normal
ALT	LEFT ALT key
SHIFT	LEFT SHIFT key
UP DWN LFT RHT	Cursor Keys

BACKSPACE	BackSpace key
DEL	Delete Key
CTRL	LEFT Control Key
GUI_R	RIGHT Windows key
INS	Insert key
HOME	Home button
ALTGR	RIGHT ALT key
CTRLR	RIGHT Control key
SHIFTR	RIGHT Shift key
F1 - F12	Function kets
CAPS_LOCK	Capital Lock
PAGE_UP PAGE_DOWN	Paging keys
MAP	Maps characters for a locale (eg, US, UK etc) Example: **MAP UK** Sets the keyboard to United Kingdom mode. Default is US. You must set the correct locale at the start of your script.
WAITKEY	Alters the default wait time between key presses on the ducky. (5 – 200msec – default is 20) Example: **WAITKEY 50**

Note: Command keys can be used together such as:

'ALT + F3'
'CTRL + ALT + DEL'
'SHIFT + \'