Total solder points: 274

Difficulty level:

beginner 1 □ 2 □ 3 □ 4 □ 5 ☑ advanced



### Touch screen keyboard

K8046

#### Features:

- ☑ LED status indication for each key/output
- ☑ Each key can be defined as toggle or momentary
- ☑ Soft touch, see-through touch panel with 8 keys
- ☑ Backlight with dim function
- ☑ Unique key-click feedback
- ☑ Optional infrared receiver module: IR38DM
- ☑ Optional BLUE BACKLIGHT: L-934MBC (8pcs required)
- ☑ 4 different functions (jumper selectable):
  - Eight independent keys (toggle or momentary selectable)
  - Eight radio (rotary simulation) buttons
  - Four radio buttons and 4 independent keys
  - One key serves as a memory for 7 other keys or "clear all" key

#### **Specifications:**

- 8 open collector switches: max 50 Volt / 50mA (all outputs)
- Board to wire connectors: 20cm wire.
- Dimensions (including frame): 165x90x35 (depth)
- Usable temperature range: -5°C to +40°C
- Keyboard operating force: 40g. (with R0.8mm test point)
- Keyboard lifetime: 1.000.000 operations with R3mm rubber
- Power supply: 2 x 9VAC or 12VDC / 250mA max.





#### **CAUTION:**

This kit is supplied with a GLASS type keyboard.

BE VERY GENTLE WITH THIS TYPE OF
KEYBOARD, THE SLIGHTEST BENDING WILL BREAK THE
GLASS AND COULD CAUSE
INJURY.

A BROKEN KEYBOARD IS NOT COVERED BY THE WARRANTY, A NEW KEYBOARD CAN BE ORDERED AT YOUR DEALER.
ORDER CODE: KB020501

IMPORTANT: Since this is a complex assembly with a lot of possibilities, it is advisable to read through the complete instructions BEFORE starting the actual assembly.

BE WARNED!

VELLEMAN KIT NV
Legen Heirweg 33
9890 Gavere
Belgium
www.velleman.be
www.velleman-kit.com




#### 1. Assembly (Skipping this can lead to troubles!)

Ok, so we have your attention. These hints will help you to make this project successful. Read them carefully.

#### 1.1 Make sure you have the right tools:

 A good quality soldering iron (25-40W) with a small tip.



Wipe it often on a wet sponge or cloth, to keep it clean; then apply solder to
the tip, to give it a wet look. This is called 'thinning' and will protect
the tip, and enables you to make good connections. When solder
rolls off the tip, it needs cleaning.

• Thin raisin-core solder. Do not use any flux or grease.

 A diagonal cutter to trim excess wires. To avoid injury when cutting excess leads, hold the lead so they cannot fly towards the eyes.

Needle nose pliers, for bending leads, or to hold components in place.

Small blade and phillips screwdrivers. A basic range is fine.





For some projects, a basic multi-meter is required, or might be handy

#### 1.2 Assembly Hints:


- $\Rightarrow$  Make sure the skill level matches your experience, to avoid disappointments.
- ⇒ Follow the instructions carefully. Read and understand the entire step before you perform each operation.
- $\Rightarrow$  Perform the assembly in the correct order as stated in this manual
- ⇒ Position all parts on the PCB (Printed Circuit Board) as shown on the drawings.
- ⇒ Values on the circuit diagram are subject to changes.
- ⇒ Values in this assembly guide are correct\*




- ⇒ Use the check-boxes to mark your progress.
- ⇒ Please read the included information on safety and customer service
- \* Typographical inaccuracies excluded. Always look for possible last minute manual updates, indicated as 'NOTE' on a separate leaflet.

#### 1.3 Soldering Hints:


**1-** Mount the component against the PCB surface and carefully solder the leads



**2-** Make sure the solder joints are coneshaped and shiny



**3-** Trim excess leads as close as possible to the solder joint



# AXIAL COMPONENTS ARE TAPED IN THE CORRECT MOUNTING SEQUENCE!

REMOVE THEM FROM THE TAPE ONE AT A






#### **CONSTRUCTION**


The unit consist out of two PCB's, one is the main PCB, P8046B and the other is the backlight PCB P8046L.

₱ Tip: The pictures on the packaging can be used as a guideline. However due to possible changes it is not 100% reliable.

First we will assemble the P8046B.


#### 1. Resistors : 680E (6-8-1-B) □ R1 : 680E (6-8-1-B) □ R2 □ R3 : 680E (6-8-1-B) □ R4 : 680E (6-8-1-B) : 680E (6-8-1-B) □ R5 □ R6 : 680E (6-8-1-B) □ R7 : 680E (6-8-1-B) □ R8 : 680E (6-8-1-B) □ R9 : 10K (1-0-3-B) ☐ R10:10K (1-0-3-B)□ R11 : 10K (1-0-2-B) □ R12 : 1K5 (1-5-2-B) □ R13: 10K (1-0-3-B)□ R14: 1K5 (1-5-2-B) □ R15 : 100K (1-0-4-B) □ R16: 100K (1-0-4-B) □ R17: 100K (1-0-4-B) □ R18: 100K (1-0-4-B) □ R19: 120E (1-2-1-B) □ R20 : 1K5 (1-5-2-B)








#### 4. Ceramic Capacitors



- ☐ C1 : 22pF (22) ☐ C2 : 22pF (22)
- ☐ C3 : 100nF (104, u1) ☐ C4 : 100nF (104, u1)
- ☐ C5 : 100nF(104, u1)

# 5. IC sockets. Watch the position of the notch!




- ☐ IC1 : 28p ☐ IC2 : 18p
- 6. Push buttons



Type: KRS1273

# 7. Voltage regulator M2.5 6mm SPACER TRIAC M2.5 BOLT









☐ SK4:6p






□ T2:BC547





#### 11. LED. Watch the polarity!



Power indication, make your choice as you prefer:

□ LD17 : 3mm green clear **OR** 3mm red

#### 12. Quartz crystal

□ X1 : 4MHz




# 13. Electrolytic capacitors. Watch the polarity!

□ C6 : 10µF □ C7 : 100µF




# 14. Relays □ RY1: VR15M121C

# 15. IC's. Watch the position of the notch!



□ IC1: VK8046 Programmed PIC16C55A -04 or equivalent

#### 16. Header





#### 17. Keyboard set-up

Each key is function definable (moment or toggle) and backlit. It is even possible to simulate old fashioned "radio buttons" (only one output can be ON, just like a rotary switch).

One key can be defined as a pre-set memory or serve as "all clear".

The K8046 features 4 operating modes, selectable with shunt SK1 or SK2.

- 1. Eight independent keys (toggle or momentary selectable).
- 2. Eight radio (Rotary simulation) buttons.
- 3. Four radio buttons and 4 independent keys.
- 4. One key is reserved as memory or "clear all" function.

	SHUNT SELECTION	
MODE	SK1	SK2
1	OFF	OFF
2	OFF	ON
3	ON	OFF
4	ON	ON


**Momentary (push button-) function:** Hold the key to activate the output and release the key to deactivate it.

**Toggle function**: Operates according to the principle of a classic switch, i.e. you have to press the key once to switch and press again to deactivate it.

#### For each output:

If a **momentary** output is needed, DO **NOT** mount a diode for the corresponding output D1 to D8.

If a **toggle** output is needed, **MOUNT** a diode for the corresponding output D1 to D8.



Diode type: 1N4148 Check the polarity!




#### JUMPER SELECTION


Different possibilities in conjunction with diode setup:

1- *Eight indepent keys* (no jumper is mounted) toggle or momentary selectable see previous page.




**2-** *Eight radio ( Rotary simulation) buttons*, only one button (output) at a time can be ON. Again with possibility of momentary or toggle.





3- Four radio buttons and 4 independent keys.


This is a combination of above. The first row (1 to4). Are independent buttons, the second row (5 to 8) have a rotary simulation.



4- Key 8 is reserved as memory or 'Clear all' Function.

If D8 is mounted this key will switch between all clear and memory of the previous keyboard setting.

If D8 is NOT mounted, this key will serve as all clear.



**HINT**: the separate CLEAR button can also be used as keyboard clear function. This key will actually reset the processor.




#### 18. Optional IR detector

It is possible to use the keyboard together with a remote control (e.g. our K8049 & K8051). In this case an optional receiver module type **IR38DM** is available.

Position the module like in the drawing. Use some hot glue to hold the receiver in place on the relay (Fig 1.0)

#### Make the connections:

- Connect 1 with right side of R13
- Connect 2 with COM connection of the output connector
- Connect 3 with left connection of R20. See picture.






#### P8046L Backlight PCB assembly

#### 1. Resistors

- : 180E (1-8-1-B): 180E (1-8-1-B) : 180E (1-8-1-B) : 180E (1-8-1-B) : 180E (1-8-1-B)■ R26 : 180E (1-8-1-B) : 180E (1-8-1-B) □ R28 : 180E (1-8-1-B)
- R...

#### 2. Spacers for keyboard support

□ Mount six 8mm M2,5 spacers at the indicated positions using six 6mm M2,5 screws (Fig 3.0).









Fig 4.0



#### 4. LED's for backlight




#### **IMPORTANT**

Mount these LED's exactly like in the drawings.

First: Bend the leads exactly like the drawing (Fig 5.0).

**Next:** Solder **one** lead, and check the position, if necessary correct by heating the soldering (Fig 6.0).

Last: Solder the second connection.



□ LD9 : 3mm Green clear

□ LD10 : 3mm Green clear□ LD11 : 3mm Green clear

□ LD12 : 3mm Green clear

□ LD13 : 3mm Green clear □ LD14 : 3mm Green clear

□ LD15 : 3mm Green clear □ LD16 : 3mm Green clear

TIP


Blue backlight is possible using special LED's (8pcs required).

Ordernr.: L-934MBC

Fig 8.0





#### 5. Header for backlight PCB connection



**First** cut the header into two headers with each 10 contacts (Fig 7.0)

Then place one 10p at position SK9 (Fig 8.0).






Last solder the header (see fig 9.0)


☐ SK9 : Pin header



#### 6. Assembling (for testing)

☐ Mount the four 15mm spacers as shown in the drawing Using four 6mm bolts (Fig 10).








☐ Fit the touch screen pcb at the component side of the base PCB (Fig 11)


#### Do not fix yet!

Make sure that the connector is correctly inserted when you mount the backlight onto the spacers.





#### 7. Testing the circuit



#### Before making a final assembly we will test the circuit:

**S**upply the power to the circuit (use the supplied wired connector, brown (-) and red (+) wire).

Normally the relay should "click" and the backlight should lit. If not; try "reset" SW1.

#### Now test the keyboard input (keyboard connector SK4):

**U**sing a small piece of wire, make a shunt between point A and point 1, one of the output LED's should lit.

Now test the other points A+2, A+3 and A+4.

All the top row output LED's should have lit one by one.

Perform the same test using point B as common, all the bottom row output LED's should lit one by one.

The circuit is now ready for final assembly.

REMOVE THE BACKLIGHT PCB!




#### 8. Creating your printed keyboard

The big advantage of this kit is that it is possible to create your own keyboard lay-out using a computer and printer.

Use transparent foil suitable for your printer


As an example a few standard lay-outs are supplied, these can be used as a guide to create your own. Please cut-out the desired layout before use.

On our web site a template can be downloaded to start making you own design, your imagination is the limit, just keep in mind the position of the keys and position of the output indications LED's. (see drawing 12)



<sup>\*</sup> Measurements are in mm!







#### 10. Final assembly

#### **IMPORTANT:**

Remove all impurities (e.g. dust, solder) between the various elements prior to assembly (between window & on-screen keys, on-screen keys & touchscreen).

#### STEP1

Gently remove the protective foil form the glass keyboard & support







Fig 13


#### STEP2

Check the touch sensitive side of the keyboard. See the position of the connector.



#### STEP 3

Position the keyboard gently into the frame between the 4 edge positioners. Check the position of the connector and check that the touch sensitive side is downwards.






Position your lay-out onto the keyboard.

Make sure the lay-out is positioned in the centre and in the correct surface/position.

Fix the lay-out using two pcs of clear tape




#### STEP 5

Position the keyboard support like in the drawing, between the provided studs, there is only 1 way.

**HINT:** to make the backlight more even and to prevent seeing the backlight PCB, it is advisable to diffuse the support plastic using some fine "sanding paper"

Again fix the plastic support using two pcs of tape.





Connect the keyboard connector with the base PCB.



Take great care to not damage the printed cable. This cable is composed by a plastic base with silver ink and shielded by a protective coating





Fig 18




Mount the backlight PCB onto the base PCB, fix the PCB using four 2.5mm screws (Fig 19)






Now the complete unit can be mounted into the frame. Insert also the two push-button actuators at the correct place.



#### STEP 9

Fix the PCB using 4 self taping screws + four metal washers and four rubber washers.

## Be gentle tot to tighten too much, this can damage the glas touch screen!!





Make sure that the output LED's correspond to your keyboard lay-out. If not you will have to disassemble the unit and reposition the lay-out.




Fig 22

#### STEP 11

#### Demo mode

To test the keyboard functions automatically, a demo mode is integrated.

- 1. Press and hold the backlight swith
- 2. Press clear briefly
- 3. Release the backlight switch, now the keyboard will show a demo of outputs and backlight dim.


Note: Before starting the "demo", the output LED's will indicate the "toggle" keys, this can be convenient to check the keyboard set-up.


#### **CAUTION:**

During demo mode the "real" outputs are also activated.



#### 11. Mounting the keyboard





PREVENT THE ENCLOSURE FOR POSSIBLE TORSION, THIS CAN DESTROY / BREAK THE GLASS KEYBOARD.
PREVENT THE KEYBOARD TO DIRECT SUNLIGHT EXPOSION


The warranty does NOT cover a broken screen.

Protect the device against direct sunlight during assembly.



# **WALL MOUNTED** Fig 23 **FLUSH MOUNTED** 0 - Max. diameter 8mm 138mm x 85mm x min. 40mm / 5,4" x 3,3" x 1,6" Fig 24







#### 12. Use of the keyboard

Connect the open collector outputs of the keyboard with your application. An open collector output is similar to a switch contact but keep in mind that a polarity must be respected.

If all outputs are used the maximum current can not exceed 50mA with a maximum of 50Vdc

#### REMEMBER: There is NO voltage coming OUT of the outputs

See next pages for connection examples.

#### Keyboard operation:

Gently press the key on the glass keyboard, an output action should occur and the relay should give a keyboard click feeling.

If an output is set as a toggle, the corresponding output LED will be activated/ deactivated with each press.

If an output is set as momentary, the corresponding output LED will be activated only during the key-press.

#### **Backlight operation:**

Each press of the backlight button will toggle between dim and regular backlight.



### HINT: the dim backlight level can be decreased by increasing the resistor value of R19.

#### Remote control:

If a remote option is chosen, please set the remote K8049 & K8051 in mode 1 to make it compatible with the keyboard (see remote control manual)


The keys 1 to 8 on the remote will simulate the keyboard keys 1 to 4 (top row) and 5 to 8 (bottom row).

The clear function of the remote (Shift + key 16) will clear the outputs (same function as the "Clear" button).




#### 13. Power supply connection

#### 1. Hook-up when using a transformer:



#### 2. Hook-up when using an adapter or dc source :







#### 14. Example with K8006

The outputs can easily be connected to your own application or to several of our kits; our K8045 LCD message board, K6714 relay card, K8006 light system bus unit , K8000 computer interface, K2633 or K2634 power cards, K8023 two wire remote.


For further connections of the K8006 look at the illustrated part list of the K8006.

















# PCB & DIAGRAM


# 15. PCB layout. 00 OF 꿏 CO 5 open collector 52 PB016B'2 +8 Ed 000000000000000 (C) VELLEMAN INC 4-45 to \$ 4 0 219 to \$ 0 5 5 5 C BIG O BIB O ORIZ 5GZD 0000001 0 9020 C roz D







### 16. Schematic diagram.



VELLEMAN KIT NV
Legen Heirweg 33
9890 Gavere
Belgium Europe
Info ?: http://www.velleman.be
Questions ?: support@velleman.be

Modifications and typographical errors reserved © Velleman Kit nv H8046IP - 2003 - ED1