Board Construction



The board is quite easy to construct but it is advisable to read through these notes before starting. The USB chip and all other surface mount components have been premounted to make construction easier.

WARNING



Be aware that the USB chip is sensitive to static electricity discharge and could be damaged by mishandling of the PCB. Be careful with the board and avoid touching any of the tracks or pads while assembling it. Try to handle it only by the edges.

The other chip in this kit is also sensitive to static discharge. This is the PIC16F628. Do not touch the pins and only handle it by the ends. A socket is supplied to allow for upgrades and easy assembly.

Starting

The first thing to do is inspect the PCB for shorted or open tracks or other damage, especially to the premounted components. Be aware of the static warning when doing this check. When you are satisfied that all is well, then you can proceed.


ALL COMPONENTS EXCEPT FOR THE LED AND ZIF SOCKET MOUNT ON THE **BOTTOM** SIDE OF THE PCB.

Start by mounting the 6MHz crystal. Before soldering it, make sure there is a small gap (~ 1mm) between it and the PCB. This is to keep the metal can of the component from shorting its own mounting pads.


Next, mount the 18 pin IC socket for the PIC16F628 chip. The indented end faces towards the USB chip. When placing the socket, make sure the pins are flush with the top of the PCB surface and not protruding above it before soldering.

Before soldering the USB connector, trim the 4 connector pins and the two support pins so that these leads are flush with the PCB top surface when inserted into the PCB.

The pins for the above two components have to be made flush with the PCB top surface otherwise the extra pin lengths won't allow the ZIF socket to sit flat on the PCB surface.



Next, mount all the electrolytic capacitors. These are polarity sensitive components so make sure they are mounted properly. The positive lead is longer than the negative lead, and the negative lead is also marked on the side of the capacitor. On the PCB overlay, there are holes marked [+] as the positive lead for each of these components. There are 2 x 1uF and 1 x 10uF capacitors so please try not to get them mixed up. See the PCB overlay for the correct mounting positions.




There is one LED that can be mounted next. Make sure it are oriented correctly and is mounted from the TOP PCB side. The anode (A) is marked on the PCB and is the longer of the two leads on the component. The Cathode has a flat surface on the LED body and is also marked on the board as (K).

Very carefully check your work at this stage, as the next part to mount is the ZIF socket. After mounting, this component hides a lot of soldered connections and will make error corrections very difficult. Inspect the board for dry or unsoldered joints and check all components for correct orientation and placement.

Now insert the preprogrammed PIC16F628 into its socket. Pin 1 is towards the USB socket. The finished board should look like the images shown here.





This completes the construction phase.

USB Drivers

To enable USB capability for your PC and this project you will need to install a special driver. This is a piece of software that handles the communications between the PC and the special USB chip on the programmer PCB.

Create a USB driver sub directory into the directory where your programmer software was installed. C:\diyprog was the default. Therefore you would have a new directory called C:\diyprog\usb.

The drivers come in 2 flavours, plug and play support and no plug and play support. As this programmer does not have plug and play support, that narrows it down to 1 choice.

You will need to visit this web page and download this driver.

VCP drivers for Win 98/2000/ME/XP (without PNP support)

http://www.ftdichip.com/FTDriver.htm

Download and unzip the file into the newly created USB directory.

Now visit this other web page and download the PDF application note that describes how to install the driver for your particular system.

http://www.ftdichip.com/FTApp.htm

For example you would download...

AN232-03 for Win 98

AN232-05 for Win2000

Download the PDF file into the USB driver directory listed above.

Open and follow the simple directions given in the PDF file. This should only take a few minutes to do.

When the driver installation is completed, connect a USB cable from the PC to the programmer board. This will power the board.

At this stage you *may* get a message from Windows saying that it has found new hardware.

Also the LED should flash on and change colors briefly.

If not, monitor and check the PCB components and make sure nothing gets too hot. If the PIC gets too hot to touch, disconnect the USB cable immediately as the PIC is most likely inserted the wrong way around. If this is the case, then they are quite tough little chips and it may have survived. Insert it the correct way and re-connect the USB cable. If the LED flashed as described earlier then it should be ok.

Disconnect the cable and insert the PCB into the mounting box provided with the kit. The PCB will be a nice snug fit and no screws should be necessary to hold it in place.

Now run MicroPro.exe which is the Windows® driver interface supplied with the kit.

Click [File] -> Port or double click the COM \times label on screen to bring up the COM port window. Select the COM port that you selected for use for USB communications while installing the driver, then OK. If you don't know what port it is connected to, click on

```
START - > Settings -> Control Panel.
```

Then double click System.

Look for the Device Manager and go to Ports (COM & LPT).

You will see COM \times listed next to the USB label. \times will be the COM port number for you to select in the MicroPro program.

The PC may take a short while to establish communications with the USB port. When it has done so, the COM port number will appear on screen and the programmer is ready for use on the USB port.

From MicroPro, make sure that Kit 128 is selected by clicking on

```
FILE -> Programmer Style -> K128.
```

If all is well, as a simple system test, click on

```
OPTIONS -> Reset Programmer
```

You should see the LED change color, then stay red. You should also see Board Connected appear on the MicroPro message bar.

Now select 16F84 from the chip select menu and click on Read. You should see the LED change to green while the programmer reads from a non existant chip. The screen will most likely fill with 0000's or 3FFF's.

Your new programmer is now ready for use.

When using the USB interface, always connect the programmer to the PCB before starting MicroPro.exe, and close MicroPro before disconnecting the programmer.

Failure to use this power up - power down sequence may result in a stalled PC for a minute or so because of the non responding USB port.



PARTS LIST

Used	Part Type	Designators	Description
SEMICONDUCTORS			
1 1 3 1 1	FT232BM PIC16F628 1N4148 BC856B 6MHz LED	U2 U1 D1, D2, D3 TR1 X1 L1	USB Converter Preprogrammed Microcontroller Diode PNP Transistor Crystal Bi-Color
RESISTORS all 1206			
2 1 2 7 1 1 1	27R 470R 1K5 10K 22K 47K 56K 680K	R7, R8 R9 R3, R10 R4, R5, R6, R12, R14, R R13 R11 R2 R1	15, R16
CAPACITORS			
2 1 2 2 1	22p 33N 100N 1uF 10uF	C1, C2 C8 C6, C7 C3, C4 C5	1206 Ceramic 1206 Ceramic 1206 Ceramic 16V Electrolytic 50V Electrolytic
MISCELLANEOUS			
1 1 1 1	Presoldered PCB 40 pin ZIF socket 18pin IC SOCKET UT-5676 Plastic Box	PCB1 SKT1 CN2	USB Connector

