# CADViewer JS – Generating Automated Hotspots in drawings

2: Use layer tool to find Room Layer and Text Layer.

There are several ways to identify layers with CADViewer JS. It can be done using the interactive layer tool to click on text and room layer to turn them off and then swap on/off layers to turn them on, alternatively use layer list to find layers. Here the Room Layer and Text layers have been identified.

3: Use Space Object layer list command to specify the Room Layer and Text Layer name.