Computer Structure and Language

Hamid Sarbazi-Azad

Department of Computer Engineering Sharif University of Technology (SUT) Tehran, Iran



(c) Hamid Sarbazi-Azac

Computer Structure & Language -- Lecture #13: IBM360 Machine

Decimal Numbers Representation

Decimal numbers are processed in IBM360 in two formats: **Zoned Decimal** (or Unpacked Decimal) or **Packed Decimal**.

In Zoned Decimal representation each byte contains one digit of the decimal number. Each digit has a left-side nibble of F. For an n-digit number, we need n bytes. The last byte contains the least significant digit and a sign nibble D (Debit) for negative numbers and C (Credit) for positive numbers.

→ decimal number $a_{n-1}a_{n-2}...a_1a_0$ (or $+a_{n-1}a_{n-2}...a_1a_0$) is shown as $Fa_{n-1}Fa_{n-2}...Fa_1Ca_0$ and number $-a_{n-1}a_{n-2}...a_1a_0$ is shown as $Fa_{n-1}Fa_{n-2}...Fa_1Da_0$.

Example 1: Decimal number -37084 is shown in zoned-decimal representation as: F3F7F0F8D4 (5 bytes in memory).

Example 2: Decimal number 374 (or +374) is shown as: F3F7C4 (3 bytes in memory).




Decimal numbers are processed in IBM360 in two formats: **Zoned Decimal** (or Unpacked Decimal) or **Packed Decimal**.


In Packed Decimal representation each byte contains two digits of the decimal number. The last byte contains the least significant digit and the sign. For an n-digit number we need [(n+1)/2] bytes.


→decimal number $a_{n-1}a_{n-2}...a_1a_0$ (or $+a_{n-1}a_{n-2}...a_1a_0$) is shown as $a_{n-1}a_{n-2}...a_2a_1a_0$ C and number $-a_{n-1}a_{n-2}...a_1a_0$ is shown as $a_{n-1}a_{n-2}...a_2a_1a_0$ D.


Example 1: Decimal numbers -37084 is shown in packed decimal format as: 37084D (3 bytes).


Example 2: Decimal numbers 1374 (or +1374) is shown in packed decimal format as: 01374C (3 bytes).


























































































































(c) Hamid S	Sarbazi-Azad	Computer Structu	ıre & Language -	Lecture #	13: IBM360 Machine	47
string (nple : ended b RESULT	by null) LINE, add	mbly progr them toge DIGITL	ram to e ether, ar LR SR	extract numbers in a chaind store the result in cha	racter racter
Defining		T 0 ase register → (R12) =6. 2,LINE pointer 0(2),C' '	PAK	LA STC PACK MP AP	TEMP(4),SIGN(1) SUM(6),TEMP(4)	R4)-1
2001	BNE LA B	NUL1 2,1(2) LOOP	ENDP	B XR UNPK	LOOP 2,2 RESULT+1(11),SUM(6)	
NUL1	CLI BE ZAP CLI BNE	0(2),0 ENDP SIGN,=P'1' 0(2),C'-'	PLUS	CP BH MVI LA OI	SUM(6),=P'.1' PLUS RESULT,C'-' 2,1 RESULT+11,X'F0'	
	ZAP LA B	POS SIGN(1),=P'-1' 2,1(2) DIGIT1	LAST	LA CLI BNE MVC	2,RESULT(2) 0(2),X'F0' ==C'0' FINISH 0(12,2),1(2)	
POS	CLI BNE LA	0(2),C'+' DIGIT1 2,1(2)	FINISH	B CLI BNE	LÄST 0(2),0 FIN	
DIGIT1 MORE	LR CLI BE CLI BE LA B	3,2 0(2),C' ' DIGITL 0(2),0 DIGITL 2,1(2) MORE	FIN Returnir TEMP SUM LINE SIGN RESULT	MVI To to OS DS PL4 DC PL6 DC C'-1 DS C DS 12C	5'0' 123 22 +401 -11 220',X'0	,ı

