Keyboard PC (TV version)

The TV version of Keyboard PC includes TV-Out and CRT-Out functions as below. The part number for order is “**KPC-T**”.



[If your Keyboard PC can’t switch TV or CRT in the BIOS settings or Graphic utility of Windows XP, please make sure that you order part number is “KPC-T”, or contact your sales direct person. For “KPC-C” version, it supports CRT output only.]

1. Switch display to TV or CRT in the BIOS settings before installing Microsoft Windows XP.

(Please ignore and jump to instruction-2 if you just want to switch display in Microsoft Windows XP. This step is just for user choosing display output before installing Microsoft Windows XP.)

Users can choose either way to do it.

First way: Users can press key of keyboard to switch display after power on system directly.



Press “C” key: System will display and output to “**CRT**” (VGA).


Press “N” key: System will display and output to “**TV (NTSC)**”.

Press “P” key: System will display and output to “**TV (PAL)**”.

Second way: Users can go to BIOS settings as below.


(1) Power on and press “**Del**” key into the BIOS settings.


(2) Choose “**Boot**” and “**Boot Settings Configuration**” selections.



(3) Set “**TV**” or “**CRT**” upon “**Boot Display Device**” selection.

(Please do not choose “**VBIOS**” or “**Panel…**” functions.)





(4) Press “F10” to save the BIOS settings and exit.


2. Switch display to TV or CRT in Microsoft Windows XP.


(1) Download and install VGA driver by ftp://ftp.dmp.com.tw/Drivers/TV-Out/Windows_XP/D1010_R8.msi.

The login name is “**vxmx**” and password is “**gc301**”.

(2) After install the driver, please reboot the system.

(3) After system rebooting, you will watch an icon upon the bottom of desktop. Please just click that icon by a USB mouse.





(4) You can plug in a CRT (VGA) Monitor and choose “**CRT**” to display and choose “**Apply**” and “**OK**” to be CRT (VGA) Output. Certainly, you can switch back to “**TV**” for TV output.




3. Set TV resolution to 640x480 in Microsoft Windows XP.

For smaller TV monitor, we suggest user to adjust the resolution to **640x480** for bigger words in Windows XP. Please look at the steps to adjust it as below.


(1) In desktop of Windows XP, please click the right key of USB mouse and choose “**Properties**”.




(2) Go to “**Settings**” and choose “**Advanced**”.




(3) Choose “**Adapter**” and “**List All Modes…**”.



(4) Choose “**640 by 480, High Color (16 bit), 60 Hertz**” and “**OK**”.



(5) Choose “Apply” and “OK”.



(6) Choose “OK” and exit Display Properties.

(7) For Internet Explorer, you can download IE7.0 (or above version) by Microsoft Website and extend the webpage from 100% to 150% for getting bigger words.

