
CONNECTION TO CC2420 BOARD
GND
VREG_EN
RESETn
NC
NC
NC
NC
NC
GND
NC
NC
FIFO
FIFOP
CCA
SFD
CSn
SCK
MOSI
MISO
NC
NC
VREG
VREG
VREG
NC
NC
NC
NC
NC
GND
GND
GND
GND
GND
GND
GND
GND
GND
GND
ADC Ch0
ADC Ch1
ADC Ch2
ADC Ch3
DAC Ch1
DAC Ch0
33
CONNECTION TO MKII
MOSI
NC
RESET
SCK
MISO
PWR
GND
GND
GND
GND