https://github.com/am32-firmware/AM32/blob/main/Inc/targets.h
F051 Group B
TIE UNUSED NRESET HIGH
ESC x1 (NEED TO COPY X4)
Need temp sensor? or activate from imu?
Check if need more 47uF caps, compare to speedybee and other designs and ask why between BATT and GND – drawing uses 7 caps, speedybee uses 21
CAA572X7R1H476M670LJ
is this low ESR?
CL10A474KB8NNNC
The boot loader is located in System Memory. It is used to reprogram the Flash memory by using USART on pins PA14/PA15 or PA9/PA10
NRST and BOOT components – Label CLEARLY on SKILK SCREEN
LABEL PINS CLEARLY ON PCB
ESC MCU
STM32F051C8Tx
Programming Pins for the MCU????
ESC signal input → PA2 by default; PB4 is the other supported option (choose the matching bootloader)
Only solder 1 Ohm on the input circuit you want to try with DSHOT – Label CLEARLY on SKILK SCREEN
0 OHMS TO UNSOLDER 2 of 3 – BUT EACH HAVE THEIR OWN OUTPUT
FF – Full Filter
R – Resistor
NF – No components straight to pin
SG1 = Signal input 1
SG2 = Signal input 2
SG3 = Signal input 3
For signal in for dshot?
CURRENT BUS BAR
https://www.digikey.co.uk/en/products/detail/altech-corporation/3803231/8547418
https://www.digikey.co.uk/en/products/detail/weidm-ller/0348900000/496908
https://www.amazon.co.uk/BENECREAT-Copper-Braided-Grounding-Reducing/dp/B0BGWZ5DGV?source=ps-sl-shoppingads-lpcontext&smid=A874XMFQVNIRI&th=1
6S ESC / 60A – FETs + Gate Drivers?
PSMN1R4-40YLDX
Take care with pcb layout
BEMF_COMMON
Warning: Solder paste nwgative margin larger than pad no solder paste generated! Please make your own to make it work!
DRV8300DRGER
Kelvin connection
NC
PMEG4010CEJ,115
or swap C1206X105K1RACAUTO to 100nF
LABEL PASSIVE COMPONENTS
Current Measure
0.005Ohms, 2512, 5W, Current Sense
Must have kelving connection check datasheet etc.
INA240A1D
ADC_CURRENT
3V3_2A
VBAT_IN
5V3A
GND
Sheet: /
File: Part7.kicad_sch
Title:
Size: A0
Date:
Rev:
KiCad E.D.A. 8.0.6
Id: 1/1