IMU NEED OWN LDO
LEDs
BUZZER
TIE UNUSED NRESET HIGH
144 pins – most use 64.
FLASH
IMU
BARO
MAG
MUST BE FAAAR AWAY FROM EVERYTHING
USE 2.7k I2C PULLUPS IF USED – PICK ONE VALUE NOT ONE FOR EACH SENSOR
GET MISO MOSI CORRECT WAY AROUND, GET USB CORRECT WAY AROUND, GET UART CORRECT WAY AROUND
100nF 3v3 caps? x9
FC
FIND ALL SPI/I2C ADDR
GPS
MUST SEE THE SKY
SBUS RX
SBUS TX
3x UART from other modules + 1 Signal Wire
PLACE NEXT TO PINS
Decoupling
CHECK GYRO/FLASH/OSD
Check what does timepulse shared with safeboot mean
AT32F435 (recommended) or STM32F405
Microcontroller F4
NOT USED CHECK VTX
ANALOG OSD
LABEL CUT TRACK AS UNUSED
BLE
Logic Shift
CHECK TARGET JSON FOR CORRENT MCU PINOUT – NOT DONE YET
M3 (3.5mm hole) and 30x30cm aim.