CHONCHOW

G600

Wireless Gaming Keyboard Mouse Set User Manual

Sincerely thank you for your trust and support in CHONCHOW products, we will be happy to provide you with satisfactory service.

Sincerely thank you for your trust and support in our CHONCHOW brand products. We are committed to providing you with high-quality after-sales service and a perfect gaming experience. This manual will detail the functional operation, combination keys and product configuration of the G600 gaming keyboard and mouse set, please read it carefully for better use.

1. How to Use



① Take out the USB receiver fromthe back of the mouse;



②Plug it into the USB interface of the computer or the device you need to use;



③ Power switch of mouse: down is use turn on with light, up is turn off; press DPI button for 3 seconds can turn off/on the light.



④Tumn on the power switch of the keyboard, and then you can use it;



⑤When the keyboard power is low, the indicator will flash red light to remind you;



⑥Use the 5V 2A charger (not included) and the attached charging cable for charging;



⑦ The green light will be on when the keyboard is charged, and when the green light is off, it means the charging has been completed;



⑧The blue light will be on when the mouse is charging, and the blue light off means the charging has been completed.

2.RGB Lighting Function

① Keyboard

Backlight On/Off:	SUNKEY
RGB Lighting Modes (Constant and Flash):	FN + SUNKEY
Dim Backlihgt Brightness:	FN + "+"
Dim Backlihgt Brightness:	FN + "-"

② Mouse

Press and hold the DPI button to turn the mouse light on and off.

3.Combination Key Function



Key Combination	Function
F1	Media
F2	Volume-
F3	Volume+
F4	Mute
F5	Refresh
F6	Previous
F7	Play/Pause

	F8	Next
	F9	Mail
	F10	Web
	F11	Fn Lock
	F12	Calculator

4. Independent Function Buttons



Key	Core Function	Key Advantages
My Computer	One-click access to system file explorer/This PC	1-step shortcut replaces 3+ mouse clicks; eliminates folder path searching
Email	One-click launch of default mail client(Outlook/ Thunderbird/webmail)	Zero app hunting; direct access to inbox/compose without desktop search
Home	One-click return to device homepage/browser default page	1-click navigation replaces backtracking or minimizing windows
Calculator	One-click pop-up of system calculator	Instant math tool; no app search/ installation needed

5.19 Anti-ghosting Keys

The following 19 keys are anti-ghosting keys.



6.Battery Power Related

①Keyboard battery capacity: 2500 mAh
②Mouse battery capacity: 500 mAh
③Low battery reminder: Keyboard indicator flashing purple light
④Automatic sleep: 5 minutes without using the keyboard/mouse to enter sleep mode
⑤Charging time: About 3 hours (mouse)
About 10 hours (keyboard)
⑥Attention: Only use a 5V2A charger

7.What's in the Box （with size info）



1 * wired Keyboard
1 * wired Mouse
1 * User Manual



Satisfied?
We're just happy that you're very satisfied. If you don't know how to express your newfound joy. we've got a few suggestion…
Tell your friends and family
Share your comments or photos on Amazon



Not Satisfied?
Our friendly customer service team will work hard to put a smile back on your face .Here's how we can connect.
supportamz@chonchow.com
Guarantee of quality for 360 days,100% replace in 15 days and 12months of parts.

Attention

If the keyboard cannot be used, how can you fix it?
It shows frequently that the keyboard can't be charged (charged and later still can't work) /backlight is lighted-up for seconds and off later/don't response on pc.
Turn off the keyboard. Unplug the receiver(necessary) ,thenpress ESC+Q and hold for 3 seconds(The indicator lightsstart to show a flash light). Reinsert the receiver and waitfor 3 seconds, the indicator light goes off later. Now youcan click any key to awake it up(you can also turn thebacklight on to test it).

If the mouse cannot be used,how can you do?
(It shows frequently that the mouse don't response onpc /the backlight can't be light up / the keyboard can'tbe charged(charged and later still can't work).
Turn off the mouse. Unplug the receiver(necessary) ,press and hold the mouse scroll wheel+right +left button at once (3 buttons together), hold for 3 seconds. Reinsert the receiver and wait for 3 seconds, click any button or move the mouse, and the mouse will resume.