
Flight Loads: DroneVLA aircraft



Pierluigi Della Vecchia

Design of Aircraft and Flight Technologies, DAF 23-Nov-2021

Table of Contents

<u>Chapter 1. Introduction</u>	1
Chapter 2. References	2
Chapter 3. List of Abbreviations	3
Chapter 4. Aircraft data	4
<u>4.1. Geometry</u>	4
4.2. Aerodynamic	
Chapter 5. Design Airspeeds	7
5.1. Maximum speed in level flight VH	7
5.2. Stall speeds VS, VS0, VS1	7
5.3. Design manoeuvring speed VA	8
5.4. Flaps maximum operating speed VF	
5.5. Flaps maximum operating speed VFE	8
5.6. Design cruising speed VC	8
5.7. Design dive speed VD	8
5.8. Demonstrated dive speed VDF	8
5.9. Never exceed speed VNE	8
Chapter 6. Altitude	9
Chapter 7. Manoeuvring and Gust load factors n	10
Chapter 8. V-n Envelope	11
Chapter 9. Loads on the aeroplane	12
9.1. Reference axes and sign convention	12
<u>9.1.1. aaaaa</u>	12
9.2. Symmetrical flight conditions	12
9.3. Aerodynamic centre	12
9.4. Pitching moment of the wing	12
9.5. Loads on the Wing	12
9.6. Influence of the fuselage	12
9.7. Forces and moments acting on the wings	12
9.7.1. SpanWise Airloads Distribution	12
9.7.2. Normal and parallel component	12
9.7.3. Shear, Bending and Torsion	12
9.7.4. Critical load condition	12

List of Figures

Figure 4.1. Wing-Body reference Aerodynamics	6
Figure 7.1. Maneuver and Gust load factors and diagram	
Figure 8.1. Maneuver and Gust load factors and diagram	

List of Tables

Table 4.1. Wing Geometrical Parameters	4
Table 4.2. horizontal Geometrical Parameters	
Table 4.3. Vertical Geometrical Parameters	
Table 4.4. Fuselage Geometrical Parameters	

Chapter 1. Introduction

This document defines the SUBPART C - Structure - Flight Loads of the:DroneVLA.The boundaries of the flight envelope will be defined within this document. All speeds are calibrated airspeeds (CAS) (requirement 4.4 [1])and given in knots if not stated otherwise.All other units used are metric (SI units).The weights are given in mass units (kg) but the formulas require force units as input,therefore these are calculated in place wherever they are used.Note: The speeds defined within this document should be used for the placards,speed markings, aeroplane flight manual (limitations), load calculations and need to be verified by flight test.

Chapter 2. References

- 1. ASTM F2245-12d," ASTM."ASTM F2245-12d, ASTM.
- 2. ABCD-FL-57-00 Wing Load Calculation, EASA.
- 3. ISO 2533:1975, International Standardization Organization, 1975.
- 4. CS-LSA Certification Specifications and Acceptable Means of Compliance, Amnd.1 29.Jul.2013, EASA, 2013.
- 5. "ABCD-FTR-01-00 Flight Test Report," EASA.
- 6. L. Smith, "NACA technical note 1945, 'Aerodynamic characteristics of 15 NACA airfoil sections at seven Reynolds numbers from 0.7x10E6 to 9x10E6," 1949.
- 7. ABCD-WB-08-00 Weight and Balance Report, EASA.

HERE BELOW AN EXAMPLE OF REFERENCES TO BE EDITED

Chapter 3. List of Abbreviations ADD HERE list of abbreviations as a formatted tableto be created		

Chapter 4. Aircraft data

Add here all the aircraft geometrical, aero and inertial and masses data useful for following paragraph

4.1. Geometry

The aircraft reference geometry is summarized in table: Ref:wingRef:horiRef:vertRef:fus

Table 4.1. Wing Geometrical Parameters

Wing parameters	Value	Measure unit
b	5.2	meters
S	2.589	square meters
AR	10.446	-
taper	1	Non dimensional
sweep	0	degrees
sweep_location	0	percentage
secondary_sweep_location	0	percentage
croot	0.498	m
ctip	0.498	m
xle	1.638	meters
yle	0	meters
zle	0.165	meters
xtip_le	NaN	% fuselage length
dihedral	0	degrees
mac	0.498	m
xmac	NaN	% fuselage length
ymac	NaN	% semispan
ypos	NaN	% semispan
zpos	NaN	% fuselage diameter
camberloc	0.15	Percentage
thickchord	0.18	Percentage
twist_angle	3	degrees

The aircraft reference geometry is summarized in table: Ref:wingRef:horiRef:vertRef:fus

Table 4.2. horizontal Geometrical Parameters

horizontal parameters	Value	Measure unit
S	0.529	square meters

horizontal parameters	Value	Measure unit
Ī	1.492	meters
camber	0	percentage
camberloc	NaN	percentage
thickchord	0.12	percentage
twist	0	degrees
twistloc	0.25	percentage
xloc0	1.49	meters
xloc	3.128	meters
yloc	0	meters
zloc	0.15	meters
xrot	0	meters
yrot	0	meters
zrot	0	meters
b	1.496	meters
ctip	0.3136	meters
croot	0.3929	meters
sweep	15	degrees
sweeploc	0	percentage
secsweeploc	1	percentage
dihedral	0	degrees
location_of_camber	0.2	percentage
secondary_sweep_location	1	percentage

The aircraft reference geometry is summarized in table: Ref:wingRef:horiRef:vertRef:fus

Table 4.3. Vertical Geometrical Parameters

vertical parameters	Value	Measure unit
MAC	0.23354	m
I_vt	1.65	m

The aircraft reference geometry is summarized in table: Ref:wingRef:horiRef:vertRef:fus

Table 4.4. Fuselage Geometrical Parameters

Fuselage parameters	Value	Measure unit
length	3.64	meters
diameter	0.42	meters
Non_dim_radius_of_gyration	0.34	Non dimensional
Radius_of_gyration	NaN	meters

4.2. Aerodynamic




Figure 4.1. Wing-Body reference Aerodynamics

Chapter 5. Design Airspeeds

This chapter defines the operating and design airspeeds as required for certification REFFFF

5.1. Maximum speed in level flight VH

According to flight tests [5] at maximum weight and maximum continuouspower at sea level conditions, the maximum speed in level flight has been determined: V H=130\ kts

5.2. Stall speeds VS, VS0, VS1

These speeds will be verified by flight test according to requirement 4.4.1 [1]In order to calculate the stall speed, the maximum lift coefficient of the aeroplane as a whole is determined first. The maximum lift coefficient of the aeroplane has been calculated starting from the polar curve of the wing profile taken form ref. [6] (p. 236, Re=2.9E6 flaps retracted c_(L_profile_max)=1.35 and p.237, δ_f =40 deg for the flapsin landing configurationc_(L_profile_flapped_max)=2.15, and δ_f =10 deg in take-off configurationc_(L_profile_flapped_to)=1.70). Considering the horizontal tail balancing force and the lower total wing lift due to wing lift distribution, the total aeroplane lift coefficient has been lowered by 15% with respect to the one of the profile.

Flaps retracted(cleam configuration):

$$V_S = \sqrt{\frac{2 W_{MTOM}}{\rho_0 C_{L_{MAX_{Clean}}} S}} = \sqrt{\frac{2 * 981}{1.225 * 1.6137 * 2.589}} = 19.7891 m/s$$

Flaps extended(Landing configuration):

$$V_{S_0} \ = \ \sqrt{rac{2 \ W_{MTOM}}{
ho_0 C_{L_{MAX_{Landing}}} S}}$$

Flaps extended(Take-off configuration):

$$V_{S_1} \ = \ \sqrt{rac{2 \ W_{MTOM}}{
ho_0 C_{L_{MAX_{Take off}}} S}}$$

Therefore aeroplane lift coefficient is estimated toc_(L_clean_max)=0.85*1.35=1.15 and for the landing configuration (since the span extension of the flaps is half of the span of the wing):c_(L_flaps_max)=(c_(L_profile_flapped_max)+ c_(L_profile_max))/ 2*0.85=(2.15+1.35)/2*0.85=1.49

The stall speed in landing configuration (flaps fully extended toxxx degrees degrees)isXXX kts.Therefore it is In accordance with CS-LSA.5 [4].In Take-Off configuration (flaps extended to ,xxx degreesdegrees) the stall speed is ,xxxkts.

(Note: These speeds are estimates. The methods for the estimation can be various.It is important that these estimations are as precise as possible. Flight tests will be used to validatethe stall speeds. In case the flight tests show different values, this might have an impact on the speedsused for design and ultimately might impair the compliance to the CS-LSA.5.)

5.3. Design manoeuvring speed VA

ADD TEXTS:

5.4. Flaps maximum operating speed VF

ADD TEXTS:

5.5. Flaps maximum operating speed VFE

ADD TEXTS:

5.6. Design cruising speed VC

ADD TEXTS:

5.7. Design dive speed VD

ADD TEXTS:

5.8. Demonstrated dive speed VDF

ADD TEXTS:

5.9. Never exceed speed VNE

ADD TEXTS:

Chapter 6. Altitude

ADD HERE ALTITUDE DETAILS

Chapter 7. Manoeuvring and Gust load factors n

Gust envelope per




Figure 7.1. Maneuver and Gust load factors and diagram

ADD HERE Manoeuvring and Gust load factors n, figures, tables....ecc. ecc.

Chapter 8. V-n Envelope




Figure 8.1. Maneuver and Gust load factors and diagram

ADD HERE V-n Envelope

Chapter 9. Loads on the aeroplane

ADD HERE details for balancing Equation

ADD HERE details for balancing Equation

9.1. Reference axes and sign convention

9.1.1. aaaaa

ADD HERE details for balancing Equation

9.2. Symmetrical flight conditions

ADD HERE details for balancing Equation

9.3. Aerodynamic centre

ADD HERE details for balancing Equation

9.4. Pitching moment of the wing

ADD HERE details for balancing Equation

9.5. Loads on the Wing

ADD HERE details for balancing Equation

9.6. Influence of the fuselage

ADD HERE details for balancing Equation

9.7. Forces and moments acting on the wings

- 9.7.1. SpanWise Airloads Distribution
- 9.7.2. Normal and parallel component
- 9.7.3. Shear, Bending and Torsion
- 9.7.4. Critical load condition