
• The lab report questions and screen captures from the first filter design exercise (refer to Part 3).

I. What is the order of the filter you designed? What does this mean?

36, it means that in order to achieve the parameter we specified, at least 36 orders filter will be used for the filtering, the order number of 36 means there will be 36 coefficients in the formula, this also determines how much historical data will be used.

II. What are the effects of altering the passband and stopband attenuation?

	lower	higher
Apass	Passband will be more smooth, less ripple on the passband, order will be higher	Passband will be less smooth, more ripple on the passband, order will be lower
Astop	Stopband attenuation is less and slower, less ripple number, order will be lower	Stopband attenuation is less and slower, less ripple number, order will be higher



- Details of your decision process to design the noise-removing FIR filter.
- 1. Observe the original audio spectrum and look for the noise location

Figure 1 Original Signal Original x(t) 0.5 Amplitude -0.50.5 1.5 2.5 3 3.5 4.5 0 2 4 5 t(s) Single-Sided Amplitude Spectrum of x(t) 40 30 € 20 10 0 0 1000 2000 3000 4000 5000 6000 7000 8000 Frequency (Hz)

 $Xf_max = 40.7837$

 $Xf_{max_f} = 281.2500$

2. Select the filter type according to the noise position

Noise is concentrated at 281Hz, consider using a band-stop filter.

3. Observe the filter processing result and adjusting filter parameters

The filter parameters can be adjusted so that the filter can obtain better performance while using less resources.


4. Consider the filter order and make trade-offs to reduce its order and performance

In order to reduce the order and facilitate the implementation, a high-pass filter is used instead.

5. Quantification and performance evaluation

The filter is quantified by considering the resource and performance requirements.


• Graphs of the frequency response before and after the audio is filtered.




• Your method for quantising the filter coefficients and graphs of the frequency response after applying the 'under-quantised', 'appropriately quantised' and 'over-quantised' filters.

The filter is quantified by considering the resource and performance requirements.


'under-quantised':



'appropriately quantised':



'appropriately quantised':



• Discuss the trade-offs you considered for selecting the number of bits for your final filter

Although higher performance can be obtained by using higher bits and higher order filters, considering the limited resources, we must reduce the order of the filter and the number of bits when quantizing, so as to obtain higher performance with fewer resources. I have changed from an ideal band-stop filter to a quantized high-pass filter, which greatly reduces the order and bits and improves the realizability while the performance is guaranteed.