

Marco Vaccari†, Gabriele Pannocchia

University of Pisa, Department of Civil and Industrial Engineering, Largo Lucio Lazzarino 2, 56126 Pisa (Italy). May 17, 2021

†Email: marco.vaccari@ing.unipi.it.

# **Contents**

1	Intr	roduction	3
	1.1	Installation	3
	1.2	Testing default examples	4
2	Bas	ic Usage and samples	5
	2.1	Non Linear MPC	5
	2.2	Linear MPC	9
	2.3	Economic MPC	12
3	Adv	anced Usage	15
	3.1	Simulation Fundamentals	15
		3.1.1 Simulation discretization parameters	15
		3.1.2 Symbolic variables	15
	3.2	Process and Model construction	16
		3.2.1 Process parameters	16
		3.2.2 Model parameters	17
		3.2.3 Disturbance model for Offset-free control	18
		3.2.4 Initial condition	18
	3.3	State estimation	18
	3.4	Steady-state and dynamic optimizers	20
		3.4.1 Setpoints	20
		3.4.2 Bounds constraints	20
		3.4.3 Steady-state optimization: objective function	21
		3.4.4 Dynamic optimization: objective function	22
		3.4.5 Solver options	23
	3.5	Further options	23
	3.6	Plotting section	24

## Chapter 1

## Introduction

#### 1.1 Installation

This document is intended to give a guideline to the user who has to prepare his own example to test on MPC\_code or to understand how the given ones work.

The program is written for Python<sup>1</sup> and CasADi 3.4 (both are supported on Windows \ Linux \ Mac). For detailed installation instruction on CasADi go to the link:

https://web.casadi.org/get/

Scypy and Numpy packages are also required. In the case where these package are not given in your Python installation package, you can download it form the following link:

https://www.scipy.org/scipylib/download.html

In order to make the code compatible to both Python 2.7 and 3.6, the package future has to be installed (for more details see: <a href="http://python-future.org/index.html">http://python-future.org/index.html</a>). This package can be installed via pip install, or searching for future among non installed packages in Anaconda Navigator (more information can be found at https://anaconda.org/anaconda/anaconda-navigator).

The MPC\_code is distributed as packed file MPC\_code.zip that contains the following items:

- MPC\_code.py: main file that has to be run
- Targ\_calc.py: it contains the steady-state target optimization module
- Control\_calc.py: it contains the dynamic optimization module
- Estimator.py: it contains all the possible state estimators
- Utilities.py: it contains many functions used in all the other modules
- Default\_Values.py: it contains the default values of many options the user can specify in the example file. Detailed descriptions will follow
- SS\_JAC\_ID.py: it contains a tool for an automatic system linearization
- Ex\_LMPC\_WB.py, Ex\_LMPC\_CSTR.py: examples of linear MPC. They represent the case where both the model and the process maps are linear
- Ex\_LMPC\_nlplant.py: example of linear controller MPC and non-linear process equations. The linear controller model has been implemented with linearization matrices and corresponding parameters;
- Ex\_LMPCxp\_plant.py: example of linear controller MPC and non-linear process equations where model and process have a different number of states;

<sup>&</sup>lt;sup>1</sup>Both Python 2.7 and 3.6 are now supported

- Ex\_NMPC.py: example of non-linear MPC. It represents the case where both the model and the process maps are non-linear;
- Ex\_NMPC\_dis.py: example of non-linear MPC. It represents the case where both the model and the process maps are non-linear where the state maps are in discrete-time for both the process and the model;
- Ex\_ENMPC.py: example of non-linear economic MPC. It represents the case where the model, the process maps and also the optimization modules objective functions are non-linear.

## 1.2 Testing default examples

First of all, unpack the zip file and put everything into a folder. In order to run a simulation for the default examples given, write the name of the file to test (i.e. Ex\_LMPC.py) in the following line in **MPC\_code.py**:

To clarify better, a line identified by the comment "# Insert here your file name" indicates the exact place at the top of the file. Note also that the extension "\*.py" is not required.

Once set the file name for the wanted file, just run the Python script MPC\_code.py to start the simulation.

When, instead, you want to create a file (new, or starting from one of the given examples), i.e. "Ex\_1.py"; remember to copy all the import lines present at the top of each given examples. As said above, after preparing the test file, write its name in the MPC\_code.py with the following line:

```
ex_name = __import__('your_relative_path/Ex_1').
```

The 'your\_relative\_path' string identifies the relative path where the Ex\_1.py can be found in your disc respect to MPC\_code.py. If the file Ex\_1.py is in the same folder of MPC\_code.py there is no need to add any path before its name.

## Chapter 2

## **Basic Usage and samples**

To start using the MPC CODE, few basic features are introduced together with some examples contained in the zip file. Three examples are given here to introduce the user to the code:

- · firstly a Non Linear example is given and explained step by step;
- then a Linear MPC approximation of the previous one is given;
- finally an Economic MPC example is explored.

It is underlined that this section provides a mix of samples for the basic user that does want to practice with a fairly standard MPC example. Anyway the reader is invited to consult Chapter 3 for the complete range of possibilities that this code offers.

It is important to note that *the user cannot change the name of the variable written in* typographical style, e.g. the code is case dependent respect to these variables.

### 2.1 Non Linear MPC

This example can be followed in the Ex\_NMPC.py file given in the zip file. Consider a non-linear system described by a ODE system by

$$\begin{split} \dot{x_0} &= \frac{F_0(c_0 - x_0)}{\pi r^2 x_2} - k_{T_0} \exp\left(-\frac{E}{R} \left(\frac{1}{x_1} - \frac{1}{T_0}\right)\right) x_0 \\ \dot{x_1} &= \frac{F_0(T_0 - x_1)}{\pi r^2 x_2} - \frac{\Delta H}{\rho C_p} k_{T_0} \exp\left(-\frac{E}{R} \left(\frac{1}{x_1} - \frac{1}{T_0}\right)\right) x_0 + 2 \frac{U_0}{r \rho C_p} (T_c - x_1) \\ \dot{x_2} &= \frac{F_0 - u_1}{\pi r^2} \end{split}$$

First of all let us introduce the simulation parameters used: a discretization time step of 0.2 is chosen to build the discrete-time system, and a simulation length of 200 time steps is used. Moreover a prediction horizon of 50 time steps is selected.

```
Nsim = 201 # Simulation length

N = 50 # Horizon

h = 0.2 # Time step
```

The problem dimensions are the following: 3 states, 2 inputs, and 2 ouputs.

```
xp = SX.sym("xp", 3) # process state vector #
x = SX.sym("x", 3) # model state vector #
u = SX.sym("u", 2) # control vector #
y = SX.sym("y", 2) # measured output vector #
```

Then the continuous-time non linear process state map is defined in this way:

```
def User_fxp_Cont(x,t,u):
               SUMMARY:
              It constructs the function fx_p for the non-linear case
              assignment = User_fxp_Cont(x,t,u)
              ARGUMENTS:
                                                       - State variable
              + x
                                  - Current time
               + u
                                                       - Input variable
              OUTPUTS:
              + fx_p
                                                       - Non-linear plant function
              F0 = if_else(t \le 5, 0.1, if_else(t \le 15, 0.15, if_else(t \le 25, 0.08, 0.1)))
             T0 = 350  # K

c0 = 1.0  # kmol/m^3
              r = 0.219 \# m
              k0 = 7.2e10 \# min^-1
              EoR = 8750 \# K
              U0 = 915.6*60/1000 \# kJ/min*m^2*K
              {\tt rho} = 1000.0 \# kg/m^3
              Cp2 = 0.239 \# kJ/kg
              DH = -5.0e4 \# kJ/kmol
              Ar = math.pi*(r**2)
              kT0 = k0*exp(-EoR/T0)
              fx_p = vertcat\
              (\
              F0*(c0 - x[0])/(Ar *x[2]) - kT0*exp(-EoR*(1.0/x[1]-1.0/T0))*x[0], 
              F0*(T0 - x[1])/(Ar *x[2]) -DH/(rho*Cp2)*kT0*exp(-EoR*(1.0/x[1]-1.0/T0))*x[0] + (1.0/x[1]-1.0/T0))*x[0] + (1.0/x[1]-1.0/x[1]-1.0/T0))*x[0] + (1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x[1]-1.0/x
              2*U0/(r*rho*Cp2)*(u[0] - x[1]), 
              (F0 - u[1])/Ar
              return fx_p
Mx = 10 # Number of elements in each time step
```

For cleaner notation, the function preamble environment denoted by " " " will be omitted later on. The parameter Mx represent the number of elements used in the automatic integration inside the code. Next the output map is the one to be defined. In this case only the first and the last state are measured, in the code we define:

```
def User_fyp(x,t):
    fy_p = vertcat\
    (\
    x[0],\
    x[2] \
    )
    return fy_p
```

In addition let us consider some measurement noise on the process output in this form:

$$y_p = h_p(x, t, u) + v$$

where  $h_p(x, t, u)$  is the process output map of the process while  $v = R_{wn}^{\frac{1}{2}} v_{rand}$  in which  $v_{rand} \in \mathbb{R}^{n_y}$  is random vector normally distributed with mean "0" and variance "1". In order to define the noise, the covariance matrix, e.g.  $R_{wn} = 10^{-7} \times I_{ny}$ , has to be specified. In the code will be:

R\_wn = 1e-7\*np.array([[1.0, 0.0], [0.0, 1.0]]) #  $\theta utput$  white noise covariance matrix

The model function is written analogously to the process one in the following way:

```
def User_fxm_Cont(x,u,d,t):
    F0 = d[1]
    TO = 350 # K
    c0 = 1.0 \# kmol/m^3
    r = 0.219 \# m
    k0 = 7.2e10 \# min^-1
    EoR = 8750 \# K
    U0 = 915.6*60/1000 \# kJ/min*m^2*K
    rho = 1000.0 \# kg/m^3
    \texttt{Cp2} = \texttt{0.239} \# kJ/kg
    DH = -5.0e4 \# kJ/kmol
    Ar = math.pi*(r**2)
    kT0 = k0*exp(-EoR/T0)
    x_model = vertcat\
    (\
    F0*(c0 - x[0])/(Ar *x[2]) - kT0*exp(-EoR*(1.0/x[1]-1.0/T0))*x[0], \
F0*(T0 - x[1])/(Ar *x[2]) -DH/(rho*Cp2)*kT0*exp(-EoR*(1.0/x[1]-1.0/T0))*x[0] + \
    2*U0/(r*rho*Cp2)*(u[0] - x[1]), 
    (F0 - u[1])/Ar\
```

Note that in this case a non linear disturbance model is used: the disturbance size is chosen to fulfill the offsett-free requirements

```
d = SX.sym("d", 2)  # disturbance  #
```

and the offree tag has to be changed to the proper value

```
offree = "nl" # set "lin"/"nl" to have a linear/non linear disturbance model. "no"
means no disturbance model will be implmented
```

Moreover the parameter F0 in  $User_fxm_Cont(x,t,u)$  has been imposed to be equal to the second component of the disturbance. The output map is defined in analogy with the process one:

The setpoints are chosen to be constant for the entire simulation:

```
def defSP(t):
    xsp = np.array([0.0, 0.0, 0.0]) # State setpoints
    ysp = np.array([0.874317, 0.6528]) # Output setpoint
    usp = np.array([300.157, 0.1]) # Control setpoints
    return [ysp, usp, xsp]
```

Being the considered system a non-linear one, as state estimator an Extended Kalman filter represented by the following matrices is chosen:

$$Q_{kf} = \begin{pmatrix} 10^{-5}I_{nx} & \\ & I_{nd} \end{pmatrix} \qquad R_{kf} = 10^{-4}I_{ny} \qquad P_0 = I_{nx+nd}$$

where  $I_{n\xi}$  is the identity matrix of dimension of the variable  $\xi$ . In the code the estimator is defined as:

```
ekf = True # Set True if you want the Extended Kalman filter
Qx_kf = 1.0e-5*np.eye(x.size1())
Qd_kf = np.eye(d.size1())
Q_kf = scla.block_diag(Qx_kf, Qd_kf)
R_kf = 1.0e-4*np.eye(y.size1())
P0 = 1*np.ones((x.size1()+d.size1(),x.size1()+d.size1()))
```

In order for the simulation and the two optimization problems to run the initial state and the bound constraint for the considered variables need to be defined.

```
x0_p = np.array([0.874317, 325, 0.6528]) # plant
x0_m = np.array([0.874317, 325, 0.6528]) # model
u0 = np.array([300.157, 0.1])

## Input bounds
umin = np.array([295, 0.00])
umax = np.array([305, 0.25])

## State bounds
xmin = np.array([0.0, 315, 0.50])
xmax = np.array([1.0, 375, 0.75])

# Output bounds
ymin = np.array([0.0, 0.5])
ymax = np.array([1.0, 1.0])

## Disturbance bounds
dmin = -100*np.ones((d.size1(),1))
dmax = 100*np.ones((d.size1(),1))
```

The two objective functions for the optimization problems are chosen to be in a quadratic form, that is for the steady-state optimizer

$$Fss_{obj} = \frac{1}{2}(y - y_{sp})^{T}Q_{ss}(y - y_{sp})$$

while for the dynamic optimizer

$$F_{obj} = \sum_{i=0}^{i=N-1} \left[ \frac{1}{2} (x(i) - x_s)^T Q(x(i) - x_s) + \frac{1}{2} (u(i) - u_s)^T R(u(i) - u_s) \right]$$

In the code the chosen matrices are defined as follows:

```
## Steady-state optimization
Qss = np.array([[10.0, 0.0], [0.0, 1.0]]) #Output matrix
Rss = np.array([[0.0, 0.0], [0.0, 0.0]]) # Control matrix


## Dynamic optimization
Q = np.array([[1.0, 0.0, 0.0], [0.0, 1.0, 0.0], [0.0, 0.0, 1.0]])
R = np.array([[0.1, 0.0], [0.0, 0.1]])
```

As result of the simulation the following quantities can be analyzed:

- X\_HAT: it represents the matrix of all the estimated states;
- U: it represents the matrix of all the inputs;
- Xp: it represents the matrix of all the process states;
- Yp: it represents the matrix of all the process output;
- XS: it represents the matrix of all the target states;
- US: it represents the matrix of all the target inputs;
- YS: it represents the matrix of all the target outputs;
- D\_HAT: it represents the matrix of all the estimated model disturbances;

These quantities can be scanned in the current Python console but they are also displayed in plots like the ones below. Usually, the model states (Actual) and its steady-state (Target) are plotted together, as well as the process output and its target values, and the inputs quantities.

The code prints a plot for each variable considered, e.g. in this case there will be 3 state plots, 2 output plots, 2 input plots and 2 disturbance plots.



### 2.2 Linear MPC

This example can be followed in the Ex\_LMPC\_nlplant.py file given in the zip file.

The same non-linear system described above in  $\S 2.1$  is presented, but this time the parameter F0 is assumed to be fixed: in particular inside the function User\_fxp\_Cont(x,t,u) the F0 value is substituted with

```
FO = 0.1  # m^3/min
```

The ODE system is modeled with a discrete-time linear one as follows

$$x^{+} - x_{lin} = A(x - x_{lin}) + B(u - u_{lin})$$
$$y = C(x - x_{lin})$$

Let us consider the same simulation parameters used in the previous example and the same dimensions of the problem. The output map is now defined. As before, only the first and the last state are measured so we define the matrix:

```
Cp = np.array([[1.0, 0.0, 0.0], [0.0, 0.0, 1.0]])
```

Then the linear model to be used in the MPC algorithm is defined as:

```
A = np.array([[0.51448, -0.00917517, -0.117995],[53.6817, 2.15004, -3.77725], [0.0, 0.0, 1]])
B = np.array([[-0.0017669, 0.0864569], [0.639423, 1.60696], [0.0, -1.32737]])
```

```
C = np.array([[1.0, 0.0, 0.0], [0.0, 0.0, 1.0]])
# Linearization parameters
xlin = np.array([0.5, 350, 0.659])
ulin = np.array([300, 0.1])
```

Now an input disturbance model is chosen so the linear system can be rewritten as:

$$x^{+} - x_{lin} = A(x - x_{lin}) + B(u - u_{lin}) + Bd$$
$$y = C(x - x_{lin})$$

In the code the disturbance dimension is chosen as before and the matrices Bd and Cd are implemented as follows:

Note that in this case the offree tag value has been changed to "lin".

Setpoints are then defined in a way that the first output will change at time 20 min (note that the total time of simulation is  $200 \times 0.2 = 40$  min), while the second one has remain at same value.

```
def defSP(t):
    xsp = np.array([0.0, 0.0, 0.0]) # State setpoints
    usp = np.array([299.963, 0.1]) # Control setpoints

if t < 20:
    ysp = np.array([0.5, 0.659]) # Output setpoint
elif t <= 40:
    ysp = np.array([0.51, 0.659]) # Output setpoint</pre>
return [ysp, usp, xsp]
```

As state estimator a Kalman filter with the following matrices is chosen:

$$Q_{kf} = \begin{pmatrix} 10^{-5}I_{nx} & & \\ & I_{nd} \end{pmatrix} \qquad R_{kf} = 10^{-4}I_{ny} \qquad P_0 = 10^{-4}Q_{kf}$$

where  $I_{n\xi}$  is the identity matrix of dimension of the variable  $\xi$ . In the code the estimator is defined in the following way:

```
kal = True # Set True if you want the Kalman filter
nx = x.size1()
ny = y.size1()
nd = d.size1()
Qx_kf = 1.0e-5*np.eye(nx)
Qd_kf = np.eye(nd)
Q_kf = scla.block_diag(Qx_kf, Qd_kf)
R_kf = 1.0e-4*np.eye(ny)
P0 = 1e-3*Q_kf
```

In order to define the simulation and the two optimization problems the initial state and the bound constraints need to be defined.

```
# Initial conditions
x0_p = np.array([0.5, 350, 0.659]) # plant
x0_m = np.array([0.5, 350, 0.659]) # model
u0 = np.array([300, 0.1])

## Input bounds
umin = np.array([295, 0.00])
umax = np.array([305, 0.25])

## State bounds
xmin = np.array([0.0, 320, 0.45])
xmax = np.array([1.0, 375, 0.75])
```

The two objective functions for the optimization problems are the next to be defined. In particular we choose to formulate two QP problems, that is for the steady-state optimizer

$$Fss_{obj} = \frac{1}{2} (y - y_{sp})^T Q_{ss} (y - y_{sp})$$

while for the dynamic optimizer

$$F_{obj} = \sum_{i=0}^{i=N-1} \left[ \frac{1}{2} (x(i) - x_s)^T Q(x(i) - x_s) + \frac{1}{2} \Delta u(i)^T S \Delta u(i) \right] + \frac{1}{2} (x(N) - x_s)^T P(x(N) - x_s)$$

(where  $\Delta u(i) = u(i) - u(i-1)$ ). In the code the chosen matrices are defined in this way:

```
## Steady-state optimization

Qss = np.array([[10.0, 0.0], [0.0, 0.01]]) #Output matrix


Rss = np.array([[0.0, 0.0], [0.0, 0.0]]) # Control matrix

## Dynamic optimization

Q = np.array([[10.0, 0.0, 0.0], [0.0, 1.0, 0.0], [0.0, 0.0, 1.0]])

S = np.array([[0.1, 0.0], [0.0, 0.1]]) # DeltaU matrix
```

Note that in this case (being the considered system linear and the objective function quadratic) the terminal weight for the dynamic problem will be automatically calculated in the code in a quadratic form with a weighting matrix result of the algebraic Riccati equation (see §3.4.4 for details). As in the previous case, the quantities can be scanned in the current Python console but they are also displayed in plots like the ones below. The code will print a plot for each variable considered, e.g. in this case there will be 3 state plots, 2 output plots, 2 input plots and 2 disturbance plots.



#### 2.3 Economic MPC

This example can be followed in the Ex\_ENMPC. py file given in the zip file. A non-linear system described by a ODE system is considered:

$$\dot{x_0} = \frac{u(c_{A0} - x_0)}{V} - k_1 x_0$$

$$\dot{x_1} = \frac{-ux_1}{V} + k_1x_0 - k_2x_1$$

Suppose that there is no plant/model mismatch, i.e.  $User_fxp_Cont(xp,t,u)$  and  $User_fxm_Cont(x,u,d,t)$  are the same. We then assume that all the states are measured, i.e. y = x, that is in the code we simply write:

```
StateFeedback = True # Set to True if you have all the states measured
```

without specifying any output map. In addition let us consider some process noise on the state map, i.e.:

$$x_p^+ = F_p(x_p, t, u) + G_{wn}w$$

where  $F_p(x_p, t, u)$  is the <u>integrated</u> process state map while  $w = Q_{wn}^{\frac{1}{2}} w_{rand}$  in which  $w_{rand} \in \mathbb{R}^{n_x}$  is a random vector normally distributed with mean "0" and variance "1". In order to define the noise, the covariance and the weighting matrices need to be specified, e.g.  $Q_{wn} = 10^{-1} \times I_{nx}$ ,  $G_{wn} = 10^{-2} \times I_{nx}$ . In the code will be:

```
G_{wn} = 1e-2*np.array([[1.0, 0.0], [0.0, 1.0]]) # State white noise matrix Q_{wn} = 1e-1*np.array([[1.0, 0.0], [0.0, 1.0]]) # State white noise covariance matrix
```

Let us then introduce the simulation parameters used: a discretization time step of 2.0 is chosen to build our discrete-time system, and a simulation length of 21 time steps is used. Moreover a prediction horizon of 25 time steps is selected.

```
Nsim = 21  # Simulation length N = 25  # Horizon h = 2.0  # Time step
```

The problem dimensions are: 2 states, 1 inputs, 2 ouputs and 2 disturbances.

```
xp = SX.sym("xp", 2) # process state vector #
x = SX.sym("x", 2) # model state vector #
u = SX.sym("u", 1) # control vector #
y = SX.sym("y", 2) # measured output vector #
d = SX.sym("d", 2) # disturbance #
```

Now an output disturbance model is chosen so the system can be rewritten as:

$$x^{+} = F(x, u, t)$$
$$y = x + d$$

where F(x, u, t) is the <u>integrated</u> model state map. As seen above, in the code only the matrices Bd and Cd need to be implemented:

```
Bd = np.zeros((d.size1(),d.size1()))
Cd = np.eye(d.size1())
```

As this is an economic MPC example, setpoints are not useful, so there is no need to define them. This time, being the system non-linear, a Moving Horizon Estimation (MHE) method with a smoothed updating is chosen. Let us define the MHE horizon to be  $N_{MHE} = 10$  time steps, and the cost function to be quadratic, i.e.:

$$F_{obj,MHE} = \sum_{i=0}^{i=N_{MHE}} \left[ \frac{1}{2} w(i)^T w(i) + \frac{1}{2} v(i)^T v(i) \right] + \frac{1}{2} (x(0) - \bar{x}_0)^T (x(0) - \bar{x}_0).$$

A linear additive noise to the state is considered so that the augmented model map will be:

$$\chi^+ = \tilde{F}(\chi, u, t) + w$$

where  $\chi = \begin{bmatrix} x \\ d \end{bmatrix}$  and  $\tilde{F} = \begin{bmatrix} F \\ d \end{bmatrix}$ . In the code we simply define the following lines:

```
nx = x.size1()
ny = y.size1()
nd = d.size1()
w = SX.sym("w", nx+nd) # state noise
P0 = np.eye(nx+nd)
x_bar = np.row_stack((np.atleast_2d(x0_m).T,np.zeros((nd,1))))
# Defining the state map
def User_fx_mhe_Cont(x,u,d,t,w):
    x_{model} = vertcat(u[0]*(cA0 - x[0])/V - k1*x[0], 
                   -u[0]*x[1]/V + k1*x[0] - k2*x[1]
    return x_model
# Defining the MHE cost function
def User_fobj_mhe(w,v,t):
    Q = np.eye(nx+nd)
    R = np.eye(ny)
    fobj_mhe = 0.5*(xQx(w,inv(Q))+xQx(v,inv(R)))
    return fobj_mhe
```

Note that in order to define the MHE problem, the definition of the additional variable w is required. The problem augmenting is automatically done into the code and so the noise adding.

The initial state and the bound constraint for the considered variables are as follows (note that a mismatch on the initial point is introduced):

```
x0_p = vertcat(0.9, 0.1) # plant
x0_m = vertcat(1.2, 0.5) # model
u0 = vertcat(0.)

## Input bounds
umin = [0.00]
umax = [2.0]

## State bounds
xmin = vertcat(0.00, 0.00)
xmax = vertcat(1.00, 1.00)
```

Then the two objective functions for the optimization problems are defined. The process economics can be expressed by the running cost:

$$\ell(u, y_1) = \beta_A u c_{A0} - \beta_B u y_1$$

where  $\beta_A$ ,  $\beta_B$  are the prices for the  $x_0$  and  $x_1$ , respectively.

While the target objective function can be formulated without any problem as  $\ell(\cdot)$ , for the dynamic optimizer there is a clarification to me made. The use of the cost function integrated over the sampling time is necessary to achieve an asymptotically stable closed-loop equilibrium. As a matter of fact, if the point-wise evaluation of  $\ell(\cdot)$  was used as stage cost in the dynamic problem, the closed-loop system would not be stable.

To recap, the two objective functions for the optimizations problems are:

$$Fss_{obj} = \ell(u, y_1)$$

and

$$F_{obj} = \sum_{i=0}^{i=N-1} \left[ \int_{i \cdot h}^{(i+1) \cdot h} \ell(u(t), y_1(t)) dt \right] + \frac{1}{2} x(N)^T P x(N)$$

where  $P = 2 \cdot 10^3 \times I_{nx}$ . In the code we can simply define the following lines:

```
cAO = 1.0  # kmol/m^3
alfa = 1.  # reactant price
beta = 4.  # product price


## Steady-state optimization
def User_fssobj(x,u,y,xsp,usp,ysp):
    obj = u[0]*(alfa*cAO - beta*y[1])
    return obj

## Dynamic optimization
def User_fobj_Cont(x,u,y,xs,us,ys):
    obj = u[0]*(alfa*cAO - beta*y[1])
    return obj

# Terminal weight
def User_vfin(x,xs):
    diffx = x-xs
    vfin = mtimes(diffx.T,mtimes(2000,diffx))
    return vfin
```

Note how to represent the integrated form of  $\ell(\cdot)$ , a continuous-time version of the objective function is defined. Note also that in this case (being the considered system non linear and the objective function non quadratic) the terminal weight for the dynamic problem will not be automatically calculated, hence a custom Python function "User\_vfin(x,xs)" needs to be specified.

The code will print a plot for each variable considered, in this case 2 state plots, 2 output plots, 1 input plot and 2 disturbance plots. Examples are given below.



## **Chapter 3**

## **Advanced Usage**

Details for an advanced usage of the code are given in this chapter. Every aspect of the code useful the the compilation of a new example will be explained. The user can explore better what are all the possible combinations to build a custom example. This section is developed as follows: firstly the construction of the plant, that produces measurements, and its model are introduced; then the main blocks that constitute the MPC algorithm are detailed (state estimation, steady-state and dynamic optimizer); in the end further options and plotting information are given.

## 3.1 Simulation Fundamentals

#### 3.1.1 Simulation discretization parameters

These are the three simulation parameters that has always to be defined in an example file.

- Nsim: It is the simulation length;
- N: It is the prediction horizon length;
- h: It is the discretization time step. If you are already in discrete-time just insert the value "1.0".

### 3.1.2 Symbolic variables

Being the MPC CODE built with a CasADi interface, you have to define some basic symbolic variables. These variables are the ones used for function evaluations during the simulation: set here the dimension of each single variable as the problem requires.

- xp: It is the state process vector;
- x: It is the state model vector;
- u: It is the control vector;
- y: It is the measured output vector;
- d: It is the disturbance model vector. If no disturbance model is selected you have to enter the value "0";
- w: It is the state update model noise. It is used when mhe is selected as estimator (see §3.3 for further details).

#### 3.2 Process and Model construction

#### 3.2.1 Process parameters

All the possible combinations that is possible to use for the process equations are now explained.

- 1. **Linear.** If the process equations are linear, then the following matrices need to be defined:
  - Ap: It is the state transition matrix ( $\in \mathbb{R}^{n_x \times n_x}$ );
  - Bp : It is the input-state matrix ( $\in \mathbb{R}^{n_x \times n_u}$ );
  - Cp : It is the state-output matrix  $(\in \mathbb{R}^{n_y \times n_x})$ ; ;
- 2. **Non Linear.** If the process equations are non-linear, then the functions explained below have to be defined. It has to be noted that the syntax in these functions has to be consistent with the CasADi language:
  - · State map.
    - (a) Continuous-time: Define the function "User\_fxp\_Cont(x,t,u)". The input "t" gives the possibility to introduce time-variant non-linear disturbances. The output describes the state dynamic to be integrated<sup>1</sup>, i.e.  $\dot{x} = User_fxp_Cont(x,t,u)$ ;
    - (b) Discrete-time: Define the function "User\_fxp\_Dis(x,t,u)". The input "t" gives the possibility to introduce time-variant non-linear disturbances. The output describes the discrete state dynamic, i.e.  $x = User_fxp_Dis(x,t,u)$ .
  - Output map. Define the function "User\_fyp(x,t)". The input "t" gives the possibility to introduce time-variant non-linear disturbances. The output describes the map, i.e.  $y = User_f yp(x,t)$ .

#### White noise

Another option that can be introduced is represented by process and measurement noise. The white noise is modeled as described below.

$$x^{+} = f_{p}(x, t, u) + G_{wn}w, \qquad y = h_{p}(x, t, u) + v$$

where

$$w = Q_{wn}^{\frac{1}{2}} w_{rand}$$
 and  $v = R_{wn}^{\frac{1}{2}} v_{rand}$ 

The matrices to be defined are then as follows:

- G\_wn: It is the state white noise matrix ( $\in \mathbb{R}^{n_x \times n_x}$ );
- Q\_wn: It is the state white noise covariance matrix ( $\in \mathbb{R}^{n_x \times n_x}$ );
- R\_wn: It is the output white noise covariance matrix ( $\in \mathbb{R}^{n_y \times n_y}$ ).

Note that  $w_{rand} \in \mathbb{R}^{n_x}$  and  $v_{rand} \in \mathbb{R}^{n_y}$  are random vector normally distributed calculated with mean "0" and variance "1".

## **Process disturbances**

If the process equations are in discrete-time form (linear or not) then additive disturbances can be added on the state dynamics or/and on the output. This is possible by defining the following functions:

- defdxp(t): It is the state disturbance. It can be defined through the Python function " $dx_p = def dxp(t)$ ".
- defdyp(t): It is the output disturbance. It can be defined through the Python function " $dy_p = def dyp(t)$ ".

The input t give the opportunity to formulate a time depending disturbance.

<sup>&</sup>lt;sup>1</sup>At the moment only the Multiple Shooting integration scheme is implemented

#### **Summary**

The user can choose any combination of the previous possibilities keeping in mind that just one state correlation and one for the output must be selected. For instance those are some possible combinations:

• 
$$x = A_p x + B_p u$$
,  $y = C_p x$ 

• 
$$x = f_p(x, t, u), \qquad y = C_p x$$

• 
$$x = A_p x + B_p u + G_{wn} w$$
,  $y = h_p(x, t, u) + v$ 

• 
$$x = f_p(x, t, u)$$
,  $y = C_p x + v + dy_p$ 

• 
$$x = A_p x + B_p u + dx_p$$
,  $y = h_p(x, t, u)$ 

## 3.2.2 Model parameters

All the possible options for the model equations are now explained.

- 1. Linear. If the model equations are linear, the following matrices has to be defined:
  - A : It is the state matrix ( $\in \mathbb{R}^{n_x \times n_x}$ );
  - B: It is the input-state matrix  $(\in \mathbb{R}^{n_x \times n_u})$ ;
  - C: It is the state-output matrix ( $\in \mathbb{R}^{n_y \times n_x}$ );;

The model matrices can also represent linearization matrices of a non-linear model map. In this case the user has to define the linearization point:

- xlin: It is the state linearization vector ( $\in \mathbb{R}^{n_x}$ );
- ulin: It is the control linearization vector ( $\in \mathbb{R}^{n_u}$ );
- ylin: It is the output linearization vector ( $\in \mathbb{R}^{n_y}$ );
- 2. **Non Linear.** If the model equations are non-linear, then the following functions needs to be defined. It has to be noted that the syntax in these functions has to be consistent with the CasADi language:
  - · State map.
    - (a) Continuous-time: Define the function "User\_fxm\_Cont(x,u,d,t)". The output describes the state dynamic to be integrated<sup>2</sup>, i.e.  $\dot{x} = User_fxm_Cont(x,u,d,t)$ ; at this purpose, the user has to define also the parameter Mx that is necessary for the explicit Euler integration: it represents the number of elements in each integration step;
    - (b) Discrete-time: Define the function "User\_fxm\_Dis(x,u,d,t)". The output describes the discrete state dynamic, i.e.  $x = User_fxm_Dis(x,u,d,t)$ ;
  - Output map. Define the function "User\_fym(x,d,t)". The output describes the integrated output dynamic, i.e.  $y = User_fym(x,d,t)$ .

#### **Summary**

The user can choose any combination of the previous possibilities keeping in mind that just one state correlation and one for the output must be selected. For instance those are few possible combinations:

• 
$$x = Ax + Bu$$
,  $y = Cx$ 

• 
$$x = f(x, u), \quad y = Cx$$

• 
$$x = Ax + Bu$$
,  $y = h(x, u)$ 

<sup>&</sup>lt;sup>2</sup>At the moment only the Multiple Shooting integration scheme is implemented

#### 3.2.3 Disturbance model for Offset-free control

To select a disturbance model, you have to modify the tag "offree" as displayed below:

- offree = "no": no disturbance model is implemented (default);
- offree = "lin": linear disturbance model is adopted. The relations would be:

$$x = F(x, u, t) + B_d d$$
,  $y = H(x, u, t) + C_d d$ 

where F(x, u, t) is any <u>integrated</u> state transition map and H(x, u, t) any output map between linear and non-linear. The matrices to be defined are:

- Bd : It is the state disturbance matrix ( $\in \mathbb{R}^{n_x \times n_d}$ );
- Cd : It is the output disturbance matrix ( $\in \mathbb{R}^{n_y \times n_d}$ ).
- offree = "nl": non-linear disturbance model is adopted. The user has to decided where the disturbance d must enter.

<u>Warning:</u> if no disturbance model is selected, then d dimension must be "0"; vice-versa, if the disturbance d dimension is "0", then the user must choose offree = "no". If this condition is not fulfilled, an error arises.

#### 3.2.4 Initial condition

The initial condition to be given are separated for the process and the model in order to give more generality to the code.

- x0\_p: It is the state initial condition for the process;
- x0\_m: It is the state initial condition for the model;
- u0: It is the control initial condition.

### 3.3 State estimation

The estimator possibilities implemented in the code are now illustrated. All of these choices are characterized by a tag that has to be set to "True" when the chosen estimator is selected.

- Kalman Filter [tag: "kal"]: for the Kalman filter the matrices to be defined are three:
  - Q\_kf: It is the process noise covariance matrix ( $\in \mathbb{R}^{n_x+n_d\times n_x+n_d}$ );
  - R\_kf : It is the measurements noise covariance matrix ( $\in \mathbb{R}^{n_y \times n_y}$ );
  - P0 : It is the covariance of the state error at the initial point ( $\in \mathbb{R}^{(n_x+n_d)\times (n_x+n_d)}$ ).
- Steady-state Kalman Filter [tag: "kalss"]: for the steady-state Kalman filter the matrices and vectors to be defined are:
  - Q\_kf : It is the process noise covariance matrix ( $\in \mathbb{R}^{(n_x+n_d)\times(n_x+n_d)}$ );
  - R\_kf : It is the measurements noise covariance matrix ( $\in \mathbb{R}^{n_y \times n_y}$ );
  - Steady-state point: this has to be defined only if "A" and/or "C" have not been defined before for the model (see Section 3.2.2):
    - \* x\_ss: It is the steady-state state vector at which the estimator gain has to be calculated  $(\in \mathbb{R}^{n_x})$ ;
    - \* u\_ss: It is the steady-state control vector at which the estimator gain has to be calculated  $(\in \mathbb{R}^{n_u})$ .

- Extended Kalman Filter [tag: "ekf"]: for the extended Kalman filter the matrices to be defined are three:
  - Q\_kf: It is the process noise covariance matrix ( $\in \mathbb{R}^{(n_x+n_d)\times(n_x+n_d)}$ );
  - R\_kf : It is the measurements noise covariance matrix ( $\in \mathbb{R}^{n_y \times n_y}$ );
  - P0: It is the covariance of the state error at the initial point  $(\in \mathbb{R}^{(n_x+n_d)\times (n_x+n_d)})$ .
- Luenberger observer [tag: "lue"]: for the Luemberger observer just the estimator gain has to be specified as:
  - K : It is the estimator gain matrix ( $\in \mathbb{R}^{(n_x+n_d)\times n_y}$ ).
- **Moving Horizon Estimation** [tag: "mhe"]: for the Moving Horizon Estimation technique, there are few parameters/functions to be defined:
  - P0 : It is the covariance of the state error at the initial point ( $\in \mathbb{R}^{(n_x+n_d)\times(n_x+n_d)}$ );
  - x\_bar: It is the *a priori* state estimate the initial point ( $\in \mathbb{R}^{(n_x+n_d)}$ );
  - $N_{mhe}$ : It is the MHE horizon length ( $\in \mathbb{R}$ );
  - mhe\_up: It is a flag to decide which prior weight updating technique has to be used in the MHE problem. It can be set with two tags:
    - \* "filter": the filtering update will be applied
    - \* "smooth": the smoothing update will be applied
  - Model Function: in order to let the user to build a general implementation of the noise w, a
    function has to be written including the state evolution map. It has to be noted that the syntax
    in this function has to be consistent with the CasADi language:
    - \* Continuous-time: Define the function "User\_fx\_mhe\_Cont(x,u,d,t,w)". The output describes the state dynamic to be integrated<sup>3</sup>,i.e.  $\dot{x} = User_fx_mhe_Cont(x,u,d,t,w)$ ; At this purpose, the user has to define also the parameter Mx that is necessary for the explicit Euler integration: it represents the number of elements in each integration step;
    - \* Discrete-time: Define the function "User\_fx\_mhe\_Dis(x,u,d,t,w)". The output describes the discrete state dynamic, i.e.  $x = User_fx_mhe_Dis(x,u,d,t,w)$ ;

Noted that the measurement noise v is always considered linearly added to the output map, whatever this last one is defined, i.e. y = h(x, u, d, t) + v. One more remark has to be done about using MHE with linear and non-linear offset-free model. In this case the noise v will be added to the augmented model map as follows:

$$\begin{cases} x^+ = F(x, u, t) + B_d d \\ d^+ = d \end{cases} \quad \text{if offree = "lin"} \\ x^+ = F(x, u, d, t) \\ d^+ = d \quad \text{if offree = "nl"} \end{cases} \rightarrow \chi^+ = \tilde{F}(\chi, u, t) + w$$

where  $F(\cdot)$  is any <u>integrated</u> state transition map,  $\chi = \begin{bmatrix} x \\ d \end{bmatrix}$  and  $\tilde{F} = \begin{bmatrix} F \\ d \end{bmatrix}$ .

- Objective Function: As for the other optimization problems, there are three possibilities to define the objective function for the MHE problem:
  - 1. **Linear.** If the objective function is linear, define the following vectors:
    - \*  $r_w$ : It is the state vector ( $\in \mathbb{R}^{n_w}$ );
    - \*  $r_v$ : It is the control vector  $(\in \mathbb{R}^{n_y})$ .

<sup>&</sup>lt;sup>3</sup>At the moment only the Multiple Shooting integration scheme is implemented

Defined the appropriate vectors, the objective function will be linear:

$$F_{obj,mhe} = r_w^T w + r_v^T v$$

- 2. Quadratic. If the objective function is quadratic, define the following matrices:
  - \* Q\_mhe : It is the state noise matrix ( $\in \mathbb{R}^{n_w \times n_w}$ );
  - \* R\_mhe: It is the measurements noise matrix ( $\in \mathbb{R}^{n_y \times n_y}$ );

Defined the appropriate matrices, the objective function will be quadratic:

$$F_{obj,mhe} = \frac{1}{2} w^T Q_{mhe} w + \frac{1}{2} v^T R_{mhe} v$$

- 3. **Non Linear.** If a non linear objective function is desired, define the following Python function: "User\_fobj\_mhe(w,v,t)". The output describes the discrete-time cost function; "w, v, t" represent the process noise, the measurement noise and the time index respectively. Note that the syntax in this function has to be consistent with the CasADi language.
- **Bound Constraints**: Is it possible to add bound constraints on the two optimization variables, "w, v" that can be written as:
  - wmin: It is the low bound for the process noise vector ( $\in \mathbb{R}^{n_w}$ );
  - wmax: It is the high bound for the process noise vector ( $\in \mathbb{R}^{n_w}$ );
  - vmin: It is the low bound for the measurement noise vector  $(\in \mathbb{R}^{n_y})$ ;
  - vmax: It is the high bound for the measurement noise vector  $(\in \mathbb{R}^{n_y})$ ;

When these quantities are not defined they are automatically set to infinite (positive or negative) val-

## 3.4 Steady-state and dynamic optimizers

#### 3.4.1 Setpoints

Setpoints can be defined with the function "defSP(t)" that takes as input the current time index. The input gives the possibility to study a time-varying setpoint problem. The output of this function has to be a list composed in this order:

- ysp: It is the output setpoint vector ( $\in \mathbb{R}^{n_y}$ );
- usp : It is the control setpoint vector  $(\in \mathbb{R}^{n_u})$ ;
- xsp: It is the state setpoint vector  $(\in \mathbb{R}^{n_x})$ .

Note that even if xsp is not used into the chosen target problem, it has to be defined anyway.

#### 3.4.2 Bounds constraints

As the MPC structure has two, possibly (and more realistically) constrained optimization problems, bound constrains need to be specified when they are not infinite. To define bounds for the specific variables, you should respect this syntax.

- umin: It is the low bound for the input vector ( $\in \mathbb{R}^{n_u}$ );
- umax : It is the high bound for the input vector  $(\in \mathbb{R}^{n_u})$ ;
- xmin: It is the low bound for the state vector  $(\in \mathbb{R}^{n_x})$ ;

- xmax : It is the high bound for the state vector ( $\in \mathbb{R}^{n_x}$ );
- ymin: It is the low bound for the output vector  $(\in \mathbb{R}^{n_y})$ ;
- ymax: It is the high bound for the output vector  $(\in \mathbb{R}^{n_y})$ ;
- dmin: It is the low bound for the disturbance vector  $(\in \mathbb{R}^{n_d})$ ;
- dmax : It is the high bound for the disturbance vector ( $\in \mathbb{R}^{n_d}$ ).
- Dumin: It is the low bound for the input rate-of-change vector ( $\in \mathbb{R}^{n_u}$ );
- Dumax: It is the high bound for the input rate-of-change vector ( $\in \mathbb{R}^{n_u}$ );

Bound not specified will be automatically transformed into the code in positive or negative infinite values respectively.

#### 3.4.3 Steady-state optimization: objective function

- 1. Linear. If the objective function is linear, the following vectors need to be defined:
  - rss\_y: It is the output vector  $(\in \mathbb{R}^{n_y})$ ;
  - rss\_u: It is the control vector ( $\in \mathbb{R}^{n_u}$ ).
  - rss\_Du : It is the control difference vector ( $\in \mathbb{R}^{n_u}$ ).

rss\_u or rss\_Du must be used alternatively. Defined the appropriate vectors, the objective function will be linear and in particular in one of the two following forms:

$$Fss_{obj} = r_{ss,v}^T y + r_u^T u$$

or

$$Fss_{obj} = r_{ss,y}^{T} y + r_{ss,Du}^{T} |(u - u_{s}(k-1))|$$

where  $u_s(k-1)$  is the steady-state input value calculated at the previous iteration.

- 2. Quadratic. If the objective function is quadratic, the following matrices need to be defined:
  - Qss: It is the output matrix ( $\in \mathbb{R}^{n_y \times n_y}$ );
  - Rss: It is the control matrix ( $\in \mathbb{R}^{n_u \times n_u}$ ).
  - Sss: It is the control difference matrix ( $\in \mathbb{R}^{n_u \times n_u}$ ).

Rss or Sss must be used alternatively. Defined the appropriate matrices, the objective function will be quadratic and in particular in one of the two following forms:

$$Fss_{obj} = \frac{1}{2}(y - y_{sp})^{T}Q_{ss}(y - y_{sp}) + \frac{1}{2}(u - u_{sp})^{T}R_{ss}(u - u_{sp})$$

or

$$Fss_{obj} = \frac{1}{2}(y - y_{sp})^T Q_{ss}(y - y_{sp}) + \frac{1}{2}\Delta u^T S_{ss}\Delta u$$

(where  $\Delta u = u - u_s(k-1)$ )

3. **Non Linear.** The Python function "User\_fssobj(x,u,y,xsp,usp,ysp)" has to be defined when a non linear objective cost is needed. The output describes the discrete-time cost function; "xsp, usp, ysp" represent the setpoint values calculated by the function defSP(t) previously defined. Noted that the syntax in this function has to be consistent with the CasADi language

### 3.4.4 Dynamic optimization: objective function

- 1. **Linear.** If the objective function is linear, the following vectors need to be defined:
  - $\mathbf{r}_{\mathbf{x}}$ : It is the state vector ( $\in \mathbb{R}^{n_x}$ );
  - r\_u: It is the control vector ( $\in \mathbb{R}^{n_u}$ );
  - r\_Du : It is the control difference vector ( $\in \mathbb{R}^{n_u}$ ).

r\_u or r\_Du must be used alternatively. Defined the appropriate vectors, the objective function will be linear and in particular in one of the two following forms:

$$F_{obj} = \sum_{i=0}^{i=N-1} r_x^T |x(i) - x_s| + r_u^T |u(i) - u_s|$$

or

$$F_{obj} = \sum_{i=0}^{i=N-1} r_x^T |x(i) - x_s| + r_{Du}^T |(u(i) - u(i-1))|$$

- 2. **Quadratic.** If the objective function is quadratic, the following matrices need to be defined:
  - Q: It is the state matrix ( $\in \mathbb{R}^{n_x \times n_x}$ );
  - R: It is the control matrix ( $\in \mathbb{R}^{n_u \times n_u}$ );
  - S: It is the control difference matrix ( $\in \mathbb{R}^{n_u \times n_u}$ ).

R or S must be used alternatively. Defined the appropriate matrices, the objective function will be quadratic and in particular in one of the two following forms:

$$F_{obj} = \sum_{i=0}^{i=N-1} \frac{1}{2} (x(i) - x_s)^T Q(x(i) - x_s) + \frac{1}{2} (u(i) - u_s)^T R(u(i) - u_s)$$

or

$$F_{obj} = \sum_{i=0}^{i=N-1} \frac{1}{2} (x(i) - x_s)^T Q(x(i) - x_s) + \frac{1}{2} \Delta u(i)^T S \Delta u(i)$$

(where  $\Delta u(i) = u(i) - u(i-1)$ ).

- 3. **Non Linear.** If a non-linear cost function is needed, a Python function has to defined. It has to be noted that the syntax in these functions has to be consistent with the CasADi language. The non linear function can be chosen to be:
  - Continuous-time: Define: "User\_fobj\_Cont(x,u,y,xs,us,ys)". The output describes the cost function to be integrated<sup>4</sup>;
  - Discrete-time: Define: "User\_fobj\_Dis(x,u,y,xs,us,ys)". The output describes the discrete-time cost function;

#### **Terminal** weight

To define the terminal weight for the dynamic objective cost function the following rule is applied. If and only if the state dynamic map is linear and the dynamic objective function is quadratic, then the terminal weight is:  $v_{fin} = \frac{1}{2}(x(N) - x_s)^T P(x(N) - x_s)$  where  $P \in \mathbb{R}^{n_x \times n_x}$  is calculated through the algebraic Riccati equation. If a custom terminal weight is desired the Python function "User\_vfin(x,xs)" must be written. In any other case the terminal weight is set to "0.0".

<sup>&</sup>quot;xs, us, ys" represent the target values that come as result from the steady-state optimization.

<sup>&</sup>lt;sup>4</sup>cvodes from CasADi is used

### 3.4.5 Solver options

There is the possibility to pass some options to the used solver IPOPT.

- Sol\_itmax = *tot*: specifies the maximum *tot* number of iterations made by the solver, i.e. Sol\_itmax = 40 means 40 iterations are the maximum. Default value is set to 100.
- Sol\_Hess\_constss: means that the hessian matrix of the steady-state optimization problem is constant. To set the option on, write Sol\_Hess\_constss = True. If and only if both the model maps are linear and the steady-state problem is quadratic, the option is automatically set to True. The default value is False.
- Sol\_Hess\_constdyn: means that the hessian matrix of the dynamic optimization problem is constant. To set the option on, write Sol\_Hess\_constdyn = True. If and only if both the model maps are linear and the dynamic problem is quadratic, the option is automatically set to True. The default value is False.

## 3.5 Further options

In this section some further and useful option that can be added to the previous discussion are described. In order to activate them, you have to set them as True. These options are:

- StateFeedback: This option automatically sets the output dynamic map as:  $H_p(x, t, u) = x_p$  for the process and H(x, u) = x for the model. In this case the estimator will be set automatically to a Luenberger observer with a gain equal to the identity matrix;
- Fp\_nominal : This option automatically sets the process dynamic maps as the one defined for the model. This means:  $F_p(x, u) = F(x, u)$  and  $H_p(x, u) = H(x, u)$ ;
- QForm\_ss: This option sets that the optimization variables entering the steady-state objective function are reduced by their setpoints. It means that  $y-y_{sp}$  and  $u-u_{sp}$  are the new optimization variables considered;
- QForm: This option sets that the optimization variables entering the dynamic objective function are reduced by the steady states. It means that  $x(i) x_s$  and  $u(i) u_s$  are the new optimization variables considered;
- DUForm: This option activates the  $\Delta u(i) = u(i) u(i-1)$  variable instead of u(i) in the dynamic optimization problem even when the model is non-linear;
- DUssForm: This option activates the  $\Delta u = u u_s(k-1)$  variable instead of u in the target optimization problem even when the model is non-linear;
- TermCons : This option activates the terminal constraint on the dynamic optimization module. The constraint will be:  $x(N) = x_s$ ;
- estimating: This option activates the simulation in open loop, i.e. u = 0. When estimating = 'True' there is no need to define any of the following quantity: setpoints (§3.4.1), Target optimization module (§3.4.3), Dynamic optimization module (§3.4.4)
- ssjacid: This option activates the steady state point hunt for the model and then linearize the model evaluating the linearization matrices at the steady state point found. This tag has to be used only when you have a non linear model function, i.e.  $\dot{x} = User\_fxm\_Cont(x,u,d,t)$  or  $x = User\_fxm\_Dis(x,u,d,t)$  or/and  $y = User\_fym(x,d,t)$ .
  - When ssjacid = 'True', despite the original model functions definition, the system considered in the MPC problem, will be the one represented in §3.2.2 with linearization parameters.

The default value of all these options is False.

## 3.6 Plotting section

The variables are all plotted against the vector tsim that represents the simulation time in minutes. These variables are all available in matrix form i.e., if there are three states:  $X = [x_1, x_2, x_3]$  where  $x_i$  is the column vector that represents the behaviour of the i-th state over tsim. Here a description of all printed information:

- X\_HAT: it represents the matrix of all the estimated states;
- U: it represents the matrix of all the inputs;
- Xp: it represents the matrix of all the process states;
- Yp: it represents the matrix of all the process output;
- XS: it represents the matrix of all the target states;
- US: it represents the matrix of all the target inputs;
- YS: it represents the matrix of all the target outputs;
- D\_HAT: it represents the matrix of all the estimated model disturbances;

When estimating = 'True' the only variables displayed in plots will be X\_HAT, Xp and Y\_HAT, Yp, where Y\_HAT represents the matrix of all the model output.

Furthermore, all the plotted figures are automatically saved in the MPC\_code.py folder. To set a specific pattern or folder where to save the generated figures, just define a string variable named pathfigure. This custom path has to be defined respective to the MPC\_code.py folder, otherwise it can also be an absolute one. For example, if the chosen folder is named "Images" and it is in the same location of MPC\_code.py, pathfigure = 'C:/.../Images/'.