Application note for WiSock

14/10/2017

1/ Button:
- Use Button 2 to control relay (On /Off)
- Use Button 1 to switch between Config state and Control state
    Press and hold Button 1 for 3 seconds to switch
- Use Button 0 to reset Wisock
2/ Led:
- Led 0: dedicate the state of WiSock:
    Led On: Wifi connectted
    Led Off for 5s and on 1s: Conffiging Wifi
    Led blink: Connectting Wifi