BMP28x Digital Pressure Sensor

Bosch Sensortec





BMP28X Handling, soldering & mounting instructions

Ordering code Please contact your Bosch Sensortec representative for the ordering code

Package type 8-pin metal-lid LGA

Document version 1.7

Document release date February 17th, 2017

Document number BST-BMP28X-HS000-07

Technical reference code(s) Valid-for all BMP28x

Notes Data in this document are subject to change without notice. Product photos

and pictures are for illustration purposes only and may differ from the real

product's appearance.



Page 2

This document describes the conditions and parameters to be applied when handling, soldering and mounting the BMP28X to a PCB.

Important:

- In order to avoid any damages of the BMP28X and resultant loss of warranty please strictly keep with the instructions described within this document.
- It is also strongly recommended to study the BMP28X data sheet prior to handling the BMP28X sensor device.
- In case you have any questions, please do not hesitate to contact your nearest Bosch Sensortec representative for further advice.



Index of Contents

1.	PAC	CKAGE OUTLINE DIMENSIONS	5
1.	.1	TOP VIEW	5
1.	.2	BOTTOM VIEW	6
1.	.3	SIDE VIEW	6
2.	DEV	/ICE MARKING	7
2.	.1	MASS PRODUCTION DEVICES	7
2.	.2	ENGINEERING SAMPLES	7
3.	MOI	STURE SENSITIVITY LEVEL AND SOLDERING	8
3.	.1	MSL AND DEVICE STORAGE	8
3.	.2	MULTIPLE REFLOW SOLDERING CYCLES	8
3.	.3	CLASSIFICATION REFLOW PROFILE	8
4.	ENV	/IRONMENTAL SAFETY	10
4.	.1	ROHS COMPLIANCY	10
4.	.2	HALOGEN CONTENT	10
4.	.3	INTERNAL PACKAGE STRUCTURE	10
5.	HAN	NDLING OF REELS	11
5.	.1	STORAGE	11
5.	.2	INTRODUCTION INTO PRODUCTION	11
6.	MOU	UNTING RECOMMENDATIONS	13
6.	.1	RECOMMENDATION DETAILS	13
	6.1.1		
	6.1.2		
	6.1.3 6.1.4	F	
	6.1.5	•	
	6.1.6		
	6.1.7	9	
	6.1.8	·	
	6.1.9	9 Integration into water resistant devices	19



Page 4

7. LE	GAL DISCLAIMER	20
7.1	Engineering samples	20
7.2	PRODUCT USE	20
7.3	APPLICATION EXAMPLES AND HINTS	20
8. DC	DCUMENT HISTORY AND MODIFICATION	21




1. Package outline dimensions

The sensor housing is a standard 8-pin LGA package with metal lid with a vent hole for pressure supply. Its dimensions are 2.0 mm $(\pm 0.1 \text{ mm}) \times 2.5 \text{ mm}$ $(\pm 0.1 \text{ mm}) \times 0.95 \text{ mm}$ $(\pm 0.05 \text{ mm})$.


Note: All dimensions are in mm. If not specified otherwise, tolerances are ±0.05 mm, ±1°.

1.1 Top view






1.2 Bottom view



1.3 Side view





2. Device marking

The BMP28X device lid shows the following laser-marking:

2.1 Mass production devices

Table 1: Marking of mass production samples

Labeling	Name	Symbol	Remark
	Lot counter	CCC	3 alphanumeric digits, variable to generate mass production trace-code
CCC TL •	Product number	Т	1 alphanumeric digit, fixed to identify product type, T = "K" "K" is associated with the product
[Sub-con ID	L	1 alphanumeric digit, variable to identify sub-con (L = "A" or L = "U" or L = "P")
	Orientation marker	•	Vent hole

2.2 Engineering samples

Table 2: Marking of engineering samples

Labeling	Name	Symbol	Remark
	Eng. Sample ID	N	1 alphanumeric digit, fixed to identify engineering sample, N = " * " or "e" or "E"
XXN CC ●	Sample ID	xx	2 alphanumeric digits, variable to generate trace-code
	Counter ID	CC	2 alphanumeric digits, variable to generate trace-code
	Orientation marker	•	Vent hole



Page 8

3. Moisture sensitivity level and soldering

3.1 MSL and device storage

The BMP28X is classified as MSL 1 (moisture sensitivity level) according to IPC/JEDEC standards J-STD-020C and J-STD-033A.

The device can be soldered Pb-free with a peak temperature of 260°C for 20 to 40 sec. The minimum height of the solder after reflow shall be at least 50µm. This is required for a good mechanical decoupling between sensor device and the printed circuit board (PCB).

Note: When designing the solder paste silk print opening window, avoid excess solder paste to allow good reflow.

To ensure good solder-ability, the devices shall be stored at room temperature (20°C).

The soldering process can lead to an offset shift. The physical origin of this shift is not material aging but mechanical hysteresis frozen in by the soldering temperature cycle. Thus the shift is reversible.

Manual unsoldering can lead to further offset shift, especially if the soldering temperature and / or soldering time is above the given values of 260°C and 40 sec. Avoid contact of the device with liquids.

3.2 Multiple reflow soldering cycles

The BMP28X can withstand in total up to 3 reflow soldering cycles.

This could be a situation where a PCB is mounted with devices from both sides (i.e. 2 reflow cycles necessary) and where in the next step an additional re-work cycle could be required (1 reflow).

Multiple reflow cycles will not add up in multiple offset shifts. The device is in the same condition after every solder reflow cycle.

3.3 Classification reflow profile


The following figure describes the recommended reflow soldering process.

Vapor phase soldering has to be avoided.



Pb-Free Assembly
3° C/second max.
150 °C 200 °C 60-180 seconds
217 °C 60-150 seconds
260 °C
20-40 seconds
6 °C/second max.
8 minutes max.

Note 1: All temperatures refer to topside of the package, measured on the package body surface.





Page 10

4. Environmental safety

4.1 RoHS compliancy

The BMP28X sensor meets the requirements of the EC directive "Restriction of hazardous substances (RoHS)", see also:

"Directive 2002/95/EC of the European Parliament and of the Council of 11 September 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment".

The BMP28X is also Lead(Pb)-free and halogen-free.

4.2 Halogen content

The BMP28X is halogen-free. For more details on the analysis results please contact your Bosch Sensortec representative.

4.3 Internal package structure

Within the scope of Bosch Sensortec's ambition to improve its products and secure the mass product supply, Bosch Sensortec qualifies additional sources (e.g. 2nd source) for the LGA package of the BMP28X.

While Bosch Sensortec took care that all of the technical packages parameters are described above are 100% identical for all sources, there can be differences in the chemical content and the internal structural between the different package sources.

However, as secured by the extensive product qualification process of Bosch Sensortec, this has no impact to the usage or to the quality of the BMP28X product.



5. Handling of reels

5.1 Storage

Once the reels are removed from the pizza box, they should always be stacked in vertical condition.

5.2 Introduction into production

Reel trailers must not be removed. Removal of the trailer could cause deformation of the reel during dereeling and consequently tilted parts.



Reel trailer was removed!


Reels must be stored vertically as shown in the image below.





When Reels are to be stored horizontally, then they must be ordered in a stack with max. 4 reels pro stack (see images below).







Page 13

6. Mounting recommendations

MEMS sensors in general are high-precision measurement devices which consist of electronic as well as mechanical silicon structures. Bosch Sensortec MEMS sensor devices are designed for precision, efficiency and mechanical robustness.

However, in order to achieve best possible results for your design, the following recommendations should be taken into consideration when mounting a pressure sensor on a printed-circuit board (PCB).

6.1 Recommendation details

- Please avoid rear side handling of the BMP28X sensor, otherwise the device can be destroyed
- It is generally recommended to keep a reasonable distance between the sensor mounting location on the PCB and the critical points described in the following examples. The exact value for a "reasonable distance" depends on many customer specific variables and must therefore be determined case by case
- It is not recommended to place the sensor directly under or next to push-button contacts as this can result in mechanical stress
- It is not recommended to place the sensor close to the edge of the PCB
- It is not recommended to place the sensor in direct vicinity of extremely hot spots (e.g. a µController) as this can result in heating-up the sensor
- Do not mount the sensor too close to a PCB anchor point, where the PCB is attached to a shelf (or similar) as this could also result in mechanical stress
- Please avoid total or partial coverage of the sensor by any kind of (epoxy) resin, as this can
 possibly result in mechanical stress and could clog the hole in the sensor's top lid
- The clearance above the metal lid of the BMP28X shall be 0.1mm at minimum
- For the device housing appropriate venting needs to be provided in case the ambient pressure shall be measured



Page 14

- When operating the sensor inside a water resistant device (e.g. IPX5 or higher rated), special
 care must be taken, if a fast response to changes in ambient air pressure is needed (see
 details below)
- The pressure sensor has to be protected against all kinds of liquids, during processing (e.g. solder flux, cleaning agents) and during operation
- The BMP28X sensor is sensitive to light, which can influence the accuracy of the measurement. Therefore, the hole in the top lid shall not be exposed to direct light during operation
- The BMP28X shall not be placed close to fast heating parts. In case of temperature changes
 > 3.0°C/sec during operation. It is recommended to follow Bosch Sensortec application note
 ANP015, "Correction of errors induced by fast temperature changes". Please contact your
 Bosch Sensortec representative for details
- During handling of the BMP28X, especially in case parts are handled manually, make sure
 that no objects, like for example tweezers tips or other sharp objects do get inside of the vent
 hole of the sensor. This could damage the device
- Ultrasonic welding: ultrasonic welding can induce damage in the pressure sensor. Customer

 in case of using this process in his manufacturing line has to secure the parameter of the
 process for each project individually to protect the pressure sensor
- Vapor phase soldering: connecting BMP28X on the PCB through vapor phase soldering might cause deposits on the diaphragm which can distort the electrical signal

In case you have any questions with regard to the mounting of the sensor on your PCB, do not hesitate to contact us.


The scenarios described below – given as examples – may lead to a bending of the PCB, which as a consequence, might influence the performance of a sensor mounted on the PCB.

Please note that this possible behavior is not limited to Bosch Sensortec devices, but may as well occur with 3rd party MEMS devices in a similar manner.




6.1.1 Push-button contacts

Keep a reasonable distance to push-button contacts, when placing the sensor device. Do not position the sensor directly beneath a push-button contact.



6.1.2 Hot-spots on the PCB


Keep a reasonable distance from any hot spots, when placing the sensor device. Hot spots can be for example other integrated circuits with high power consumption.






6.1.3 PCB anchor points

Please keep a reasonable distance from any anchor points, where the PCB is fixed at a base plate (e.g. like a shelf or similar), when placing the sensor device.



6.1.4 Resin coatings

Please avoid total and partial covering of the BMP28X sensor with any protective material like for example epoxy resin.




As shown in the above figure, please take care that the sensor is not covered and not in contact with any (epoxy) resign material leading to an un-symmetric stress distribution over the sensor package.




6.1.5 Minimum distance between Sensor and PCB

The distance between the sensor and the PCB after the soldering process must be at least 50µm.



6.1.6 Underfill and cleaning materials


Please avoid all kinds of foreign materials under the sensor, e.g. underfill and cleaning materials.





6.1.7 Redundant PCB anchor points


It is recommended to unscrew or remove any redundant PCB anchor points. In theory, an ideal flat plane is determined by 3 anchor points, exclusively. Any further anchor point will over-determine the ideal flat plane criteria. If these redundant anchor points are out of plane position (which means not 100% exact in plane position) the ideal flat criteria is infringed, resulting in mechanical stress.



6.1.8 Mechanical stress maximum on the PCB

It is recommended to keep a reasonable distance from any mechanical stress maximum, when placing the sensor device. Mechanical stress can be induced for example by redundant anchor points, as described in 7.1.7.

The below given example will show a stress maximum in the center of the diagonal crossover of the 4 anchor points. It is good manufacturing praxis to always avoid or reduce the mechanical stress by optimizing the PCB design first, then to place the sensor in an appropriate low stress area.




BST-BMP28X-HS000-07 | Version 1.7 | February 2017




6.1.9 Integration into water resistant devices

When operating the sensor inside a water resistant device (e.g. IPX5 or higher rated), special care must be taken, if a fast response to changes in ambient air pressure is needed.



Typical non-optimized placement of sensor inside a water resistant device.



Visualization of potential optimizations: Dead volume reduction with confinement walls and larger port hole

Typically, in a water resistant device the port for ambient air pressure exchange is protected by a porous membrane (e.g. ePTFE), which prevents the intrusion of water into the device (see figure above). However, this also means that the air exchange might be reduced depending on the water proofness of the membrane and its airflow breathability, leading to a slower response of the pressure sensor to changes in ambient air pressure.

The following measures can be taken to mitigate this effect (see figure above):

- 1. Reduction of dead volume to reduce to amount of air needed to reach pressure equilibrium
- 2. Increase of port aperture
- 3. Careful choice of membrane to optimize trade-off between airflow and water protection

Please note that while the device is exposed to water, accurate pressure readings cannot be guaranteed.

Page 20

7. Legal disclaimer

7.1 Engineering samples

Engineering Samples are marked with an asterisk (*) or €. Samples may vary from the valid technical specifications of the product series contained in this data sheet. They are therefore not intended or fit for resale to third parties or for use in end products. Their sole purpose is internal client testing. The testing of an engineering sample may in no way replace the testing of a product series. Bosch Sensortec assumes no liability for the use of engineering samples. The Purchaser shall indemnify Bosch Sensortec from all claims arising from the use of engineering samples.

7.2 Product use

Bosch Sensortec products are developed for the consumer goods industry. They may only be used within the parameters of this product data sheet. They are not fit for use in life-sustaining or security sensitive systems. Security sensitive systems are those for which a malfunction is expected to lead to bodily harm or significant property damage. In addition, they are not fit for use in products which interact with motor vehicle systems.

The resale and/or use of products are at the purchaser's own risk and his own responsibility. The examination of fitness for the intended use is the sole responsibility of the Purchaser.

The purchaser shall indemnify Bosch Sensortec from all third party claims arising from any product use not covered by the parameters of this product data sheet or not approved by Bosch Sensortec and reimburse Bosch Sensortec for all costs in connection with such claims.

The purchaser must monitor the market for the purchased products, particularly with regard to product safety, and inform Bosch Sensortec without delay of all security relevant incidents.

7.3 Application examples and hints

With respect to any examples or hints given herein, any typical values stated herein and/or any information regarding the application of the device, Bosch Sensortec hereby disclaims any and all warranties and liabilities of any kind, including without limitation warranties of non-infringement of intellectual property rights or copyrights of any third party. The information given in this document shall in no event be regarded as a guarantee of conditions or characteristics. They are provided for illustrative purposes only and no evaluation regarding infringement of intellectual property rights or copyrights or regarding functionality, performance or error has been made.



Page 21

8. Document history and modification

Rev. No	Chapter	Description of modification/changes	Date
1.0	all	Document creation	8 Oct 2012
1.1	3	Chapter tape & reel specification removed, see document shipment packaging for details	13 Nov 2012
1.2	3	Chapter "Printed circuit board (PCB) design" removed, see datasheet for this detail	21 Nov 2012
1.3	4.1	Changed release date to 11 Sep 2011 for RoHS directive	E April 2012
1.5	5.1	Please avoid rear side handling of the BMP28X sensor, otherwise the device can be destroyed	5 April 2013
1.4 2.1 Change M		Change MP marking from A to K	20 June 2013
1.5	Page 1	Added all TRC	7 June 2016
	5	New chapter 5 was inserted: Handling of reels	24 Aug 2016
1.6	5.2	Additional pictures and comments: Handling of reels	25 Oct 2016
	all	Removed TRC, valid for all BMP28x	14 Nov 2016
1.7	6 & 6.1.9	Added waterproof comment & section	17 Feb 2017

Bosch Sensortec GmbH Gerhard-Kindler-Strasse 9 72770 Reutlingen / Germany

contact@bosch-sensortec.com www.bosch-sensortec.com

Modifications reserved | Printed in Germany Specifications subject to change without notice Document number: BST-BMP28X-HS000-07 Revision_1.7_022017