
Roman Shades

How to Install

GETTING STARTED:

Please read all instructions before attempting to install your shade. Carefully unpack your shade and check to make sure you have the following parts. If any part is missing or damaged, do not attempt to assemble or install the shade.

PARTS INCLUDED:




YOU WILL NEED THE FOLLOWING TOOLS:



OUTSIDE MOUNT OPTION:

Shades are mounted on the wall surface above opening or casing, ideal for window with little or no window depth.



- Measure the Window Frame Width and Height.
- Roman Shade Width = Window Frame Width plus 6-10 Inches Roman Shade Height = Window Frame Height plus 3-5 inches
- Outside mounted shades require extra width and height to ensure that the entire window is covered.

INSIDE MOUNT OPTION:

Provides a neater, more tailored look without hiding your decorative window frame.



- Measure the Window Inside Width and Height.
- Roman Shade Width = Window Inside Width minus 0.25 inch Roman Shade Height = Window Inside Height
- Window Depth requires at least 2 inches.

MOUNTING BRACKETS:

The Roman Shade (a) can be mounted two ways; either inside (Ceiling Mount) or Outside (Wall Mount) of your frame using the provided Brackets (b).





Headrail (e)

