

## Using JTAG And Hardware Manager

- 1. Connect JTAG Cable to Saturn.
- 2. Plug it into the PC USB.
- 3. Power up Saturn.
- 4. Run Vivado
- 5. Select Flow -> Open Hardware Manager
- 6. Vivado will report "no hardware target is open". Click Open Target & select Auto Connect


The hardware window shows the FPGA, but no serial config prom:




- 7. Right click on the FPGA xc7a200t\_0 and select Add Configuration Memory Device
- 8. Select manufacturer to **Spansion**
- 9. Select s25fl256sxxxxxx0-spi-x1\_x2\_x4




- 10. Click OK
- 11. The config prom is now shown in the hardware window



- 12. You will get an option "do you want to program the configuration memory now?" select Yes
- 13. Select the saturnprom.bin file and click OK



- 14. The config prom is programmed through the JTAG cable and the FPGA this will take 2-5 minutes
- 15. The operation is complete when this appears:



- 16. Close Vivado hardware manager
- 17. Power the board off and back on; it will boot from that file.