

Week 1: The IOS Operating System (5 Marks)

Name and Surname: Refiloe Seselinyane

Date: 31 July 2026

TASK 1:



TASK 2:

```
PC1
Physical Config Desktop Programming Attributes
Terminal
If you require further assistance please contact us by sending email to
export@ciseco.com.
cisco WS-C2960-24TT-L (PowerPC405) processor (revision B0) with 65536K bytes of memory.
Processor board ID FOC1010X104
Last reset from power-on
1 Virtual Ethernet interface
24 FastEthernet interfaces
2 Gigabit Ethernet interfaces
The password-recovery mechanism is enabled.
64K bytes of flash-simulated non-volatile configuration memory.
Base ethernet MAC Address      : 00:E0:48:F1:C9:8C
Motherboard assembly number    : 73-10390-03
Power supply part number       : 341-0097-02
Motherboard serial number      : FOC10093R12
Power supply serial number      : AZS1007032H
Model revision number          : B0
Motherboard revision number     : B0
Model number                   : WS-C2960-24TT-L
System serial number           : FOC1010X104
Top Assembly Part Number       : 800-27221-02
Top Assembly Revision Number   : A0
Version ID                     : V02
CLEI Code Number               : COM3L00BRA
Hardware Board Revision Number : 0x01

Switch Ports Model          SW Version        SW Image
-----
*  1 26 WS-C2960-24TT-L    15.0(2)SE4        C2960-LANBASEK9-M

Cisco IOS Software, C2960 Software (C2960-LANBASEK9-M), Version 15.0(2)SE4, RELEASE SOFTWARE (fc1)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2013 by Cisco Systems, Inc.
Compiled Wed 26-Jun-13 00:49 by mnnguyen

Press RETURN to get started!

Switch>?
Exec commands:
connect      Open a terminal connection
disable      Turn off privileged commands
disconnect    Disconnect an existing network connection
enable       Turn on privileged commands
exit         Exit from the EXEC
logout       Exit from the EXEC
ping         Send echo messages
resume       Resume an active network connection
show         Show running system information
ssh          Open a secure shell client connection
telnet       Open a telnet connection
terminal     Set terminal line parameters
traceroute   Trace route to destination
Switch>
```

TASK 3:

```
Switch>enable
Switch#?
Exec commands:
clear      Reset functions
clock      Manage the system clock
configure  Enter configuration mode
connect    Open a terminal connection
copy       Copy from one file to another
debug      Debugging functions (see also 'undebug')
delete     Delete a file
dir        List files on a filesystem
disable    Turn off privileged commands
disconnect Disconnect an existing network connection
enable     Turn on privileged commands
erase      Erase a filesystem
exit       Exit from the EXEC
logout     Exit from the EXEC
more       Display the contents of a file
no         Disable debugging informations
ping       Send echo messages
reload     Halt and perform a cold restart
resume     Resume an active network connection
setup      Run the SETUP command facility
show       Show running system information
--More--
```

Top

TASK 4:

```
Switch#configure
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line.  End with CNTL/Z.
Switch(config)#exit
Switch#
%SYS-5-CONFIG_I: Configured from console by console
```

TASK 5:

```
Switch#configure
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line.  End with CNTL/Z.
Switch(config)#exit
Switch#
%SYS-5-CONFIG_I: Configured from console by console

Switch#show clock
*0:26:0.567 UTC Mon Mar 1 1993
Switch#clock
% Incomplete command.
Switch#clock?
clock
Switch#clock?
clock
Switch#clock set?
set
Switch#clock set 15:00:00 ?
<1-31> Day of the month
MONTH Month of the year
Switch#show clock
*0:31:27.688 UTC Mon Mar 1 1993
Switch#
```