Project 2: The mcu91 ISA

This is not all you need to do the project, unless you're already an experienced hardware designer. **Open up the project details too... that will guide you through it.**

Instruction formats

mcu91 instructions are **20 bits long.** There are three instruction formats: R, I, and J.

- The top bit is 0 for R-type and I-type instructions, and 1 for J-type.
 - The opcode field is a different size in the two formats!
 - The "opcode" column in the tables below is **@xxxxx** for R/I-type instructions, and **1xxx** for J-type instructions.
- All three formats have an immediate, but **the immediate is different** sizes.
 - To distinguish them, they're named according to their size (imm5, and imm16).
- The rd, rs, and rt fields hold register numbers.
 - \circ So if $| \mathbf{rd} == \mathbf{4} |$, then that means $| \mathbf{r4} |$.
 - In R-type instructions, the result is written to register rd.
 - In I-type instructions, the result is written to register **rt**.

R-Type Instruction

19	18		14	13	11	10	8	7	5	4		0
0		opcode			rs		rt		rd		imm5	

I-Type Instruction

19	18	14	1 1.	3 11	10 8	8	7 0
0		opcode		rs	rt		imm8

J-Type Instruction

19	18 16	15
1	opcode	imm16

The mcu91 instruction set

- They are listed more or less in the order I recommend you try implementing them.
- The Mnemonic column shows how the instruction is written.
- The Operation column shows how the instruction works. **That's what you implement!**
- The <- means "store the value on the right into the thing on the left."
- **sxt()** and **zxt()** mean sign-extend and zero-extend. (There are components to do this in Logisim.)
- **x[4:0]** or whatever means "bits 4, 3, 2, 1, and 0 of x".
- **REG[x]** means "the register file whose number is given by x."
- RAM[x] means "the word in RAM at memory address x."

Basic instructions

lui means "load upper immediate." Just like in MIPS, this loads the immediate into the upper half of the register, and sets the lower half to 0. This is used in combination with **ori** to load a 16-bit immediate.

Format	Opcode	Mnemonic	Operation
R	000000	halt	stop CPU and turn on HALT LED
R	000001	put rs	display <- REG[rs]
I	000010	li rt, imm	REG[rt] <- zxt(imm8)
	000011	lui rt, imm	REG[rt] <- imm8 << 8

Memory access

Format	Opcode	Mnemonic	Operation
R	000100	ld rd,	REG[rd] <- RAM[REG[rs] +
	999199	ld rd, [rs+imm5]	zxt(imm5)]
		c+ [nc.immE]	RAM[REG[rs] + zxt(imm5)] <-
R	роотот		REG[rt]

When implementing these, think to yourself: do you really need another component to do the addition?;)

ALU operations

Both shr and sri should use logical right shifts.

Be careful about sign- vs. zero-extension on the I-type instructions!

Format Opcode Mnemonic Operation

Format	Opcode	Mnemonic	Operation
R	000110	add rd, rs, rt	REG[rd] <- REG[rs] + REG[rt]
R	000111	sub rd, rs, rt	REG[rd] <- REG[rs] - REG[rt]
R	001000	and rd, rs, rt	REG[rd] <- REG[rs] & REG[rt]
R	001001	or rd, rs, rt	REG[rd] <- REG[rs] REG[rt]
R	001010	not rd, rs	REG[rd] <- ~REG[rs]
R	001011	shl rd, rs, rt	REG[rd] <- REG[rs] << REG[rt] [3:0]
R	001100	shr rd, rs, rt	REG[rd] <- REG[rs] >> REG[rt] [3:0]
I	001101	adi rt, rs, imm8	REG[rt] <- REG[rs] + sxt(imm8)
1	001110	sbi rt, rs, imm8	REG[rt] <- REG[rs] - sxt(imm8)
1	001111	ani rt, rs, imm8	REG[rt] <- REG[rs] & zxt(imm8)
1	010000	ori rt, rs, imm8	REG[rt] <- REG[rs] zxt(imm8)
ı	010001	sli rt, rs, imm8	REG[rt] <- REG[rs] << imm8[3:0]
ı	010010	sri rt, rs, imm8	REG[rt] <- REG[rs] >> imm8[3:0]

Control flow

Function return addresses are not stored in registers *or* in regular data memory. There's a separate component for them! That's **STK[]** and **sp** below.

Format	Opcode	Mnemonic	Operation
ı	010011	blt rs, rt, imm8	<pre>if(REG[rs] < REG[rt]) { PC <- PC + sxt(imm8) }</pre>
ı	010100	bge rs, rt,	<pre>if(REG[rs] >= REG[rt]) { PC <- PC + sxt(imm8) }</pre>
ı	010101	beq rs, rt,	<pre>if(REG[rs] == REG[rt]) { PC <- PC + sxt(imm8) }</pre>
ı	010110	bne rs, rt,	<pre>if(REG[rs] != REG[rt]) { PC <- PC + sxt(imm8) }</pre>
ı	010111	bez rs, imm8	<pre>if(REG[rs] == 0) { PC <- PC + sxt(imm8) }</pre>

Format	Opcode	Mnemonic	Operation
I	011000	bnz rs, imm8	if(REG[rs] != 0) { PC <- PC + sxt(imm8) }
R	011001	jr rs	PC <- REG[rs]
J	1000	j imm16	PC <- imm16
J	1001	call imm16	PC <- imm16 STK[sp] <- PC + 1 sp <- sp + 1
R	011010	ret	PC <- STK[sp - 1] sp <- sp - 1

© 2016-2018 Jarrett Billingsley