


## DIS-ASSMBLY INSTRUCTIONS

- 1) REMOVE TWO SET SCREWS IN ROTATING HANDWHEEL KNOB (BOTH ARE IN THE SAME HOLE).
- 2) KNOB IS VERY TIGHT, YOU MUST CAREFULLY PRY IT LODSE WITH TWO SCREWDRIVERS, PROTECTING COVER FROM SCRATCHES.
- REMOVE FIVE SCREWS, INCLUDING THREE OUTER SCREWS BENEATH KNOB.
- 4) TO REMOVE FRONT PANEL HOLD CASE IN RIGHT HAND WITH THUMB ON TOP OF E-STOP SWITCH AND WITH LEFT HAND AROUND YELLOW KNOBS PRY TO LEFT TO EXPAND CASE AND FOLD OUT COVER

## MODIFICATION INSTRUCTIONS

- 1) REMOVE EXISTING E-STOP SWITCH AND REPLACE WITH EAWO1260 AND REPLACE WIRES ON CONTACTS 11 AND 12.
- 2) DISCONNECT YEL/BLK WIRE FROM ENABLE BUTTON AND CONNECT TO E-STOP CONTACT 21.
- 3) CUT DRN/WHT WIRE 1.5' FROM PCB CONNECTOR, SDL DER/SPLICE TO DRN WIRE AND CONNECT TO ENABLE SWITCH (ON THE OPEN SIDE OF SWITCH WHERE WIRE WAS REMOVED IN STEP 2).
- 4) DRN/WHT WIRE IS NOT CONNECTED ANYWHERE.
- 5) CUT GRN/WHT WIRE 1.5' FROM PCB CONNECTOR, AND CONNECT TO E-STOP CONTACT 22.
- 6) WIRE D-STYLE CONNECTOR AS SHOWN AND RE-ASSEMBLE.



PROPRIETARY INFORMATION
THIS DRAWING IS THE PRORERTY
OF AEROTECH, INC. AND IS
SUBMITTED IN COIN IDENCE AND
SHALL NOT BE REPRODUCED NOR
COPIED NOR DISCLOSED TO DITHERS
UNDER PENALTY OF LAW.

AEROTECH. INC. 101 Zeta Drive Pittsburgh, PA. 15238 (412)963-7470 TWX710-795-3125

TOLERANCES ON FRACTIONS DECIMALS ANGLES O TO 6 ± 1/32 .XX ± .01 ± 0-30' OVER 6 ± 1/16 .XXX ± .005 RMS FINISH

	MPG
HANDHEL	_D PENDAN <sup>-</sup>

EXCEPT
AS NOTED JFM 7/22/2009 PART CODE 620D1410 MPG CHECKED AGS JFM 7/24/2009 SCALE NTS | FILE NAME 620D1410A1.Dwg | SHEET 1 of 1