安装 Husky Simulator

```
sudo apt-get update
sudo apt-get install ros-kinetic-husky-desktop
sudo apt-get install ros-kinetic-husky-simulator
```

启动

```
roslaunch husky_gazebo husky_empty_world.launch
roslaunch husky_viz view_robot.launch
```

移动

```
rostopic pub -r 10 /cmd_vel geometry_msgs/Twist '{linear: {x: 1, y: 0, z: 0}, angular: {x: 0, y: 0, z: 0}}'

1米/秒往前走

rostopic pub -r 10 /cmd_vel geometry_msgs/Twist '{linear: {x: 0, y: 0, z: 0}, angular: {x: 0, y: 0, z: 6.28}}'

原地打转

rostopic pub -r 10 /cmd_vel geometry_msgs/Twist '{linear: {x: -1, y: 0, z: 0}, angular: {x: 0, y: 0, z: 0}}'

1米/秒往后走
```

生成图表

```
rosrun rqt_graph rqt_graph
rosrun tf view_frames
evince frames.pdf
```