# ROBUST VERSATILE AND RELIABLE





# WHY ROBOGUARD?

Wireless security provides mobility
No trenching
No ugly wiring
as well as Security Surveillance 24 hours a day,
7 days a week, 52 weeks a year.

# **Applications include:**


- Houses
- Driveways
- Carports
- Gardens
- Pools
- Caravans
- Game spotting
- Building sites
- Store rooms
- Warehouses
- Factories
- Farms
- Stables

## STAFIX SECURITY CENTRES

	Bloemfontein	051 448 6695
	Cape Town	021 534 5056
	Centurion	012 644 0201
	Durban North	031 563 0274
	East Rand (Jet Park)	011 397 3507
	East London	043 726 6652
	George	044 874 0669
	Kimberley	053 861 5631
	Nelspruit	013 752 7152
	North Rand (Kya Sands)	011 708 6442
q	Pietermaritzburg	033 342 6727
	Pinetown	031 702 6351
	Polokwane	015 292 6273
	Port Elizabeth	041 365 7178
	Pretoria	012 335 4290
	Rustenburg	014 537 2823
	Somerset West	021 851 1978
	Vanderbijl Park	082 783 8449
	West Rand (Roodepoort)	011 472 8823

www.roboguard.co.za





Enjoy peace of mind with these mechanical guards

providing a 24/7 warning system.

# **PRODUCTS**



#### Roboguard

A battery-operated, dual-sensor, outdoor movement detector designed to detect intruders and wirelessly transmit the information to a Roboguard Base station.



#### **Askari Wired Beam**

A 180 degree, 18 meter dual wired beam. Connect straight to any alarm panel.



### Portable Headquarters (HQ)

A portable 8-zone, 4-output, base-station is used to receive and announce signals from up to 8 Roboguard Sensors. The HQ can also be wired to a siren and/or an up-line alarm panel.



#### **Alarm Interface**

The Roboguard alarm interface is used to interface up to four Roboguards with individual intruder detect, tamper and status LED's.



#### Power pack

HQ interface to external devices such as a siren and/or alarm panel. A complete solution with 1.3A/h battery, 16VAC transformer, tele-cable, DC power to HQ and 5 relay out-put PCB.



#### Keypad

A 4-zone, 4-output fixed Roboguard basestation is used to interface Roboguards into an existing alarm panel. Also ideal for larger installations that require more than 8 guards.



#### Receiver

A separate receiver that provides the data stream for the Keypad and for the repeater station.



#### **Transmitter**

A Roboguard Transmitter is capable of transmitting roboguard intruder and roboguard remote alarms in response to triggering from externally connected systems.



## **Keyfob Transmitter**

A handheld remote transmitter is used as a panic button and remote control for radio base-stations. 4-button and 6-button versions are available.



Roboguard uses state-of-the-art equipment and technology.

The entire system is wireless and simple to install and move.


The HQ monitors for tampering with the sensors, as well as battery levels.

The HQ can be connected to a siren or to any existing alarm panel and can be armed/disarmed by remote control.

The Roboguard sensor is weather proof, tamper proof, robust and impervious to lightning and ultra-violet light damage.

The Roboguard sensor can be positioned up to 400 meters from the HQ (and up to 800 meters with a booster).

The Roboguard will detect movement up to 20 meters away and has a detection arc of 110.



Forewarned is forearmed!

Peace of mind, wherever you need it



Temporary or

permanent

asset protection

Robust versatile and reliable

