

Once you have a nice decaying sinusoid, push the soft key to the right of the display to set Mode $\rightarrow$ Track. Now push the soft key to the right of the display to set Mode $\rightarrow$ Track. Now push the soft key to the right of the display to set Mode $\rightarrow$ Track. Note the similar circle-arrow that is lit up on the right side of the o-scope. Turn this knob and the cursor should track the waveform. The values of voltage and time should be displayed on the screen. Use the cursor to find the peak and trough values and the times at which they occur. This is the data that fills in Table 1.

W/out box				Main Lab				Box w stuff			
Mass	frequency	VPP	Amplitude	mass	frequency	VPP	Amplitude	mass	frequency	VPP	Amplitude
0g	40.4	1.33	10	0g	87	1.47	10	0g	84.1	1.15	10
5g	37.7	0.599	4	5g	81.7	0.292	2	5g	79.1	0.290	2
10g	35.7	0.536	4	10g	77	0.276	2	10g	73.1	0.232	2
15g	33.7	0.528	4	15g	72.2	0.268	2	15g	69.1	0.220	2
20g	32.3	0.524	4	20g	68.7	0.258	2	20g	66.4	0.220	2
25g	31.0	0.520	4	25g	65.7	0.252	2	25g	64.0	0.218	2
30g	29.7	0.512	4	30g	63.7	0.239	2	30g	61.4	0.208	2

fres = 40.4 Hz

Me Resistance

n	t_n (s)	V_n (V)	$\ln(V_n)$ (V)	n	t_n (s)	V_n (V)	$\ln(V_n)$
0.0	$1.6 \cdot 10^{-3}$	-0.276 V	-1.29 V	3.0	$78.1 \cdot 10^{-3}$	-0.056 V	-2.88 V
0.5	$14.5 \cdot 10^{-3}$	0.184 V	-1.69 V	3.5	$90.8 \cdot 10^{-3}$	0.036 V	-3.32 V
1.0	$27.2 \cdot 10^{-3}$	-0.164 V	-1.81 V	4.0	$103.0 \cdot 10^{-3}$	-0.032 V	-3.44 V
1.5	$40.0 \cdot 10^{-3}$	0.108 V	-2.23 V	4.5	10^2	0.	
2.0	$52.7 \cdot 10^{-3}$	-0.095 V	-2.34 V	5.0			
2.5	$65.4 \cdot 10^{-3}$	0.060 V	-2.81 V				