

PETROL TOOL – 5 POINT WARRANTY PHYSICAL CHECK

Complete this physical inspection prior to booking any petrol unit under warranty.

1. FUEL

- Smell fuel – fresh fuel has a clean petrol smell.
- Varnish or sour smell indicates stale fuel.
- Check for water contamination or discolouration.

2. OIL (4-STROKE ONLY)

- Check oil level is within operating range.
- Inspect colour – dark black or metallic glitter may indicate wear.
- Smell for fuel contamination in oil.

3. AIR FILTER

- Remove and inspect filter element.
- Check for excessive dirt, oil saturation, or damage.
- Confirm filter is correctly fitted.

4. CONDITION

- Check for impact damage or cracked housings.
- Inspect fuel lines and primer bulb condition.
- Confirm recoil starter operates smoothly.
- Look for signs of misuse or modification.

5. MISCELLANEOUS

- Check spark plug condition if accessible.
- Confirm no unauthorised adjustments have been made.
- Verify unit is within warranty period.

If evidence of stale fuel, incorrect oil level, contamination, neglect, or misuse is found, advise customer prior to warranty submission.