

# DECKLE DUPLEX CALIBRATION SHEET

LANDSCAPE -- the printed half of the calibration wizard. Do not print this page in either pass.

## WHAT THIS IS

Deckle prints two-sided books by printing every front, asking you to turn the stack over, and printing every back. Four things decide whether the backs land on the right fronts the right way up, and no printer driver reports any of them. This sheet finds them out by having you look at paper.

Nothing in this file is imposed: the pages come out in plain order, so what you report is evidence about your printer and not a check of Deckle against itself.

## HOW TO PRINT IT

1. Print pages 2-5 of this file at 100%. Turn OFF "fit to page" and any "scale to fit" or "shrink oversized pages" option.
2. Take the stack out of the output tray. Do NOT reorder or rotate it.
3. Turn the stack over the way you would to print its other side, and put it back in the paper tray.
4. Print pages 6-9 of this file, same settings.

You now have four double-sided sheets.

## WHAT TO WRITE DOWN

Answer what you SEE. Do not correct anything, and do not reprint to tidy it up -- a wrong-looking result is the result.

- A. After step 1, the printed side of the sheets in the output tray faced  
**UP / DOWN** -> **output\_face**
- B. The edge of the paper that went into the printer first was the sheet's  
**TOP / BOTTOM edge** -> **feed\_edge**
- C. After step 1, the sheet lying on TOP of the output stack was number  
**1 2 3 4** -> **reverse\_stack**
- D. On each finished sheet, the BACK number that landed on it:  
**front 1 -> back** \_\_\_\_\_ **front 2 -> back** \_\_\_\_\_  
**front 3 -> back** \_\_\_\_\_ **front 4 -> back** \_\_\_\_\_ -> **reverse\_stack**
- E. Hold a finished sheet so its FRONT reads upright, with the solid black band along the top. Now turn it over left-to-right, like a page in a book.  
On the BACK, the solid black band lies along the  
**TOP / BOTTOM edge**  
and the big triangle points  
**UP / DOWN** -> **flip\_axis**
- F. Hold sheet 1 up to a bright light so both crosses show through. The BACK


**TOP EDGE**



SHEET

**1**

**LEFT**



**RIGHT**

**FRONT**

PASS 1 = pages 2-5 of this file. Then turn the stack over and print pages 6-9.

Full instructions and the grid to fill in are on page 1.

Record what you see. Do not reprint to tidy up the result.

sheet 1 front

**BOTTOM EDGE**


**TOP EDGE**



SHEET

**2**

**LEFT**



**RIGHT**

**FRONT**

sheet 2 front


**BOTTOM EDGE**

TOP EDGE



SHEET

3



LEFT

RIGHT

FRONT

sheet 3 front


BOTTOM EDGE

TOP EDGE



SHEET

4



LEFT

RIGHT

FRONT

sheet 4 front

BOTTOM EDGE


**TOP EDGE**



SHEET

**1**

**LEFT**



**RIGHT**

**BACK**

sheet 1 back


**BOTTOM EDGE**

**TOP EDGE**



SHEET

**2**



**LEFT**

**RIGHT**

**BACK**

sheet 2 back


**BOTTOM EDGE**

**TOP EDGE**



SHEET

**3**



**LEFT**

**RIGHT**

**BACK**

sheet 3 back

**BOTTOM EDGE**




**TOP EDGE**



SHEET

**4**



**LEFT**

**RIGHT**

**BACK**

sheet 4 back

**BOTTOM EDGE**