Lecture 16: Wireless Networking

Outline

- Wireless physical layer challenges
 - Signal, noise, modulation
 - A little bit of EE goes a long way
- Wireless link layers
 - Hidden terminals, exposed terminals
 - CSMA/CA
 - RTS/CTS
- Wireless routing and throughput

Ethernet: 802.3

- Dominant wired LAN technology
 - 10BASE5 (vampire taps)
 - 10BASE-T, 100BASE-TX, 1000BASE-T

• Frame format:

Phys	Link			Layer 3	Link		
Preamble	SFD	Src	Dest	Type/ Len	Payload	CRC	Gap 96 ns,
7 x 10101010	10101011	6 bytes	6 bytes	2 bytes	46-1500 bytes	4 bytes	960 ns, 9600 ns

Physical Layer (Layer 1)

• Responsible for specifying the physical medium

- Category 5 cable (Cat5): 8 wires, twisted pair, RJ45 jack
- WiFi wireless: 2.4GHz

Responsible for specifying the signal

- 100BASE-T: 5-level pulse amplitude modulation (PAM-5)
- 802.11b: Binary and quadrature phase shift keying (BPSK/QPSK)

Responsible for specifying the bits

- 100BASE-T: 4-to-6 bit-to-chip encoding, 3 chip symbols
- 802.11b: Barker code (1-2Mbps), complementary code keying (5.5-11Mbps)


Wireless is Different

- Variable: signal attenuates over space
- Interference: other RF sources can interfere with signal
- Multipath: signal can self-interfere
- Distributed: nodes cannot detect collisions
- To address these differences, wireless link layers use slightly different mechanisms
- Also, can't just abstract away the physical and link layers: need a brief introduction to underlying EE


Attenuation Over Space

- Signal weakens as distance from transmitter increases
- Reflections, obstructions, etc. complicate the attenuation
- Depending on the antenna, not uniform in all directions
- Much more complex than the wired model

Signal Strength Over Space




Directional Antennas




Interference

- In unlicensed bands (e.g., 802.11), there are lots of transmitters
 - 802.11 cards
 - 802.15.1 (Bluetooth)
 - 802.15.4 (ZigBee)
 - 2.4GHz phones
 - Microwave ovens
- This interference can be stronger or weaker than the signal, and can prevent successful reception


Analog Signals



Specifying the Signal: Modulation





Modulation, Continued




I/Q Modulation

- I: in-phase, Q: quadrature
- Sum of two sines is a sine
- Show what the carrier looks like compared to a simple, unmodulated signal
- Use I/Q because this is how it's actually done in hardware






Modulation in I/Q Plots




Example measurements from 16-QAM



Signal, Noise, and Interference

- Signal: energy of desired transmission
- Noise/Noise floor: energy of hardware thermal effects
- Interference: energy of other transmitters
- Usually measured in dBm/dBW: 0dBm = 1mW,
 0dBW = 30dBm = 1W
 - Note dB is a logarithmic scale: 10dBm = 10mW, 20dBm = 100mW

Signal Plus Noise




SINR

- Signal to Interference-and-Noise Ratio
- Measured in dB: $\frac{|S|}{|N+I|}$
 - S = -50 dBm, N+I = -95 dBm, SINR = 35 dB
 - S = -89 dBm, N+I = -93 dBm, SINR = 4 dB
- SINR is particularly critical in wireless because of attenuation over space

Bit Error Rates

- There is a theoretical limit on how much information a channel can carry (Shannon limit)
- Bit error rate depends on the SINR and the modulation
- This is why wireless link layers use more complex chip/bit encoding
 - If signal is strong (high SINR), have few chip errors, can use low encoding
 - If signal is weak (low SINR), have many chip errors, use higher encoding to recover from errors


Example Theoretical Bit Error Rates



Variable Bit Rates

- 802.11b supports 1, 2, 5.5, and 11Mbps
- 2, 5.5Mbps and 11Mbps are QPSK
- To support this, the signal field says what the data rate is
 - 00001010: 1Mbps (11 chips/bit, barker code)
 - 00010100: 2Mbps (11 chips/bit, barker code)
 - 00110111: 5.5Mbps (2 chips/bit, CCK)
 - 01101110: 11Mbps (1 chip/bit, CCK)
- So the header is still at 1Mbps, even if the data is at 11Mbps

Collisions are not so simple




- If A transmits first, B can still decode its packet
- If C transmits first, A will corrupt its packet and B can't decode C's packet
- What if AB and BC are both -60dB?
- Signal strength matters: this is the RF capture effect

802.11 Packet Loss Rates



802.11 Packet Loss Rates (at 11Mbps)



• How does this affect TCP?

Wireless PHY Summary

- Can't control or limit the channel
- Need to deal with weak signals, interference, etc.
- Signal strength affects collisions
- Many different kinds of modulation: amplitude, frequency, phase
- Use robust encodings when needed, use fast speeds when possible
- Lots of intermediate packet delivery ratios

2 minute break



MAC Layer Responsibilities


- Arbitrate control of the channel
- One node should be able to use 100%
- Multiple nodes should get a fair share
- Want high utilization under contention

CA versus CD

- Collision detect (CD) is hard in wireless
- Local signal is much stronger than anything received
- Protocols use collision avoidance (CA) by sensing the channel


Simple MAC: CSMA/CA

- 1) Wait a small random period, check the channel
- 2) If the channel is busy, go to 1 (maybe longer wait)
- 3) Transmit packet



802.11b MAC: CSMA/CA


- \bullet Maintain a waiting counter c
- For each time step channel is idle, c -
- When c = 0, transmit
- If packet is not acknowledged (layer 2), pick a new, larger \boldsymbol{c}
 - Use lack of layer 2 ack as collision detect



Problems with CSMA/CA


- Want to know state of channel at receiver, not transmitter
- But wireless is not transitive!
 - A hears B
 - A hears C
 - B and C may not hear each other
 - B and C can only sense their channel, but need to know if A's channel is clear

Hidden Terminal Problem



- B and C can't hear each other, A can hear both
- B and C sense a clear channel, transmit, and collide at A
- B is a hidden terminal to C, and C is a hidden terminal to B

Exposed Terminal Problem




- A transmits to B
- C hears the transmission, backs off, even if it wants to transmit to D
- C is an exposed terminal to A's transmission


RTS/CTS

- Request-to-send, Clear-to-send (RTS/CTS)
- Allows transmitter to check availability of channel at receiver
- Transmitter sends an RTS
- If it hears a CTS, sends data
- If not, retries RTS some time later
- If you hear a CTS for someone else, don't transmit


RTS



CTS



Data






Network Allocation Vector (NAV)

- 802.11b supports RTS/CTS
- NAV is data structure node uses to know when channel may be clear
- NAV is in terms of *time*: variable bit rates, RTS, etc.

RTS/CTS Benefits

- Solves the hidden terminal problem (assuming CTS not corrupted)
 - In practice, not true: a node's CTS can collide with another node's RTS
 - In practice, can reduce but not solve the hidden terminal problem on data
 - Control packets still collide
- Improves data packet delivery ratio
- Does it solve the exposed terminal problem? What about ACKs?



RTS/CTS Drawbacks

- 3 packets per packet: RTS/CTS/DATA
- RTS still go through CSMA: they can be lost
- CTS losses cause lengthy retries
- 33% of IP packets are TCP ACKs: is it worth it?
- In practice, WiFi doesn't use RTS/CTS


Wireless Routing

- Network is much more dynamic
- Not constrained by physical topology
- Discovering and estimating links to neighbors
- Discovering and maintaining routes to nodes
- Rich area of study: we'll just touch on link cost

Hopcount Considered Harmful


- Minimizing hopcount causes protocol to choose long links
- Links are more likely to be on edge of SNR/PRR curve
 - Less stable
 - Require more maintenance
- One way wireless routing is different
- OLSRv2 adds the concept of link metrics

DSDV and Hopcount on Roofnet



• From DeCouto et al., "A High-Throughput Path Metric for Multi-Hop Wireless Routing."

Variations Across Hopcounts




• From DeCouto et al., "A High-Throughput Path Metric for Multi-Hop Wireless Routing."

Expected Transmissions (ETX)

- Proposed by DeCouto et al.
- Alternative metric: ETX, number of transmissions until you receive an ACK
- Cost of link is $\frac{1}{PRR_{AB} \cdot ARR_{BA}}$
 - $PRR_{AB} = 75\%$, $ARR_{BA} = 66\%$, $ETX_{AB} = 2.0$
 - $PRR_{AB} = 50\%$, $ARR_{BA} = 50\%$, $ETX_{AB} = 4.0$
- Cost of route is sum of ETX values of links on route

ETX Benefits



• From DeCouto et al., "A High-Throughput Path Metric for Multi-Hop Wireless Routing."

ETX Is Not Enough


- 802.11b supports four different bit rates
- ETX can select the route, but not the bitrate
- One packet at 11Mbps \neq one packet at 1Mbps
- Solution: Estimated Time of Transmission (ETT)
 - Probe at different bit rates
 - Choose link bit rate based on minimum cost

Link Metrics Today

- Rough consensus that ETX/ETT is the right metric
 - Addresses intermediate links
 - Can be used across link layers
- No consensus on how to estimate the value
 - Several proposals
 - Still an active area of research
- Issue: conflates hopcount and link quality, making loops very easy ($100\% \rightarrow 33\%$ can look like 2 more hops)
- Issue: minimizes delay, does not maximize throughput

Throughput Dropoff

- Only every third node can transmit, or you get the hidden terminal problem
- In TCP, data and ack packets cause the hidden terminal problem



Wireless Routing

- Maintaining consistent, distributed state on a dynamic system
- Preventing loops via serialization or source routing
- On-demand versus continuous
- ETX/ETT better metric than hopcount