

### How prevalent is NUMA?


- All major vendors
  - HP, Dell, IBM, Cisco, SuperMicro, Hitachi, etc.
- As small as 1U
- ▶ 2, 4, and 8 socket systems
- ▶ 2 to 10 cores per socket
- Number of cores doubles with HyperThreading
   8 x 10 x 2 = 160 CPU cores

NUMA is mainstream.


### Why use large NUMA servers?

- NUMA is key to the current evolution of performance
  - Storage rates are drastically increasing
  - Processor speeds are stagnant
  - Multi-core cannot scale infinitely without NUMA
- NUMA meets the needs of the application
  - No partitioning is required
  - Faster than clustering multiple servers
  - Works well in combination with scale out

# Nodes, Sockets, Cores, Threads




### **Non-Uniform I/O Access**





I/O = PCle

- Internal flash
- Host bus adapter to storage network

## 2, 4, and 8 Socket Servers








```
# numactl --hardware
     10
         12
             17
                17
                     19
                        19
                            19
                                19
     12
         10
             17
                 17
                     19
                        19
                        19
         17
             10
                12
                    19
                            19
         17
             12
                10
                    19
                        19
                            19
         19
             19 19 10 12
             19
                        10
                19
                    12
             19
                 19
                    17
             19
                 19
                        17
                    17
```

# **Enterprise Storage**





Storage

Database Servers


Clients


### **PCIe Local Nodes**





### PCIe Local Nodex







# cat /sys/devices/pci0000:50/0000:50:09.0/numa\_node
0

Only one local node is presented to the OS

### **PCIe Local Node?**






# cat /sys/devices/pci0000:50/0000:50:09.0/numa\_node
-1


Not detected? Update the BIOS.

## **Localizing I/O from Storage**




► 50-100% performance improvement vs. non-NUMA aware volume placement

# **Localizing I/O – High Availability**



Node locality of volumes must still be maintained


# **Localizing I/O – HA Failover**



- Node locality maintained
- All available ports are still used

## **Localizing I/O – Components**

- HBA placement
- Interrupt affinity
- Kernel thread affinity
- Application affinity




Analyze everything in the data path.

Localize all components to the HBA local nodes.

Reduces latency and improves caching

## **Discovering Device Locality**


- Devices associated with each volume
  - multipath -ll
  - ls -d /sys/bus/pci/devices/\*/host\*
- Device location
  - dmidecode -t slot
  - lspci -tv
- NUMA node of devices
  - /sys/devices/pci\*/\*/numa\_node



### **Pinning Interrupts**

- Pin IRQs to the local node
- Distribute IRQs between cores in the local node

```
# grep [driver] /proc/interrupts
[num]: ...
# cat /proc/irq/[num]/node
[node]
```



# echo [CPU mask] > /proc/irq/[num]/smp\_affinity

~100% improvement

Reduces latency & CPU contention, improves caching

### **Persistently Pinning Interrupts**

- irqbalance: run-time load balancing
  - Mixed results
  - Better with RHEL 6.4 + kernel update + Sandy Bridge
- Customized init service to set affinity on boot
  - Best results for a known application

# **Driver Kernel Thread Affinity**

- Sometimes handled by Linux drivers
- Verify and adjust

```
# taskset -p -c [cpumask] [pid]
pid [pid]'s current affinity list: 0-159
pid [pid]'s new affinity list: 20-29
```

### **Block Device Tuning**

- # echo noop > /sys/block/[device]/queue/scheduler
  - 10% improvement
- # echo 0 > /sys/block/[device]/queue/add\_random
  - 10% improvement
- # echo 2 > /sys/block/[device]/queue/rq\_affinity
  - 5% improvement
- # echo [0 or 1] > /sys/block/[device]/queue/rotational
  - Mixed results

#### Reduces latency and CPU utilization

### Persistent Block Device Tuning

- udev rules (/etc/udev/rules.d/)
  - I/O devices

ACTION=="add|change", SUBSYSTEM=="block", ATTR{device/vendor}=="FUSIONIO", ATTR{queue/scheduler} = "noop", ATTR{queue/rq\_affinity}="2", ATTR{queue/add\_random}="0"

devices with I/O slave devices (DM multipath)

ACTION=="add|change", KERNEL=="dm-\*", PROGRAM="/bin/bash -c 'cat /sys/block/\$name/slaves/\*/device/vendor | grep FUSIONIO'", ATTR{queue/scheduler}="noop", ATTR{queue/rq\_affinity}="2", ATTR{queue/add random}="0"

Note: udev rules may only rely on sysfs parameters that are available at the time the device is created.

## **Power/Performance Tuning**

- Disable c-states in the BIOS
- Disable c-states in the boot loader (grub)
  - intel\_idle.max\_cstate=0
  - processor.max\_cstate=0
- ▶ 10% improvement

Keeping processors in active states reduces latency


## **Application Tuning**

- OS-provided tools
  - taskset
  - cgroups
  - numad
- Application-specific settings
  - Oracle
    - \_enable\_NUMA\_support

## **Benchmarking Performance**

- Test thread affinity
  - FIO
    - cpus\_allowed
    - numa\_cpu\_nodes
    - numa\_mem\_policy
  - Oracle Orion and others
    - taskset -c [cpulist] [test command]
- Measuring performance
  - iostat
  - Application-specific

## **8 Socket Total Performance Gains**



# **Tools for NUMA Tuning**

numactl cgroups

taskset Istopo

dmidecode sysfs

irqbalance numad

top numatop

htop tuna

irqstat tuned-adm

### top: terminal is not big enough


```
root@RHEL980:~
                                               root@RHEL980:~
                                                                   ssh ...
top - 13:31:23 up 1 day, 5:17, 2 users, load average: 3.66, 0.96, 0.42
Tasks: 3897 total, 1 running, 3896 sleeping,
                                                  0 stopped.
Cpu(s): 0.2%us, 1.4%sy, 0.0%ni, 95.7%id, 0.5%wa, 0.0%hi, 2.2%si,
Mem: 264521876k total, 118689448k used, 145832428k free,
                                                             243928k buffers
Swap: 20971504k total.
                              0k used, 20971504k free, 2139856k cached
Sorry, terminal is not big enough
  PID USER
                     NI VIRT
                               RES
                                                        TIME+ COMMAND
124807 root
                         824m
                                                        1:47.06 fio
                 20
                               59m
                                    48m S 583.5
    89 root
                 20
                                                       0:46.11 ksoftirgd/21
                                            5.1
                                                 0.0
    85 root
                 20
                                                 0.0
                                                       0:36.00 ksoftirgd/20
   405 root
                 20
                                                 0.0
                                                       0:37.30 ksoftirgd/100
   421 root
                 20
                                                       0:12.97 ksoftirqd/104
                 20
                        17964
                              4232
124743 root
                                                       0:02.39 top
   121 root
                 20
                                                       0:10.04 ksoftirgd/29
                                                       0:10.26 ksoftirgd/109
   441 root
                 20
   101 root
                 20
                                           2.2
                                                 0.0
                                                       0:13.09 ksoftirgd/24
                 20
   113 root
                                                       0:16.79 ksoftirgd/27
 10953 oracle
                 20
                      0 1388m 135m 114m S
                                                      24:00.31 oracle
   409 root
                 20
                                           1.0
                                                 0.0
                                                       0:12.80 ksoftirgd/101
   413 root
                                                       0:24.10 ksoftirgd/102
   425 root
                 20
                                                       0:05.92 ksoftirgd/105
   437 root
                 20
                                                       0:08.67 ksoftirgd/108
                 -2
 10945 oracle
                        1365m
                               14m
                                                       6:36.87 oracle
    97 root
                 20
                                                       0:31.75 ksoftirgd/23
                 20
   117 root
                                                 0.0
                                                       0:08.93 ksoftirad/28
```

(top in RHEL 6.4)

# mpstat with 160 cores

								0.0
rc	ot@RI	HEL980:~		root	@RHEL980:~	ssh		
[root@RHEL98 Linux 2.6.32				t.fusionio.	com) 04/13	/2013	_x86_64_	(16
01:57:00 PM 01:57:00 PM								
01:57:00 PM	CPU	0/s	1/s	3/s	4/s	8/s	9/s	12
01:57:00 PM 103/s		104/s	105/s	106/s	107/s	108/s	109/s	110/s
120/s								
s 138/s MIS/s		139/s	140/s	141/s	NMI/s	LOC/s	SPU/s	PMI/s
01:57:00 PM	0	0.01	0.00	0.00	0.00	0.00	0.00	0.
0.01		0.08	0.00	0.00	0.01	0.00	0.01	0.00
0.00	0.00	0.00	0.00	0.00	0.00	0.92	0.22	. 0
0.00		0.00	0.00	0.00	0.01	19.33	0.00	0.01
0.00								
01:57:00 PM	1	0.00	0.00	0.00	0.00	0.00	0.00	0.
0.00		0.00	0.00	0.00 1	31.68	0.00	0.00	0.00
0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0
0 0.00		0.00	0.00	0.00	0.02	15.82	0.00	0.02
0.00								
01:57:00 PM	2	0.00	0.00	0.00	0.00	0.00	0.00	0.
0.00		0.00	0.00	0.00	0.00	0.00	0.00	0.00
0.00								
0 0.00		0.00	0.00	0.00	0.01	4.17	0.00	0.01

# /proc/interrupts with 160 cores



### top: added NUMA support

```
root@RHEL980:~
                                           root@RHEL980:~
                                                             ssh ...
lt-top - 13:32:31 up 1 day, 5:18, 2 users,
                                          load average: 10.55, 3.58, 1.36
Tasks: 3898 total,
                   1 running, 3897 sleeping,
                                             0 stopped,
%Cpu(s): 0.2 us, 1.3 sy, 0.0 ni, 95.7 id, 0.6 wa, 0.0 hi, 2.2 si, 0.0 st
%Node0: 0.6 us, 4.4 sy, 0.0 ni, 82.7 id, 3.6 wa, 0.0 hi, 8.7 si,
%Node1: 0.1 us, 0.1 sy, 0.0 ni, 99.8 id,
                                          0.0 wa, 0.0 hi, 0.0 si,
%Node2: 0.8 us, 5.9 sy, 0.0 ni, 82.2 id, 1.2 wa, 0.0 hi, 10.0 si,
                                          0.0 wa, 0.0 hi, 0.0 si,
%Node3: 0.0 us, 0.0 sy, 0.0 ni,100.0 id,
%Node4: 0.0 us, 0.0 sy, 0.0 ni,100.0 id,
                                          0.0 wa, 0.0 hi,
%Node5 : 0.0 us, 0.0 sy, 0.0 ni,100.0 id, 0.0 wa, 0.0 hi, 0.0 si,
%Node6 : 0.0 us, 0.0 sy, 0.0 ni,100.0 id, 0.0 wa, 0.0 hi, 0.0 si, 0.0 st
%Node7 : 0.0 us, 0.0 sy, 0.0 ni,100.0 id, 0.0 wa, 0.0 hi, 0.0 si, 0.0 st
KiB Mem: 26452187+total, 11869251+used, 14582937+free, 243976 buffers
KiB Swap: 20971504 total,
                              0 used, 20971504 free, 2140132 cached
```

PID	USER	PR	NI	VIRT	RES	SHR	S	%CPU	%MEM	TIME+	COMMAND
124807	root	20	0	843984	60460	50076	S	578.6	0.023	8:37.67	fio
89	root	20	0	0	0	0	S	6.097	0.000	0:48.85	ksoftirqd/21
93	root	20	0	0	0	0	S	5.776	0.000	0:25.55	ksoftirqd/22
413	root	20	0	0	0	0	S	4.172	0.000	0:25.72	ksoftirqd/102
97	root	20	0	0	0	0	S	3.851	0.000	0:33.76	ksoftirqd/23
124881	root	20	0	117652	4820	1136	R	3.851	0.002	0:01.37	lt-top
105	root	20	0	0	0	0	S	2.888	0.000	0:18.82	ksoftirqd/25
405	root	20	0	0	0	0	S	2.567	0.000	0:39.12	ksoftirqd/100
425	root	20	0	0	0	0	S	2.567	0.000	0:06.28	ksoftirqd/105
85	root	20	0	0	0	0	S	2.246	0.000	0:37.75	ksoftirqd/20

https://gitorious.org/procps/procps

# irqstat: IRQ viewer for NUMA

root@RHEL980:~/numatools					root@RHEL980:~ ssh					
IRQs	/ 5 sec	ond(s)								
IRQ#	TOTAL	NODE0	NODE1	NODE2	NODE3	NODE4	NODE5	NODE6	NODE7	NAME
125	361145	0	0	361145	0	0	0	0	0	PCI-MSI-edge qla2xxx
123	356357	0	0	356357	0	0	0	0	0	PCI-MSI-edge qla2xxx
109	46118	46118	0	0	0	0	0	0	0	PCI-MSI-edge lpfc:fp
111	46085	46085	0	0	0	0	0	0	0	PCI-MSI-edge lpfc:fp
115	44369	0	0	44369	0	0	0	0	0	PCI-MSI-edge lpfc:fp
117	43951	0	0	43951	0	0	0	0	0	PCI-MSI-edge lpfc:fp
107	37149	37149	0	0	0	0	0	0	0	PCI-MSI-edge lpfc:fp
113	36305	36305	0	0	0	0	0	0	0	PCI-MSI-edge lpfc:fp
126	11	11	0	0	0	0	0	0	0	PCI-MSI-edge eth0[0]
129	5	5	0	0	0	0	0	0	0	PCI-MSI-edge eth0[3]

https://github.com/lanceshelton/irqstat

### Must end users be NUMA-aware?

- Unfortunately, yes.
  - Users must be aware of PCIe device slot placement
  - Optimal NUMA tuning is not yet performed by the OS
  - Persistent tuning is a non-trivial task
  - Performance challenges are changing faster than tools

### How can this be improved?

- NUMA architectures must be detected properly and tuned by default
  - Phase out Nehalem or add SLIT support for multiple local nodes
- Linux distributions need to provide optimal tuning across applications and devices at the OS level
- Improve existing tools

#### What's next?

- More cores per socket
  - 15 core CPUs by the end of next year?
- Removal of existing bottlenecks
  - Multi-queue block layer: <a href="http://kernel.dk/blk-mq.pdf">http://kernel.dk/blk-mq.pdf</a>
- Improved tools
  - numatop: <a href="https://01.org/numatop">https://01.org/numatop</a>
  - top: <a href="https://gitorious.org/procps/procps">https://gitorious.org/procps/procps</a>
  - irqstat: <a href="https://github.com/lanceshelton/irqstat">https://github.com/lanceshelton/irqstat</a>

#### References

- ► HP DL980 Architecture
  - http://h20195.www2.hp.com/V2/GetPDF.aspx/4AA3-0643ENW.pdf
- ► HP NUMA Support
  - http://bizsupport1.austin.hp.com/bc/docs/support/SupportManual/ c03261871/c03261871.pdf
- Performance profiling methods
  - http://dtrace.org/blogs/brendan/2012/03/07/the-use-method-linuxperformance-checklist/

