
END COVER INSPECTION

id051700663400

Radial Needle Bearing Inspection

1. Rotate the radial needle bearing shown in the figure by hand and verify that there is no malfunction in the radial needle bearing (rotation sticking).
   - If there is a malfunction, replace the end cover with a new one.



bcw6ja00000154