




0112-201
FAN CONTROL MODULE



Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.


MAIN FUSE
(REFER TO 00F SECTION)
F-03
RELAY AND FUSE BLOCK
(REFER TO 00F SECTION)
F-01
G03
0112-201
FAN CONTROL MODULE
[BLACK]
: FRONT HARNESS
: ENGINE No.2 HARNESS
: EMISSION HARNESS