




0114-201
FUEL WARMER



Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.


G20
0114-201
FUEL WARMER
[LIGHT GRAY]
MAIN FUSE
(REFER TO 00F SECTION)
F-03
RELAY AND FUSE BLOCK
(REFER TO 00F SECTION)
F-01
(F)-(R)
C-05
: FRONT HARNESS
: ENGINE No.2 HARNESS
: REAR HARNESS
: REAR No.2 HARNESS
: EMISSION HARNESS
: DOOR HARNESS
: INTERIOR LIGHT HARNESS
INTERIOR LIGHT No.2 HARNESS