




0140-108
A/F SENSOR




0140-109
KNOCK SENSOR




(SKYACTIV-G 1.5 (WITH 4-2-1 EXHAUST SYSTEM))

(SKYACTIV-G 1.3, 1.5 (WITH 4-1 EXHAUST SYSTEM))


0140-110
THROTTLE BODY




0140-113
ACCELERATOR PEDAL POSITION SENSOR




0140-128
NEUTRAL SWITCH No.1




0918-701
BRAKE SWITCH




0140-129
CLUTCH PEDAL POSITION SWITCH




0940-103B
START STOP UNIT



0940-103A
START STOP UNIT



Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.


[DARK GRAY]
A/F SENSOR
0140-108
G10
[BLACK]
PCM
0140-101A
[BLACK]
PCM
0140-101B
JOINT CONNECTOR
C-57
[BLACK]
THROTTLE BODY
0140-110
0140-109
KNOCK SENSOR
[LIGHT GRAY] ← WITH 4-2-1 EXHAUST SYSTEM
[GRAY] ← WITH 4-1 EXHAUST SYSTEM
0140-128
NEUTRAL SWITCH No.1
[DARK GRAY]
[GRAY]
(F)-(I)
C-04
(F)-(R)
C-05
CLUTCH PEDAL POSITION SWITCH
0140-129
(R)-SHORT CORD
C-22
BRAKE SWITCH
0918-701
G18
0140-113
ACCELERATOR PEDAL
POSITION SENSOR
[BLACK]
[GRAY]
(F)-(I)
C-04
0940-103B
START STOP UNIT
0940-103A
START STOP UNIT
: FRONT HARNESS
: ENGINE HARNESS
ENGINE No.2 HARNESS
: REAR HARNESS
: INSTRUMENT PANEL HARNESS
: EMISSION HARNESS