

@2 : SKYACTIV-D 1.5




cardiagn.com


0517-101
TCM




0517-102
ELECTRIC AT OIL PUMP




0517-104
STEERING SHIFT SWITCH




0922-201
CLOCK SPRING




0922-202
CRUISE CONTROL SWITCH /
STEERING SWITCH /
CLOCK SPRING




0940-103A
START STOP UNIT




Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.



[SKYACTIV-G 1.3, 1.5]





[SKYACTIV-D 1.5]

: FRONT HARNESS
: ENGINE HARNESS
ENGINE No.2 HARNESS
: INSTRUMENT PANEL HARNESS
: EMISSION HARNESS

cardiagn.com