





0810-101A
SAS CONTROL MODULE




0810-101B
SAS CONTROL MODULE




0810-106
DRIVER-SIDE FRONT PRE-TENSIONER SEAT BELT




0810-107
PASSENGER-SIDE FRONT PRE-TENSIONER SEAT BELT




0810-108
DRIVER-SIDE CURTAIN AIR BAG MODULE




0810-109
PASSENGER-SIDE CURTAIN AIR BAG MODULE




0810-110
DRIVER-SIDE SIDE AIR BAG SENSOR



0810-111
PASSENGER-SIDE SIDE AIR BAG SENSOR



Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.


[YELLOW]
DRIVER-SIDE CURTAIN AIR BAG MODULE
0810-108
[YELLOW]
PASSENGER-
SIDE CURTAIN AIR BAG MODULE
0810-109
(R)[DARK GRAY]
(R)-SHORT CORD
C-21
(R)[DARK GRAY]
(R)-SHORT CORD
C-20
[YELLOW]
DRIVER-SIDE FRONT PRE-TENSIONER
SEAT BELT
0810-106
0810-110
DRIVER-SIDE SIDE AIR BAG SENSOR
[BLACK]
0810-101B
SAS CONTROL MODULE
[YELLOW]
C-20
(R)-SHORT CORD
C-21
(R)-SHORT CORD
0810-107
PASSENGER-SIDE FRONT PRE-
TENSIONER SEAT BELT
[YELLOW]
[4SD]
0810-111
PASSENGER-SIDE SIDE AIR BAG SENSOR
[BLACK]
[YELLOW]
DRIVER-SIDE CURTAIN AIR BAG MODULE
0810-108
[YELLOW]
PASSENGER-SIDE CURTAIN AIR BAG MODULE
0810-109
(R)[DARK GRAY]
(R)-SHORT CORD
C-21
[YELLOW]
SAS CONTROL MODULE
0810-101B
[YELLOW]
SAS CONTROL MODULE
0810-101A
[YELLOW]
PASSENGER-SIDE
FRONT PRE-
TENSIONER SEAT BELT
0810-107
C-20
(R)-SHORT CORD
(R)[DARK GRAY]
0810-106
DRIVER-SIDE FRONT PRE-TENSIONER SEAT BELT
[YELLOW]
0810-110
DRIVER-SIDE SIDE AIR BAG SENSOR
[BLACK]
[5HB]
0810-111
PASSENGER-SIDE SIDE AIR BAG SENSOR
[BLACK]
: REAR HARNESS
: REAR No.2 HARNESS
: DOOR HARNESS
: INTERIOR LIGHT HARNESS
INTERIOR LIGHT No.2 HARNESS