





0912-201A
POWER WINDOW MAIN SWITCH / POWER OUTER MIRROR SWITCH / DOOR LOCK SWITCH (RH)




0912-203
POWER WINDOW SUBSWITCH (LF)




0912-205
POWER WINDOW SUBSWITCH (LR)




0912-207
POWER WINDOW SUBSWITCH (RR)




0912-204
POWER WINDOW MOTOR (LF)




0912-206
POWER WINDOW MOTOR (LR)



0912-208
POWER WINDOW MOTOR (RR)



Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.


POWER WINDOW SUBSWITCH (LR)
0912-205
POWER WINDOW MOTOR (LR)
0912-206
(DR4)[LIGHT GRAY]
(R)-(DR4)
C-17
POWER WINDOW SUBSWITCH (LF)
0912-203
POWER WINDOW MOTOR (LF)
0912-204
(R)-(DR2)
C-16
(R)-(DR1)
C-15
0912-201A
POWER WINDOW MAIN SWITCH /
POWER OUTER MIRROR SWITCH /
DOOR LOCK SWITCH (RH)
C-18
(R)-(DR3)
(DR3)[LIGHT GRAY]
[4SD]
0912-208
POWER WINDOW MOTOR (RR)
0912-207
POWER WINDOW SUBSWITCH (RR)
(R)-(DR2)
C-16
C-15
(R)-(DR1)
POWER WINDOW SUBSWITCH (LF)
0912-203
POWER WINDOW MOTOR (LF)
0912-204
(R)-(DR2)
C-16
(DR4)[LIGHT GRAY]
(R)-(DR4)
C-17
(R)-(DR1)
C-15
0912-206
POWER WINDOW MOTOR (LR)
0912-201A
POWER WINDOW MAIN SWITCH /
POWER OUTER MIRROR SWITCH /
DOOR LOCK SWITCH (RH)
[5HB]
C-18
(R)-(DR3)
(DR3)[LIGHT GRAY]
0912-205
POWER WINDOW SUBSWITCH (LR)
0912-208
POWER WINDOW MOTOR (RR)
0912-207
POWER WINDOW SUBSWITCH (RR)
: FRONT HARNESS
: REAR HARNESS
: REAR No.2 HARNESS
: DOOR HARNESS
: INTERIOR LIGHT HARNESS
INTERIOR LIGHT No.2 HARNESS