






0912-201A
POWER WINDOW MAIN SWITCH / POWER OUTER MIRROR SWITCH / DOOR LOCK SWITCH (RH)





0912-201B
POWER WINDOW MAIN SWITCH / POWER OUTER MIRROR SWITCH





0912-202
POWER WINDOW MOTOR (RF)






0940-101B
BCM





Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.








: FRONT HARNESS
: ENGINE HARNESS
ENGINE No.2 HARNESS
: REAR HARNESS
: REAR No.2 HARNESS
: EMISSION HARNESS
: DOOR HARNESS
: INTERIOR LIGHT HARNESS
INTERIOR LIGHT No.2 HARNESS




[SKYACTIV-G 1.3, 1.5]




[SKYACTIV-D 1.5]